



802.11n-HT20 AV PSD - Ant 0 / Ant 0 + 1 (CDD Mode)


Channel 01 (2412MHz)



Channel 06 (2437MHz)



Channel 11 (2462MHz)




802.11n-HT40 AV PSD - Ant 0 / Ant 0 + 1 (CDD Mode)

Channel 03 (2422MHz)



Channel 06 (2437MHz)




Channel 09 (2452MHz)




802.11b AV PSD - Ant 1 (SISO Mode)


Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11g AV PSD - Ant 1 / Ant 0 + 1 (CDD Mode)


Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11n-HT20 AV PSD - Ant 1 / Ant 0 + 1 (CDD Mode)


Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11n-HT40 AV PSD - Ant 1 / Ant 0 + 1 (CDD Mode)


Channel 03 (2422MHz)



Channel 06 (2437MHz)




Channel 09 (2452MHz)




802.11n-HT20 AV PSD - Ant 0 / Ant 0 + 1 (Beam-Forming Mode)


Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11n-HT20 AV PSD - Ant 1 / Ant 0 + 1 (Beam-Forming Mode)


Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11n-HT40 AV PSD - Ant 1 / Ant 0 + 1 (Beam-Forming Mode)

Channel 03 (2422MHz)



Channel 06 (2437MHz)



Channel 09 (2452MHz)



結束