




**1. External Photograph of EUT**

**Brand Name: Sony / Model Name: Xperia XA1 Plus (G3426)**



Brand Name: Sony / Model Name: Xperia XA1 Plus (G3426)



**Brand Name: Sony / Model Name: Xperia XA1 Plus (G3426)**



Brand Name: Sony / Model Name: Xperia XA1 Plus (G3426)



**Brand Name: Sony / Model Name: Xperia XA1 Plus (G3426)**



**Brand Name: Sony / Model Name: Xperia XA1 Plus (G3426)**




**2. Photograph of Accessory****Brand Name: Sony / Model Name: Xperia XA1 Plus (G3426)**

| Specification of Accessory |             |             |
|----------------------------|-------------|-------------|
| AC Adapter 1               | Brand Name  | Sony        |
|                            | Model Name  | UCH20       |
|                            | Manufacture | 飛宏          |
| AC Adapter 2               | Brand Name  | Sony        |
|                            | Model Name  | UCH20       |
|                            | Manufacture | 群閎          |
| Car Charger                | Brand Name  | Sony        |
|                            | Model Name  | AN400       |
| Battery                    | Brand Name  | Sony        |
|                            | Model Name  | LIP1653ERPC |
| Earphone 1                 | Brand Name  | Sony        |
|                            | Model Name  | MH410c      |
| Earphone 2                 | Brand Name  | Sony        |
|                            | Model Name  | MH410c      |
| USB Cable                  | Brand Name  | Sony        |
|                            | Model Name  | UCB20       |

**Remark:** For accessories equipped with this EUT, please refer to the following photos.

Brand Name: Sony / Model Name: Xperia XA1 Plus (G3426)



Brand Name: Sony / Model Name: Xperia XA1 Plus (G3426)

AC Adapter 1



Brand Name: Sony / Model Name: Xperia XA1 Plus (G3426)

AC Adapter 2



Brand Name: Sony / Model Name: Xperia XA1 Plus (G3426)

Battery

