






































NTNV-11N40SISO-Ant1-5230-5250~5251-See table below





NTNV-11N40SISO-Ant1-5230-5251~5270-PASS

































NTNV-11AC20SISO-Ant1-5180-30~5142-PASS





NTNV-11AC20SISO-Ant1-5180-5142~5150-PASS

















NTNV-11AC20SISO-Ant1-5240-30~5142-PASS




NTNV-11AC20SISO-Ant1-5240-5142~5150-PASS



NTNV-11AC20SISO-Ant1-5240-5250~5251-See table below




NTNV-11AC20SISO-Ant1-5240-5251~5260-See table below




NTNV-11AC20SISO-Ant1-5240-5260~5266.7-PASS




NTNV-11AC20SISO-Ant1-5240-5266.7~26000-PASS








NTNV-11AC20SISO-Ant1-5260-5240~5249-See table below





NTNV-11AC20SISO-Ant1-5260-5249~5250-See table below




































NTNV-11AC20SISO-Ant1-5700-5765~26000-See table below




NTNV-11AC40SISO-Ant1-5190-30~5141.6-PASS












NTNV-11AC40SISO-Ant1-5230-5141.6~5150-PASS



NTNV-11AC40SISO-Ant1-5230-5250~5251-See table below




NTNV-11AC40SISO-Ant1-5230-5251~5270-See table below




NTNV-11AC40SISO-Ant1-5230-5270~5278.4-PASS




NTNV-11AC40SISO-Ant1-5230-5278.4~26000-See table below




NTNV-11AC40SISO-Ant1-5270-30~5221.6-PASS







NTNV-11AC40SISO-Ant1-5270-5249~5250-See table below




NTNV-11AC40SISO-Ant1-5270-5350~5358.4-PASS






NTNV-11AC40SISO-Ant1-5310-5221.6~5230-PASS




NTNV-11AC40SISO-Ant1-5310-5230~5249-PASS








NTNV-11AC40SISO-Ant1-5310-5358.4~26000-PASS





NTNV-11AC40SISO-Ant1-5510-30~5460-PASS

















NTNV-11AX20SISO-Ant1-5180-5260~5266.7-PASS





NTNV-11AX20SISO-Ant1-5180-5266.7~26000-PASS


















NTNV-11AX20SISO-Ant1-5240-5250.2~5251-See table below




NTNV-11AX20SISO-Ant1-5240-5251~5260-PASS







NTNV-11AX20SISO-Ant1-5260-5240~5249-See table below



NTNV-11AX20SISO-Ant1-5260-5249~5249.8-See table below