

Figure 17
Inside Configuration of the EUT




Figure 18
Inside Configuration of the EUT




Figure 19
Inside Configuration of the EUT



Figure 20
Inside Configuration of the EUT



Figure 21

Inside Configuration of the EUT




Figure 22

Inside Configuration of the EUT




Figure 23
Inside Configuration of the EUT



Figure 24
Inside Configuration of the EUT




Figure 25
Inside Configuration of the EUT



Figure 26
Inside Configuration of the EUT



Figure 27
Inside Configuration of the EUT



Figure 28
Inside Configuration of the EUT




Figure 29
Inside Configuration of the EUT




Figure 30
Inside Configuration of the EUT




Figure 31
Module of the EUT




Figure 32
Module of the EUT




Figure 33
WIFI Antenna of the EUT





Figure 34
WIFI Antenna of the EUT



Figure 35
WIFI Antenna of the EUT



THE END