




NTNV-11N20SISO-Ant1-5180-5260~5266.7-PASS




NTNV-11N20SISO-Ant1-5180-5266.7~26000-PASS




NTNV-11N20SISO-Ant1-5200-30~5142-PASS




NTNV-11N20SISO-Ant1-5200-5142~5150-PASS



NTNV-11N20SISO-Ant1-5200-5250~5251-PASS




NTNV-11N20SISO-Ant1-5200-5251~5260-PASS




NTNV-11N20SISO-Ant1-5200-5260~5266.7-PASS




NTNV-11N20SISO-Ant1-5200-5266.7~26000-PASS




NTNV-11N20SISO-Ant1-5220-30~5142-PASS




NTNV-11N20SISO-Ant1-5220-5142~5150-PASS



NTNV-11N20SISO-Ant1-5220-5250~5251-PASS




NTNV-11N20SISO-Ant1-5220-5251~5260-PASS




NTNV-11N20SISO-Ant1-5220-5260~5266.7-PASS




NTNV-11N20SISO-Ant1-5220-5266.7~26000-PASS




NTNV-11N20SISO-Ant1-5240-30~5142-PASS




NTNV-11N20SISO-Ant1-5240-5142~5150-PASS



NTNV-11N20SISO-Ant1-5240-5250~5251-See table below




NTNV-11N20SISO-Ant1-5240-5251~5260-See table below




NTNV-11N20SISO-Ant1-5240-5260~5266.7-PASS




NTNV-11N20SISO-Ant1-5240-5266.7~26000-PASS




NTNV-11N40SISO-Ant1-5190-30~5141.6-PASS




NTNV-11N40SISO-Ant1-5190-5141.6~5150-PASS



NTNV-11N40SISO-Ant1-5190-5250~5251-PASS




NTNV-11N40SISO-Ant1-5190-5251~5270-PASS




NTNV-11N40SISO-Ant1-5190-5270~5278.4-PASS




NTNV-11N40SISO-Ant1-5190-5278.4~26000-PASS




NTNV-11N40SISO-Ant1-5230-30~5141.6-PASS




NTNV-11N40SISO-Ant1-5230-5141.6~5150-PASS



NTNV-11N40SISO-Ant1-5230-5250~5251-See table below




NTNV-11N40SISO-Ant1-5230-5251~5270-PASS




NTNV-11N40SISO-Ant1-5230-5270~5278.4-PASS




NTNV-11N40SISO-Ant1-5230-5278.4~26000-PASS




NTNV-11AC20SISO-Ant1-5180-30~5142-PASS




NTNV-11AC20SISO-Ant1-5180-5142~5150-PASS




NTNV-11AC20SISO-Ant1-5180-5250~5250.2-PASS



NTNV-11AC20SISO-Ant1-5180-5250.2~5251-PASS




NTNV-11AC20SISO-Ant1-5180-5251~5260-PASS




NTNV-11AC20SISO-Ant1-5180-5260~5266.7-PASS




NTNV-11AC20SISO-Ant1-5180-5266.7~26000-PASS




NTNV-11AC20SISO-Ant1-5200-30~5142-PASS




NTNV-11AC20SISO-Ant1-5200-5142~5150-PASS



NTNV-11AC20SISO-Ant1-5200-5250~5251-PASS




NTNV-11AC20SISO-Ant1-5200-5251~5260-PASS




NTNV-11AC20SISO-Ant1-5200-5260~5266.7-PASS




NTNV-11AC20SISO-Ant1-5200-5266.7~26000-PASS




NTNV-11AC20SISO-Ant1-5220-30~5142-PASS




NTNV-11AC20SISO-Ant1-5220-5142~5150-PASS




NTNV-11AC20SISO-Ant1-5220-5250~5250.2-PASS



NTNV-11AC20SISO-Ant1-5220-5250.2~5251-PASS




NTNV-11AC20SISO-Ant1-5220-5251~5260-PASS




NTNV-11AC20SISO-Ant1-5220-5260~5266.7-PASS




NTNV-11AC20SISO-Ant1-5220-5266.7~26000-PASS




NTNV-11AC20SISO-Ant1-5240-30~5142-PASS




NTNV-11AC20SISO-Ant1-5240-5142~5150-PASS



NTNV-11AC20SISO-Ant1-5240-5250~5251-See table below




NTNV-11AC20SISO-Ant1-5240-5251~5260-PASS




NTNV-11AC20SISO-Ant1-5240-5260~5266.7-PASS




NTNV-11AC20SISO-Ant1-5240-5266.7~26000-PASS




NTNV-11AC40SISO-Ant1-5190-30~5141.6-PASS




NTNV-11AC40SISO-Ant1-5190-5141.6~5150-See table below



NTNV-11AC40SISO-Ant1-5190-5250~5251-PASS




NTNV-11AC40SISO-Ant1-5190-5251~5270-PASS




NTNV-11AC40SISO-Ant1-5190-5270~5278.4-PASS




NTNV-11AC40SISO-Ant1-5190-5278.4~26000-PASS




NTNV-11AC40SISO-Ant1-5230-30~5141.6-PASS




NTNV-11AC40SISO-Ant1-5230-5141.6~5150-PASS



NTNV-11AC40SISO-Ant1-5230-5250~5251-See table below




NTNV-11AC40SISO-Ant1-5230-5251~5270-See table below




NTNV-11AC40SISO-Ant1-5230-5270~5278.4-See table below




NTNV-11AC40SISO-Ant1-5230-5278.4~26000-See table below




NTNV-11AX20SISO-Ant1-5180-30~5142-PASS




NTNV-11AX20SISO-Ant1-5180-5142~5150-PASS




NTNV-11AX20SISO-Ant1-5180-5250~5250.2-PASS




NTNV-11AX20SISO-Ant1-5180-5250.2~5251-PASS




NTNV-11AX20SISO-Ant1-5180-5251~5260-PASS




NTNV-11AX20SISO-Ant1-5180-5260~5266.7-PASS




NTNV-11AX20SISO-Ant1-5180-5266.7~26000-PASS




NTNV-11AX20SISO-Ant1-5200-30~5142-PASS




NTNV-11AX20SISO-Ant1-5200-5142~5150-PASS




NTNV-11AX20SISO-Ant1-5200-5250~5250.2-PASS



NTNV-11AX20SISO-Ant1-5200-5250.2~5251-PASS




NTNV-11AX20SISO-Ant1-5200-5251~5260-PASS




NTNV-11AX20SISO-Ant1-5200-5260~5266.7-PASS




NTNV-11AX20SISO-Ant1-5200-5266.7~26000-PASS




NTNV-11AX20SISO-Ant1-5220-30~5142-PASS




NTNV-11AX20SISO-Ant1-5220-5142~5150-PASS




NTNV-11AX20SISO-Ant1-5220-5250~5250.2-PASS



NTNV-11AX20SISO-Ant1-5220-5250.2~5251-PASS




NTNV-11AX20SISO-Ant1-5220-5251~5260-PASS




NTNV-11AX20SISO-Ant1-5220-5260~5266.7-PASS




NTNV-11AX20SISO-Ant1-5220-5266.7~26000-PASS



NTNV-11AX20SISO-Ant1-5240-30~5142-PASS




NTNV-11AX20SISO-Ant1-5240-5142~5150-PASS




NTNV-11AX20SISO-Ant1-5240-5250~5250.2-PASS



NTNV-11AX20SISO-Ant1-5240-5250.2~5251-PASS




NTNV-11AX20SISO-Ant1-5240-5251~5260-PASS




NTNV-11AX20SISO-Ant1-5240-5260~5266.7-PASS




NTNV-11AX20SISO-Ant1-5240-5266.7~26000-PASS




NTNV-11AX40SISO-Ant1-5190-30~5141.6-PASS




NTNV-11AX40SISO-Ant1-5190-5141.6~5150-PASS



NTNV-11AX40SISO-Ant1-5190-5250~5251-PASS




NTNV-11AX40SISO-Ant1-5190-5251~5270-PASS




NTNV-11AX40SISO-Ant1-5190-5270~5278.4-PASS




NTNV-11AX40SISO-Ant1-5190-5278.4~26000-PASS




NTNV-11AX40SISO-Ant1-5230-30~5141.6-PASS




NTNV-11AX40SISO-Ant1-5230-5141.6~5150-PASS




NTNV-11AX40SISO-Ant1-5230-5250~5251-PASS



NTNV-11AX40SISO-Ant1-5230-5251~5270-PASS




NTNV-11AX40SISO-Ant1-5230-5270~5278.4-PASS





NTNV-11AX40SISO-Ant1-5230-5278.4~26000-PASS

Step2





NTNV-11A-Ant1-5240-5250~5251-PASS







NTNV-11A-Ant1-5240-5251~5260-PASS







NTNV-11N20SISO-Ant1-5240-5250~5251-PASS







NTNV-11N20SISO-Ant1-5240-5251~5260-PASS







NTNV-11N40SISO-Ant1-5230-5250~5251-PASS







NTNV-11AC20SISO-Ant1-5240-5250~5251-PASS







NTNV-11AC40SISO-Ant1-5190-5141.6~5150-PASS







NTNV-11AC40SISO-Ant1-5230-5250~5251-PASS







NTNV-11AC40SISO-Ant1-5230-5251~5270-PASS







NTNV-11AC40SISO-Ant1-5230-5251~5270-PASS







NTNV-11AC40SISO-Ant1-5230-5270~5278.4-PASS






NTNV-11AC40SISO-Ant1-5230-5278.4~26000-PASS





NTNV-11AC40SISO-Ant1-5230-5278.4~26000-PASS



7.4. OCCUPIED BANDWIDTH (99%)

7.4.1. Limit

ARIB STD-T71, Clause 3.1.2 (11)

Item	Limit
Occupied Bandwidth	≤18MHz (Others, Bandwidth = 18MHz) ≤20MHz (OFDM, Bandwidth = 20MHz) ≤40MHz (OFDM, Bandwidth = 40MHz) ≤80MHz (OFDM, Bandwidth = 80MHz) ≤160MHz (OFDM, Bandwidth = 160MHz)

7.4.2. Test Procedure

Test Method for Radio Equipment mentioned in Certification Regulations Article 2, Item 19-3-2

MIC Notice No.88 Annex45 Clause 4

7.4.3. Test Configuration

Temperature and Voltage Measurement (under normal and extreme test conditions)



Remarks:
The spectrum analyzer could be connected to a monopole antenna or directly connected to the EUT, if the EUT has already employing an antenna connector.


7.4.4. TEST RESULT

Temperature :	28.3℃	Test By:	Huang YiYang
Humidity :	55 %	Test voltage:	Normal voltage


TestCondition	TestMode	Antenna	Frequency[MHz]	Result [MHz]	Limit [MHz]	Verdict
NTNV	11A	Ant1	5180	16.679	≤20	PASS
NTNV	11A	Ant1	5200	16.596	≤20	PASS
NTNV	11A	Ant1	5220	16.572	≤20	PASS
NTNV	11A	Ant1	5240	16.639	≤20	PASS
NTNV	11N20SISO	Ant1	5180	17.831	≤20	PASS
NTNV	11N20SISO	Ant1	5200	17.985	≤20	PASS
NTNV	11N20SISO	Ant1	5220	17.851	≤20	PASS
NTNV	11N20SISO	Ant1	5240	17.863	≤20	PASS
NTNV	11N40SISO	Ant1	5190	36.134	≤40	PASS

NTNV	11N40SISO	Ant1	5230	36.266	≤40	PASS
NTNV	11AC20SISO	Ant1	5180	18.047	≤20	PASS
NTNV	11AC20SISO	Ant1	5200	17.923	≤20	PASS
NTNV	11AC20SISO	Ant1	5220	18.034	≤20	PASS
NTNV	11AC20SISO	Ant1	5240	17.795	≤20	PASS
NTNV	11AC40SISO	Ant1	5190	36.062	≤40	PASS
NTNV	11AC40SISO	Ant1	5230	28.766	≤40	PASS
NTNV	11AX20SISO	Ant1	5180	18.917	≤20	PASS
NTNV	11AX20SISO	Ant1	5200	19.054	≤20	PASS
NTNV	11AX20SISO	Ant1	5220	18.842	≤20	PASS
NTNV	11AX20SISO	Ant1	5240	19.235	≤20	PASS
NTNV	11AX40SISO	Ant1	5190	37.856	≤40	PASS
NTNV	11AX40SISO	Ant1	5230	37.456	≤40	PASS


複製禁止




NTNV-11A-Ant1-5180-PASS




NTNV-11A-Ant1-5200-PASS




NTNV-11A-Ant1-5220-PASS



NTNV-11A-Ant1-5240-PASS




NTNV-11N20SISO-Ant1-5180-PASS



NTNV-11N20SISO-Ant1-5200-PASS




NTNV-11N20SISO-Ant1-5220-PASS



NTNV-11N20SISO-Ant1-5240-PASS



NTNV-11N40SISO-Ant1-5190-PASS



NTNV-11N40SISO-Ant1-5230-PASS