

Annex A.1 Frequency Error

2. 802.11a_20M_Band1_M

2.1. A.1-Frequency Error(NTNV)


Frequency(MHz)	Level(dBm)
5220.007552	11.953



3. 802.11a_20M_Band1_H

3.1. A.1-Frequency Error(NTNV)


Frequency(MHz)	Level(dBm)
5240.007271	11.536



4. 802.11a_20M_Band2_L

4.1. A.1-Frequency Error(NTNV)


Frequency(MHz)	Level(dBm)
5260.005031	11.388



5. 802.11a_20M_Band2_M

5.1. A.1-Frequency Error(NTNV)


Frequency(MHz)	Level(dBm)
5300.003731	10.592



6. 802.11a_20M_Band2_H

6.2. A.1-Frequency Error(NTNV)


Frequency(MHz)	Level(dBm)
5320.003471	10.583



7. 802.11a_20M_Band3_L

7.1. A.1-Frequency Error(NTNV)


Frequency(MHz)	Level(dBm)
5500.003611	9.82



8. 802.11a_20M_Band3_M

8.1. A.1-Frequency Error(NTNV)


Frequency(MHz)	Level(dBm)
5580.004251	9.284



9. 802.11a_20M_Band3_H

9.2. A.1-Frequency Error(NTNV)

Frequency(MHz)	Level(dBm)
5700.003111	11.35



--BLANK BELOW--