



SENTINELLE

by SENTIDRIVE



———— Application Guide ————



Welcome

to Sentidrive's community !

Sentidrive is available for iOS (Apple Store) and Android (Google Play):





Summary

General use

Registration by the application	4
Registration Information	5-7
Register your Sentinelle	8
Sentinelle information	9-10
Account information and equipment list	11
Dashboard	12
Remote photo capture	13
Geolocate your two-wheeler	14
Main menu	15
Quick menu settings	16
Wi-Fi mode connected	17-21
Camera Visualization	22
Your Videos	23-24
Retrieving files in your Sentinelle	25-27
Your Trips	28-30
Your Guardian Angels	31
Your statistics	32
Settings	33-39
Your activities history	40
Equipment registration	41
User Guide	42

Alarms & Alerts


Fall Alarm	44
Theft Alert	45-46
Other alerts	47-48

Package update

Update available	50
Updated installation	51
Updated finalization	52



Registration by the application




Sign up.

Please enter your name.

Please enter your forename.

Create your connection ID :
This is the identifier you will use
to connect to your account.

Enter a valid Email.





Registration Information

Create your connection password.
This password will be used to
access your user account.

Please confirm your
password choice above.



Registration Information

Get your phone number.
This number must be valid and
belongs to the owner of the
Sentinelle : it will be used to notify
you in case of alarm.
A confirmation SMS is sent to the
confirmed number after validation.

Renseignez un numéro de téléphone valide

+33 6 91 12 34 56

Nous venons de vous envoyer un code de validation par SMS

1 2 3 4

Suivant

Précédent

Fill in the 4-digit validation code
received by SMS.
You can receive this validation
code within 1 minute.



Registration Information

Politique de protection des données

Les dispositions légales et réglementaires en matière de protection des données constituent un enjeu particulièrement important pour notre entreprise.

La présente politique de protection des données vise à vous informer, en tant qu'utilisateur de notre application (ci-après l'« Application »), de la nature, de la portée et des finalités des traitements des données à caractère personnel ainsi que sur les droits qui sont les vôtres dès lors que vous nous communiquez des données à caractère personnel.

Elle tient compte des dernières évolutions liées au Règlement Européen n° 2016/679 du 26 avril 2016 de Règlement général sur la protection des données (RGPD), qui est entré en vigueur le 25 mai 2018. Cette politique respecte également les exigences de la Loi n° 78-17 du 6 janvier 1978 relative à l'informatique, aux fichiers et aux libertés telle que modifiée.

Identité du responsable du traitement des données

SENTIDRIVE, société par actions simplifiée au capital de 152 073 €, immatriculée au R.C.S. Lyon sous le numéro 832 091 631, et dont le siège social est situé 46 rue de Marseille (69030) MEYZIEU - France.

Pour toute demande relative à la protection des données, merci de contacter notre responsable de la protection des données par e-mail ou par courrier postal à l'adresse suivante :

Monsieur Thomas BILGER
SENTIDRIVE
46 rue de Marseille
69030 MEYZIEU - France
E-mail : dpd@sentidrive.com

Définitions

Conformément au RGPD, les termes utilisés dans la présente politique de protection des données sont définis comme suit :

J'ai lu et j'accepte ☒

Valider mon inscription

Annuler

After reading the data protection policy, please tick the box «I have read and I accept» in order to validate your registration.



Register your Sentinelle

Fill in the serial number of
your Sentinelle.
(see S/N serial
number slot)

S/N serial number slot :

On your Sentinelle :



On the back of the Quick Start Guide in
the box :



Possibility to scan the QR code.
(see S/N serial number slot)

Fill in the identification key
4-digit on the back of the Quick
Start Guide.



Sentinelle information

Add a name to your Sentinelle.
This name will appear in alert notifications in order to identify the vehicle concerned.

Ces informations nous permettent d'identifier votre véhicule plus rapidement en cas de vol ...

Nommer votre Sentinelle

Marque du véhicule

Cylindrée

Modèle du véhicule

Immatriculation

Année de mise en circulation

N° chassis

Couleur principale

Couleur secondaire

Autre couleur

Suivant

Précédent

Add the vehicle information associated with your Sentinelle.
In the event of theft, this information allows us to identify the vehicle more quickly.




Sentinelle information

Add photos of the vehicle.
They will be kept on your personal
space.





Account information & equipment list




Quick access to equipment/user information.

User Information :
Whenever you request assistance from the Sentidrive team, these details will be requested of you.


Device information linked to the user account.

Associate a new device with your user account.






Dashboard






Remote photo capture




10 seconds after the front camera photo arrives, you can download the rear camera photo.




Switch to the photo Forward / Backward.



Geolocate your two-wheeler



If the connection is «Out of line», click to get information on the last position.





Main menu

Connection status to the wifi
of the equipment.

Connected 
Disconnected 

Connection status of the device to
the server.

Sending videos status to your
personal space.


 Automatic sending to the cloud enabled.
 Sending files to the cloud in progress.

Parking alarm status.

 Disabled
 Activated

État de la détection de chute.


 Disabled
 Activated






PROCHAINEMENT

Quick menu settings



Modify the configuration of your quick menu by remaining pressed on one of the main menu icons.

Tap the icon  to add to the quick menu.



Tap the icon  to remove from the quick menu.



Wi-Fi mode connected



The name of the Wifi corresponds to the IMEI number of your Sentinelle composed of 15 digits (unique identification number). The default password corresponds to the last 8 digits of your Sentinel's WIFI name.

Example:

Wifi name: 864796050000205

Password: 50000205



Number IMEI



Wi-fi mode connected (only ANDROID)



In case of mishandling
(click on the «Cancel» button),
forget the network to proceed with the
operation again.

When connecting to Wifi on
Android, the network of your
Sentinelle will inform you that it is
not connected to the internet, it is
normal.
Press « Connect » and the
connection between your
Sentinelle and your smartphone
can be established correctly.
If you click on the button
« Cancel », the wifi connection will
not be established. Your Sentinelle
will therefore not be reachable.



Wi-fi mode connected (only IOS)




Once connected to the wifi of your Sentinelle, select on the information point of the Wifi.

Select the IP configuration setting.





Wi-fi mode connected (only IOS)



Set the IP to «Manual».

Fill in the following fields:
IP address: 192.168.43.146
Subnet mask: 255.255.255.0

Make sure that the login information is saved correctly and that the auto login button is active.

The Wifi network of your Sentinelle is then well connected and your smartphone keeps its own 4G connection.





Wi-Fi mode connected




Video recovery status.

→ Video recovery setting enabled.

→ Recovery of videos in progress.



Camera Visualization



Access the cameras - in video streaming - to control the angle of view and the cleanliness of the equipment.

Change the viewing angle and image rotation of the cameras by accessing the setting parameters.




Switch video streaming to Front/Back camera.





Your Videos



Access your videos stored on your personal space, your application, or in your Sentinelle.

Search for a video by :
day / week / month.

Start playing your video.

Navigate to location
of your videos :


Personal space



Smartphone memory
(temporary)




Internal memory of your
Sentinelle





Your Videos



Tap the secondary camera to reverse the display of videos.

Sending videos status to your personal space.



Automatic sending to the cloud enabled.
Sending files to the cloud in progress.

In order to select multiple files, stay pressed on the video and then select your videos.

Delete the video.

Sending the video to your personal space.


Sending files to the cloud in progress.





Retrieving files in your Sentinelle

Navigate through the folders of your Sentinelle.



Standard Videos :

Streaming videos.
The oldest file will be overwritten when the memory is full.

Collision Videos :

Recording videos during a fall.
This folder is protected and must be deleted manually.

Vibration Videos :

Video recording during vibration detection (parking alarm).
This folder is protected and must be deleted manually.




Retrieving files in your Sentinelle

View storage subfolders by date.

Delete the entire contents of the folder.


Navigate to the subfolder's contents.

Delete a folder and its contents.






Retrieving files in your Sentinelle



Upload a video file to the smartphone memory.


Delete a video file.

Please wait for the targeted videos to download.
The videos will be accessible through tab  after downloading.






Your Trips



Access your trips.


Search for a trip by :
day / week / month

Select your trip to access the
details of the information.
In order to facilitate your search,
we display the city of departure,
the city of arrival as well as the
distance traveled and the time
of the trip made.






Your Trips




Find the detailed information of your trip as well as the itinerary made.

Move the slider from left to right to relive your trip.
The icons on either side of the navigation bar give you point-by-point accuracy.






Your Trips




In order to delete multiple files,
stay pressed on a trip and then
select your trip to delete.





Your Guardian Angels



Define your guardian angels:
in case of fall they will be
automatically alerted by SMS.

Fill in the surname, first name and
telephone number of the guardian
angel to add.
He will receive an SMS to validate
your request. Then, he will have to
fill in his name and surname within
15 minutes after receiving the
SMS (identical to the fields you
entered).

Find the list of your Guardian
Angels and their status.

● = confirmed
● = awaiting confirmation


Allows you to remove a guardian
angel.

Allows you to resend a
confirmation SMS to your pending
Guardian Angel if the request has
expired.





Your statistics




Access your statistics.

View your data by :
week / month / year





Settings



Access settings.


Access your personal information.

Access your subscription.

Access your equipment.


Access to your general settings.

Access to your equipment settings.





Settings - my personal information





Settings - my subscription

Information about your subscription.



Access to the request to cancel your subscription.

Access to the subscription.



Settings - my equipment

If more than one device is available,
select the device you want to view.

Edit the characteristics of your
equipment.
Only information not filled in is
editable.

12:58

MES ÉQUIPEMENTS

MA MOTO

S/N Number SEA11A1A6D1000

Type d'équipement Sentinelle

Marque du véhicule Yamaha

Cylindrée 600

Modèle Fazer

Immat PL-123

Année mise en circulation 1999

N° Chassis ABCHEMOCHJK123456

Couleur principale Gris

Couleur secondaire Noir

Autre couleur Blanc

Affichage photos

Libérer l'équipement

Éteindre l'équipement

Turn off your equipment.
As soon as your vehicle is started,
your equipment will start up again.

Free up your equipment.
You will be redirected to a form
to release it permanently.



Settings - my general settings



Change the language of your app.



Settings - my equipment settings

Phone storage allocated to Sentidrive video data. Data is uploaded to your personal space when you connect to a verified WiFi network.

Video recording time.

Delay before your Sentinel goes to sleep Sentinel when you turn off the ignition.

Enabling / disabling the automatic sending of videos to your personal space. The videos are sent as soon as you connect to a known Wifi network.

Automatic video retrieval when you connect to your Sentinel's Wi-Fi network. Wifi network of your Sentinel.

Enabling / disabling the «low battery» notification. This alarm is triggered when the voltage of your of your vehicle is below the set threshold set triggering threshold.

Threshold for triggering the «low battery» alarm.

Activation/deactivation of the battery protection. The equipment switches off when the voltage in your vehicle falls below the set trigger threshold. The equipment is therefore no longer protected. In the event of prolonged standby, we recommend the use of a trickle charger A slight consumption can be observed when the equipment is switched off.

Battery protection trip threshold.

Enabling / disabling the «lost connection» notification. This alarm is triggered when your Sentinel no longer communicates with the Sentidrive server.

MES PARAMÈTRES ÉQUIPEMENT

MA MOTO

Paramètres généraux

- Alarme batterie faible
- Seuil de déclenchement 12,5 Volt
- Protection batterie
- Seuil de déclenchement 12,0 Volt
- Alarme perte de connexion

Paramètres vidéo

- Limite de stockage 40 Go - 3h18
- Durée d'enregistrement 3 min
- Délai avant veille 15 sec
- Envoi automatique au cloud
- Récupération automatique

Alarme de chute

- Activation
- Sensibilité Tout-terrain



Settings - my equipment settings

Enabling / disabling of the fall alarm (when stationary and in motion).

Enabling / disabling the parking alarm.

After switching off the ignition, the delay before the vibration monitoring is activated for the parking alarm.

On detection of a vibration, delay before sending the parking alarm. Starting the vehicle during this delay cancels the alarm.

Sensitivity for triggering the parking alarm.

Trigger sensitivity based on impact analysis. For urban use, keep the setting «road». For off-road use, set the parameter to «off-road».

Setting the video quality of the front camera.


Rotation of the front camera. The control of the set angle is explained on page 21: Viewing the cameras.

Adjusting the video quality of the rear camera.

Rotating the rear camera. The control of the set angle is explained on page 21: Viewing the cameras.



Activities history




Access to the activity and alert history of your Sentinelle.

Access to a specific date.





Equipment registration




Associate a new device with your user account.



User Guide

Access to the user guide
from the application.





Alarms & Alerts



Fall Alarm

When we detect a crash, we will contact you via phone call or notification. Unless you respond within 3 minutes, we will send emergency SMS to your Guardian Angels.




If the fall is not real or not serious, then you can raise the alert on the application or by replying to the voice message received. Emergency SMS sent to your Guardian Angels will then be canceled.

For emergency situations, you can immediately dial 112 via the app and be put in touch with rescue services.



Theft Alert

Your vehicle's position.
If a vibration is detected, your vehicle will be geolocated every second during 60 seconds.
If the vehicle is moved, the geolocation will continue until the vehicle is fully stopped.
In the meantime, the system will then switch back to standby while waiting for the next tremor.



Time since vibration detection on your vehicle.


In case of doubt, if you are not close to your vehicle, you can retrieve the video footage of the triggering of the vibration alarm.



Theft Alert



Vibration trigger videos display.
The video sequence lasts
5 seconds and runs in a loop.




If the potential danger is ruled
out, raise the alert.



Other Alerts


Cause : The voltage of your vehicle is less than 11.8 Volt.



SENTIDRIVE il y a 4 mn

Batterie faible
Batterie faible détectée sur votre deux-roues Ma moto.
Éteindre votre Sentinelle pour protéger votre batterie ?


Cause : Disconnection of the vehicle battery from the red or black wire of the power module of your Sentinelle or interruption of the power supply (battery of the vehicle no longer providing any energy at all).



SENTIDRIVE il y a 4 mn

Votre Sentinelle n'est plus alimentée
Veuillez vérifier le raccordement de votre Sentinelle Ma moto à la batterie


Cause : Your Sentinelle's internal memory is not working properly. If the problem persists after restarting your Sentinelle, please contact Sentidrive Support.



SENTIDRIVE il y a 4 mn

Mémoire interne non détectée
Veuillez redémarrer votre Sentinelle Ma moto


Cause : Your Sentinelle's internal memory is not working properly. If the problem persists after restarting your Sentinelle, please contact Sentidrive Support.



SENTIDRIVE il y a 4 mn

Mémoire interne erronée
Veuillez redémarrer votre Sentinelle Ma moto

Cause: The collision file of your Sentinelle is almost full. It is protected against automatic rewriting. It is therefore necessary to clean it manually before the operation of your Sentinelle is blocked.
Procedure available on page 19.



SENTIDRIVE il y a 4 mn

Mémoire presque pleine
Pensez à nettoyer le dossier collision pour ne pas bloquer le fonctionnement de votre Sentinelle



Other Alerts

Cause : Your Sentinelle's collision file is full.

It is protected against automatic rewriting. It is therefore necessary to clean it manually.
Procedure available on page 19.

 SENTIDRIVE il y a 4 mn
Mémoire pleine
Nettoyez le dossier collision pour débloquer le fonctionnement de votre Sentinelle Ma moto SENTIDRIVE il y a 4 mn
Mémoire presque pleine
Pensez à nettoyer le dossier vibration pour ne pas bloquer le fonctionnement de votre Sentinelle

Cause : The vibration record of your Sentinelle is full.
It is protected against automatic rewriting. It is therefore necessary to clean it manually.
Procedure available on page 19.

 SENTIDRIVE il y a 4 mn
Mémoire pleine
Nettoyez le dossier vibration pour débloquer le fonctionnement de votre Sentinelle Ma moto

Cause : The vibration record of your Sentinel is almost full.
It is protected against automatic rewriting. It is therefore necessary to clean it manually before the operation of your Sentinel is blocked.
Procedure available on page 19.

 **Perte de connexion** maintenant
La connexion de votre Sentinelle Sentinelle Mini Salon au serveur est interrompue

Cause : Your Sentinelle no longer communicates with the Sentidrive server because no 2G / 3G / 4G network available (example: underground garage, white area)

Cause : Your Sentinelle is communicating with the Sentidrive server again.


 **Connexion retrouvée** maintenant
La connexion de votre Sentinelle Sentinelle Mini Salon au serveur est retrouvée



Package update



Update available




Download the update of your Sentinelle on your Smartphone.
If you click cancel, it will be offered to you again in 12 hours.



The update is being downloaded.
Please wait and don't close the application.



Update installation




Install the update on your Sentinelle. The update is carried out by Wifi. It will be necessary to stay close to your vehicle for the time of the transfer (about 3 minutes).



The update is being installed. Please wait and do not close the application.



Updated finalization



Your Sentinelle will automatically restart within a period of 2 minutes to complete the installation. Don't turn off the contact of your two-wheeler during this restart.



For any technical questions, the Sentidrive
team remains at your disposal:
support@sentidrive.com

www.sentidrive.com