


EUT External Photographs

External Photo – Top View



External Photo – Bottom View



External Photo – Left-side View



External Photo – Right-side View



External Photo – Front View



External Photo – Rear View



Antenna Specification

Part Number	Description	Gain Frequency	Antenna Picture or Web Link or Both
AIR-ANT2524DB-R/=	Dipole Antenna, Black, with RP-TNC connectors.	2 dBi (2.4 GHz) 4 dBi (5 GHz)	 https://www.cisco.com/c/en/us/td/docs/wireless/antenna/installation/guide/ant2524.html?dtid=osscdc000283
AIR-ANT2524DG-R/=	Dipole Antenna, Gray, with RP-TNC connectors.	2 dBi (2.4 GHz) 4 dBi (5 GHz)	 https://www.cisco.com/c/en/us/td/docs/wireless/antenna/installation/guide/ant2524.html?dtid=osscdc000283
AIR-ANT2524DW-R/=	Dipole Antenna, White, with RP-TNC connectors.	2 dBi (2.4 GHz) 4 dBi (5 GHz)	https://www.cisco.com/c/en/us/td/docs/wireless/antenna/installation/guide/ant2524.html

AIR-ANT2524DW-RS=	Dipole Self-Identifying Antenna, White, with RP-TNC connectors.	2 dBi (2.4 GHz) 4 dBi (5 GHz)	https://www.cisco.com/c/en/us/td/docs/wireless/antenna/installation/guide/ant2524.html
AIR-ANT2524V4C-R=	Ceiling Mount Omni Antenna, 4-port, with RP-TNC connectors.	2 dBi (2.4 GHz) 4 dBi (5 GHz)	 https://www.cisco.com/c/en/us/td/docs/routers/connectedgrid/antennas/installing-combined/industrial-routers-and-industrial-wireless-antenna-guide/AIR-ANT2524V4C-R.html?dtid=ossdc000283
AIR-ANT2524V4C-RS=	Ceiling Mount Omni Self-Identifying Antenna, 4-port, with RP-TNC connectors.	2 dBi (2.4 GHz) 4 dBi (5 GHz)	https://www.cisco.com/c/en/us/td/docs/wireless/antenna/installation/guide/ant2524v4c.pdf
AIR-ANT2535SDW-R=	Low Profile Antenna, White, with RP-TNC connectors.	3 dBi (2.4 GHz) 5 dBi (5 GHz)	 https://www.cisco.com/c/en/us/td/docs/wireless/antenna/installation/guide/ant2535sdwr.html?dtid=ossdc000283
AIR-ANT2535SDW-RS=	Low Profile Self-Identifying Antenna, White, with RP-TNC connectors.	3 dBi (2.4 GHz) 5 dBi (5 GHz)	https://www.cisco.com/c/en/us/td/docs/wireless/antenna/installation/guide/ant2535sdwr.html

AIR-ANT2544V4M-R=	Wall Mount Omni Antenna, 4-port, with RP-TNC connectors.	4 dBi (2.4 GHz) 4 dBi (5 GHz)	 https://www.cisco.com/c/en/us/td/docs/routers/connecte dgrid/antennas/installing-combined/industrial-routers-and-industrial-wireless-antenna-guide/AIR-ANT2524V4C-R.html?dtid=osscdc000283
AIR-ANT2544V4M-RS=	Wall Mount Omni Self-Identifying Antenna, 4-port, with RP-TNC connectors.	4 dBi (2.4 GHz) 4 dBi (5 GHz)	https://www.cisco.com/c/en/us/td/docs/wireless/antenna/installation/guide/ant2544v4m-r.html
AIR-ANT2566D4M-R=	60° Patch Antenna, 4-port, with RP-TNC connectors.	6 dBi (2.4 GHz) 6 dBi (5 GHz)	https://www.cisco.com/c/en/us/td/docs/wireless/antenna/installation/guide/ant2566p4w.html
AIR-ANT2566D4M-RS=	60° Patch Self-Identifying Antenna, 4-port, with RP-TNC connectors.	6 dBi (2.4 GHz) 6 dBi (5 GHz)	https://www.cisco.com/c/en/us/td/docs/wireless/antenna/installation/guide/ant2566d4m.html
AIR-ANT2566D4M-DS=	60° Patch Self-Identifying Antenna, 4-port, with 4DART connector.	6 dBi (2.4 GHz) 6 dBi (5 GHz)	https://www.cisco.com/c/en/us/td/docs/routers/connecte dgrid/antennas/installing-combined/industrial-routers-and-industrial-wireless-antenna-guide/AIR-ANT2566D4M-R.html?dtid=osscdc000283
AIR-ANT2566P4W-DS=	Directional Self-Identifying Antenna, 4-port, with 4DART connector.	6 dBi (2.4 GHz) 6 dBi (5 GHz)	https://www.cisco.com/c/en/us/td/docs/wireless/antenna/installation/guide/ant2566p4w.html
AIR-ANT2566P4W-R=	Directional Antenna, 4-port, with RP-TNC connectors.	6 dBi (2.4 GHz) 6 dBi (5 GHz)	https://www.cisco.com/c/en/us/td/docs/wireless/antenna/installation/guide/ant2566p4w.pdf

AIR-ANT2566P4W-RS=	Directional Self-Identifying Antenna, 4-port, with RP-TNC connectors.	6 dBi (2.4 GHz) 6 dBi (5 GHz)	https://www.cisco.com/c/en/us/td/docs/wireless/antenna/installation/guide/ant2566p4w.pdf
AIR-ANT2513P4M-N=	Patch Antenna, 4-port, with N connectors.¹	13 dBi (2.4 GHz) 13 dBi (5 GHz)	https://www.cisco.com/c/en/us/td/docs/wireless/antenna/installation/guide/ant2513p4mn.html