KiDS'N PLAY	CLIENT	PRINTING COLOURS GUIDE / CMYK	DIELINE
	PROJECT 5004106 RC Stunt Tumbler w LED Lights 27 and 49 MHz - 2 Asst'd	C100 M100 Y100 K100 · C0 M99 Y100 K0 · C0 M35 Y100 K0	
	DATE July 8, 2025		

ALTHOUGH EVERY POSSIBLE EFFORT HAS BEEN MADE TO ENSURE ACCURACY, ERRORS CAN OCCUR. PLEASE CHECK THIS PROOF/PDF/JPG FILE CAREFULLY. THIS PROOF FILE IS FOR COLOUR BREAK ONLY AND MAY NOT ACCURATELY REFLECT FINAL PRINTED INKS.

Stunt TUMBLER™

Operating Instructions

Operation requires 2 AA batteries for the remote control and 4 AA batteries for the vehicle (not included)

1. Carefully remove items from package
2. Locate the battery compartment on the back of each item (see diagram below)
3. Unscrew battery cover on the bottom of the vehicle and remote control to insert or replace batteries as needed.
4. On the underside of the car, slide the power switch into the "ON" position.
5. For best result use the vehicle on hard surfaces such as wood or tile.
6. Use Up Down buttons to control FORWARD or REVERSE
7. Use Left Right buttons to control FRONT or REAR stunt action
8. Use a combination of Up, Down, Left and Right buttons for spin and flip stunt action
9. When your vehicle/controller run out of battery power, the vehicle will slow down or stop moving. Simply replace/recharge the batteries as appropriate and keep on playing!



Requires 4 AA batteries (not included)

Controller requires 2 AA batteries (not included)

SAFETY WARNINGS

- Adult supervision is recommended.
- Product may contain small parts that could present a choking hazard.
- Remove and discard all inner packaging before delivering this toy to a child.
- Bags, packing material, etc., are not part of the toy and represent a risk of choking or suffocation.
- Keep the product manual or instructions on product package for future reference.
- It is recommended that this toy and all accessories be periodically examined for potential hazards and that any potentially hazardous parts be repaired or replaced.
- Avoid water, sand and snow when operating your vehicle.
- Do not submerge vehicle or controller in water.
- Keep fingers, hair and loose clothing away from the tires, gears and motor while the vehicle is switched to the "ON" position.
- Never operate your vehicle on the street or highway.
- Not appropriate for children under 6 years.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user`s authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

BATTERY WARNING

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- Insert batteries using the correct polarity. Do not short-circuit the supply terminals.
- Remove batteries when not in use. Recycle or dispose of exhausted batteries according to federal, state, and local laws. Do not dispose of batteries in a fire – they may leak or explode.
- Only use manufacturer specified battery(ies), charger(s) and/or adapter, if applicable, specified by the manufacturer.
- Always use, replace, and recharge (if applicable) batteries under adult supervision.