hiPee

USER'S GUIDE

Content

Brief description ····· 1
Wear instruction ····· 2
Steps for usage ····· 3
Operation & feedback ····· 7
charge ····· 10
Other Information ····· 11

目錄

產品介紹 ····· 1
佩戴指導 ····· 2
使用步驟 ····· 3
操作及反饋 ····· 7
充電 ····· 10
其它信息 ····· 13

目次

製品説明 ····· 1
装着指導 ····· 2
使用手順 ····· 3
操作&フィードバック ····· 7
充電する ····· 10
その他の情報 ····· 15

This product is composed of device and silicone accessory,
please refer to below image for assemble

本產品由主機和頸圈組成，请按图示组装

製品は設備と付属品で構成されている，図のように組み立てる





Wear istruction

please refer to below image for wearing

佩戴指導

請參考圖示的佩戴方式

装着指導

図の装着方法を参考にしてください



1

Power on / Power off

Press the button for 3 seconds to turn on/off the device.

開機 / 關機

長按按鍵 3 秒,設備開機/關機。

起動する / シャットダウン

ボタンを 3 秒間押し続けると、マシンの電源がオン/オフになります。



❷

Connect to mobile phone

Scan the QR code to install the App and operat as instructed.

Noted：Turn on bluetooth and GPS of moblie phone before connecting.

App Store

綁定設備

手機掃描右側二維碼下載App，按照提示進行設備綁定。

連接前請確保開啟藍牙和定位權限。

Google Play

携帯電話に接続する

指示に従ってアプリと操作をインストールするためにQRコードをスキャンします。

接続する前にモブリー電話のブルートゥースとGPSをオンにする

❷

Personalize reminder

Wear it and set the correct posture, angle and delay the reminding time according to the prompts；when the incorrect posture duration,the device will "Vibretion".

個性化設置

佩戴好設備，按軟件提示設置正確身姿、提醒角度、提醒延遲；当持续错误姿态時，設備將“震動提醒”。

パーソナライズされたリマインダ

装着し、指示に従って正しい姿勢、角度、遅延注意時間を設定します。姿勢が正しくないと、装置が振動して注意します。



4

Rest awhile

Double-click the button to pause the reminder for 30 min, during which time double-click the button again to resume the reminder.

休息一下

雙擊按鍵，可暫停提醒 30 分鐘，期間再次雙擊按鍵可恢復提醒。

しばらく休む

ボタンをダブルクリックして、リマインダーを 30 分間一時停止します。期間中、ボタンをもう一度ダブルクリックしてリマインダーを再開します。

Operation and feedback

Device Status	Operating	Vibrations	Indicator lights
Power on	Hold down the button for 3 seconds	Fully charged: turn on after 1 long shock Low battery: Shut down after 1 long shock	Fully charged: Detection mode: blue light keeps on for 5 seconds and then flashes Rest mode: purple light keeps on for 5 seconds and then flashes Low battery: red light flashes Insufficient battery: the device shuts down after the red light flashes twice
Power off	Press and hold the button for 3 seconds after powering on	1 short shock	*
Bluetooth connecting	Bind device in applet	2 short shock	*
Correct posture	Software setting standard posture	Start /Successful : 2 short shocks	Start recording: blue light flashes quickly Record success: blue light flashes
Detecting mode	When bad posture occurs	After 3 s by default Short shock 3 times and repeat	*
Long-sitting reminder	After sitting for 1 hour	3 long shocks	*
Rest mode	Double-click the button	1 short shock	*
Recover detecting mode	In rest mode Double-click the button	2 short shock	*
Check device status	Short press the button	*	Detection mode: blue light on once Rest mode: purple light on once
Charge	*	*	Charging: red light flashes Charging completed: blue light is on

⚠ Cautions

1. When app is unavailable, if you want to record your posture, you can press the button for 8 seconds (please don't let go once in the middle), and the equipment vibrates twice to start recording. After recording, the equipment vibrates twice briefly, indicating that the standard posture record is successful.
2. The vibration modes of posture reminder and sedentary reminder can be modified through "Settings" in the software.
3. When Bluetooth is bound, the short shock twice indicates that the device has been found, and click the device button to bind; When entering the software again, the device can be connected directly.
4. Equipment and app are continuously updated and upgraded. Please refer to the actual version for specific operation.

操作及反馈说明

设备状态	操作说明	震动反馈	指示灯说明
開機	長按按鍵 3 秒	滿電： 長震 1 次後開機 低電： 長震 1 次後關機	滿電： 檢測模式藍燈 5 秒後閃爍 休息模式紫燈 5 秒後閃爍 低電：紅燈 電量不足：紅燈 次後關機
關機	開機後長按 按鍵 3 秒	短震 1 次	*
設備綁定	用手機綁定設備	短震 2 次	*
記錄標準 姿態	設置標準身姿	開始記錄/記錄成功： 短震 2 次	開始記錄：藍燈快速閃爍 紀錄成功：藍燈閃爍
檢測模式	不良姿勢發生時	默認 3 秒後 短震 3 次並重複	*
久坐提醒	久坐 1 小時後	长震 3 次	*
休息模式	雙擊按鍵	短震 1 次	*
繼續檢測	休息模式中 雙擊按鍵	短震 2 次	**
查看設備 當前狀態	短按按鍵	*	檢測模式：藍燈亮 1 次 休息模式：紫燈亮 1 次
充電	*	*	充電中：紅燈閃爍 充電完成：藍燈長亮

⚠ 注意

1. 軟件不可用時，若要記錄身姿，可長按按鍵 8 秒（中間會長震一次請不要鬆手），設備震動 2 次開始記錄，記錄完成後設備會短震 2 次，表示標準身姿記錄成功。
2. 姿態提醒、久坐提醒的震動方式可通過軟件中“設置”進行修改。
3. 藍牙綁定時，短震 2 次表示找到了該設備，單擊設備按鍵可進行綁定；再次進入軟件時，可直接連接該設備。
4. 設備及小程序持續更新升級，具體操作請以實際版本為準。

正しい着用方法

状態	指示	ショック	指示ランプ
起動する	ボタンを 3 秒間押します	完全充電:1 回振動するとオンになります バッテリー低下:1 回振動後にシャットダウンします	完全充電: 検出モード 青い光 は 5 秒です,それからフラッシュ 休憩モード 紫色の光 は 5 秒です,それからフラッシュ バッテリー低下: 赤信号 が点滅 電力不足:が 2 回点滅した後シャットダウン
シャットダウン	電源を入れた後、ボタンを 3 秒間押し続けます	1 回の短い振動	*
電話をバインドする	携帯電話接続機器	2 回の短い振動	*
標準姿勢を記録する	標準姿勢を設定する	開始/成功: 2 回の短い振動	開始: 青い光 すばやく点滅します 成功: 青い光 が点滅します
検出モード	姿勢が悪いとき	初期値:3 秒後、3 回振動して繰り返します	*
座りがちなリマインダー	1 時間座った後	3 回振動	*
レストモード	ダブルクリックボタン	1 回の短い振動	*
テストを続ける	休憩中にボタンをダブルクリック	2 回の短い振動	*
マシンの現在の状態	ボタンを押す	*	検出モード: 青い光 が 1 回点灯 休憩モード: 紫色の光 が 1 回点灯
充電する	*	*	充電中: 赤信号 が点滅 充電が完了しました: 青い光 が点灯しています

⚠ 注意

1. ソフトウェアが利用できない場合、姿勢を記録したい場合は、ボタンを 8 秒間押し続けます(途中で長い揺れがあります。離さないでください)。マシンは 2 回揺れます。録音を開始すると、録音が完了するとデバイスが 2 回ショートシェイクし、標準の姿勢を示します。録音は成功します。
2. 姿勢リマインダーと座りがちなリマインダーの振動モードは、ソフトウェアの「設定」から変更できます。
3. Bluetoothバインド中に、2 つの短い振動がマシンが検出されたことを示します。ボタンをクリックしてバインドします。ソフトウェアを再度入力すると、自動的に接続されます。
4. マシンとソフトウェアは継続的に更新およびアップグレードされます。特定の操作については、実際のバージョンを参照してください。

Charging instruction

1. When charging, please push the back of the machine forward and remove it from the silicone part to see the charging port. (As follows)
2. This device uses a Type-C port for charging, and the power adapter should meet the following requirements, Rated input: 5 V ⎓ 1 A
3. After charging, please unplug the power as soon as possible and stop charging, so as not to damage the lithium battery due to overcharging. Please dry your hands before plugging or unplugging the power adapter.
4. The battery cannot be replaced. When the battery life expires and cannot be charged, the product will be scrapped. Discarded products should be disposed of in accordance with the electronic product disposal regulations stipulated by the state.

充電説明

1. 充電時請推動設備主機背面,將主機從頸圈上取下,可見充電口。(如下圖所示)
2. 本設備使用Type-C端口充電,電源適配器應符合GB 9706.1的要求, 額定輸入:5 V ⎓ 1 A
3. 充電結束請盡快拔下電源停止充電,避免過度充電對鋰電池造成傷害,插拔電源適配器插頭前請將手擦乾。
4. 設備電池不可更換,電池到達壽命無法繼續充電時,產品報廢,報廢的產品應按照國家規定的電子產品處置規則處理。

充電説明

1. 充電するときは、機械の背面を前方に押してシリコン部分から取り外し、充電ポートを確認してください。(次のように)
2. このデバイスは充電にType-Cポートを使用し、電源アダプターは次の要件を満たしている必要があります,定格入力: 5 V ⎓ 1 A
3. 充電後は、リチウム電池の過充電や損傷を防ぐため、できるだけ早く電源を抜いて充電を停止してください。電源アダプタを抜き差しする前に、手を乾かしてください。
4. バッテリーは交換できません。バッテリーの寿命が切れて充電できない場合、製品は廃棄されます。廃棄された製品は、州が規定する電子製品廃棄規則に従って廃棄する必要があります。

Charging period: around 1.5 h
Charging: red light flashes
Fully Charged : blue light is on

充電時長: 約 1.5 小時
充電中: 紅燈閃爍
充電完成: 藍燈常亮

充電時間: 約 1.5 時間
充電中: 赤信号が点滅
充電が完了する: 青いライトが点灯しています



Parameters

Product name: Smart Posture Corrector
Product model: P1
Product size: (Adult) 137×167×32mm
(Kid) 120×132×32mm
Product weight: (Adult) 60 g (Kid) 51 g
battery and neck loop included
Power supply: internal power supply
Rated input: 5V ⎓ 1A
Operating time: 50 h
Charging time: around 1.5 h

Working environment:
temperature: -10 ℃~+55 ℃
relative humidity: ≤ 80%R.H.
atmospheric pressure: (70.0~106.0)kPa.
Storage/transportation conditions:
temperature: -10℃~+55℃
relative humidity: ≤ 80%R.H.
atmospheric pressure: (70.0~106.0)kPa.

Safety Precautions

1. In order to use this product safely and correctly to prevent harm to you and others, please read this manual carefully.
2. This product is recommended for children, adolescents and adults 3 years old and above.
3. The silicone accessories are soft, please put them out of the reach of children to avoid accidental eating by children.
4. Do not use this product in strong electromagnetic fields.
5. The use of unspecified accessories, transducers or cables together with equipment and systems may result in an increase in the emission of the equipment or system or a decrease in immunity; even if other equipment meets the emission requirements of the corresponding national standards, the equipment or system will still It may be interfered by other equipment.
7. Please follow the operating temperature and humidity and storage temperature and humidity recorded in this manual, otherwise the system may not reach the claimed performance specifications.
8. The battery cannot be replaced, please do not disassemble or repair it yourself. If you have any questions, please contact the after-sales unit.
9. This warranty applies to other regions except China.

Warranty description

1. From the date of purchase of this product, within the scope of normal use of the product in accordance with the instructions, if the product has performance failures that are not artificially damaged, the warranty period is 6 months. After 6 months, repairs will be charged.
2. Repairs that are not caused by the quality of the company's products, such as improper use, improper storage, unauthorized disassembly, etc., will be charged for repairs and the freight will be borne by the user.
3. The following conditions are not covered by the free warranty: damage caused by man-made damage, such as damage caused by falling, touching, water immersion, damp, high temperature; damage caused by not following the correct operation of the instruction manual;damage caused by accident; Without the written authorization of the company, the user disassembles and changes the product without authorization, and there is no proof of purchase.
4. This warranty does not apply to China.

Cleaning and maintenance

1. The silicone accessories can be disassembled separately for cleaning and cleaning. The machine is not waterproof, please do not wash it with water; if there is dust or stains, you can wipe the machine with a clean dry cloth or a wrung wet cloth.
2. When cleaning, be sure to shut down and unplug the power adapter.
3. Do not use any cleaning agents or cleaning agents for cleaning. If there is dirt that is difficult to clean, you can wipe it with a disinfectant containing alcohol and other volatile substances. Put it in a cool place and wait for the substance to evaporate before assembling.
4. If the product is not used for a long time, the battery should be charged regularly.

Storage:

1. Do not store the product in high temperature, humidity, direct sunlight, dusty, and salty places; do not place it in a place where it is inclined, vibrated, or impacted; keep away from chemicals or corrosive gases.
2. Avoid hard and sharp materials contacting the silicone fittings to avoid scratches.
3. The cleaned product must be thoroughly dried and stored in an environment that meets the requirements: Storage conditions: temperature: -10°C~+55°C; relative humidity: ≤80%; atmospheric pressure: (70.0~106.0) kPa

Support

The final interpretation right belongs to Tianjin Fruitech Technology Co., Ltd.
If you have any questions, please contact us
Customers in Mainland China can call 400-900-5115 (9:00-18:00)
Email to feedback@fruitech.cn for other regions

參數

產品名稱：智能矯姿精靈
產品型號：P1
產品尺寸：（L碼）137×167×32 毫米
（S碼）120×132×32 毫米
產品重量：（L碼）60 克（含電池、頸圈）
（S碼）51 克（含電池、頸圈）
使用電源：內部電源
額定輸入：5V ⎓1A

工作環境：溫度：-10 ℃~+55 ℃
相對濕度：≤80 %R.H.不凝結狀態
大氣壓力：（70.0~106.0）kPa
貯存/運輸條件：溫度：-10 ℃~+55 ℃
相对湿度：≤80 %R.H.不凝结状态
大气压力：（70.0~106.0）kPa
工作时长：待机状态下约 50 小时
充电时长：约 1.5 小时

安全事項

1. 為了安全且正確地使用本產品，防止對您及他人造成傷害，請仔細閱讀本說明書。
2. 本產品推薦 3 歲及以上兒童、青少年及成人使用。
3. 設備頸圈圈體柔軟，請放在兒童接觸不到的地方，避免兒童誤食。
4. 請勿在強電磁場的場合使用本產品。
5. 對規定外的附件、換能器或電纜與設備和系統一起使用可能導致設備或系統發射的增加或者抗擾度的降低；即使其它設備符合相應的國家標準的發射要求，設備或系統仍可能被其它設備干擾。
7. 請按照本說明書記載的使用溫濕度及保存溫濕度使用，否則係統可能無法達到聲稱的性能規格。
8. 主機電池不可更換，請勿自行拆卸或修理，如有問題請聯繫售後單位。
9. 請勿過分用力彎折拉扯設備頸圈。

保修條例

1. 自您購買本產品之日起，在按照說明書正常使用產品範圍內，如產品出現非人為損壞的性能故障，保修期為 6 個月，6 個月後維修收取工本費。
2. 非本公司產品質量原因引起的維修，如使用不當、保管不妥、擅自拆機等原因造成的損壞，維修收取維修工本費，運費由用戶承擔。
3. 下列情況不屬於免費保修範圍：人為造成的損壞，如摔、碰、浸水、受潮，高溫而導致的損壞；沒有按照使用說明書的正確操作而導致的損壞；由於意外事故造成的損壞；在無本公司書面授權條件下，用戶擅自對產品進行拆裝和更改；沒有購買憑證。
4. 此保修範圍適用於中國香港、中國台灣。

清潔保養

1. 本設備頸圈可單獨拆卸水洗清潔，主機體不防水，請勿用水沖洗清潔；如果有灰塵或污漬，可用潔淨的干布或擰乾的濕布擦拭設備。
2. 進行清潔時，請務必保證設備關機，拔掉電源適配器。
3. 請勿使用任何洗滌劑或清潔劑進行清潔。如有難清潔的髒污，可使用含酒精等易揮發物質的消毒劑進行擦拭，置於陰涼避光處等待物質完全揮發後，再裝在頸圈上。
4. 產品長期不用，應定期對電池進行充電。

貯存

1. 不可將產品保存在高溫、潮濕、日光直射、灰塵多、含鹽分多的地方；不要放在傾斜、振動、衝擊的地方；遠離化學物品或存在腐蝕性氣體。
2. 應避免堅硬鋒利的物質接觸頸圈，以免刮劃損傷頸圈。
3. 清潔後的設備需徹底晾乾，並貯存在滿足要求的環境中：

貯存条件：温度：-10 ℃~+55 ℃

相对湿度：≤80 %R.H.不凝结状态

大气压力：（ 70.0~106.0 ） kPa

支援

最終解釋權歸天津果實科技有限公司所有

如有任何問題可聯繫我們

中國地区用戶可致電諮詢 400-900-5115（ 9：00-18：00 ）

其它地區可郵件至 feedback@fruitech.cn

パラメータ

製品名：スマートポーズ修正ウィザード
製品モデル：P 1
商品サイズ：（Lサイズ）137×167×32mm
（Sコード）120×132×32mm
製品重量：バッテリー、シリコンアクセサリーを含む
（Lサイズ）60グラム
（Sコード）51グラム
電源：内部電源
定格入力：5 V ⎓ 1 A

作業環境：温度：-10℃～+ 55℃
相対湿度：≤80％R.H.
大気圧：（70.0～106.0）kPa
保管・輸送条件：温度：-10℃～+ 55℃
相対湿度：≤80％R.H.
大気圧：（70.0～106.0）kPa
勤務時間：待機時間約 50 時間
充電時間：約 1.5 時間

安全上のご注意

1. 本製品を安全かつ正しく使用し、ご自身や他人への危害を防止するため、本書をよくお読みください。
2. この商品は、3 歳以上の子供、青年、大人におすすめです。
3. シリコンアクセサリーは柔らかいので、お子様が誤って摂取しないように、お子様の手の届かないところに置いてください。
4. この製品を強い電磁界で使用しないでください。
5. 不特定の付属品、トランスデューサー、またはケーブルを機器およびシステムと一緒に使用すると、機器またはシステムのエミッションが増加したり、イミュニティが低下したりする可能性があります。他の機器が対応する国内基準のエミッション要件を満たしている場合でも、機器またはシステムは引き続き他の機器によって干渉される可能性があります。
7. このマニュアルに記録されている動作温度と湿度、および保管温度と湿度に従ってください。従わない場合、システムが要求された性能仕様に達しない可能性があります。
8. バッテリーは交換できませんので、ご自身で分解・修理しないでください。ご不明な点がございましたら、アフターユニットまでお問い合わせください。
9. シリコンアクセサリを過度に曲げたり引っ張ったりしないでください。

保証の説明

1. 本製品の購入日から、取扱説明書に従った通常の使用の範囲内で、製品に人為的な損傷がない性能障害がある場合、保証期間は 6 か月です。6 か月後、修理費がかかります。
2. 不適切な使用、不適切な保管、不正な分解など、当社の製品の品質に起因しない修理は、修理費を請求し、運賃はユーザーが負担します。
3. 以下の条件は、無料保証の対象外です。落下、接触、水浸、湿気、高温などの人為的損傷による損傷、取扱説明書の正しい操作に従わなかったために生じた損傷;事故による損傷;会社の書面による許可なしに、ユーザーは購入の証明なしに許可なく製品を分解および変更します。
4. この保証は、中国を除く他の地域に適用されます。

クリーニングとメンテナンス

1. シリコンアクセサリは、クリーニングとクリーニングのために別々に分解できます。防水仕様ではありませんので、水洗いはご遠慮ください。ほこりや汚れが付着した場合は、清潔な乾いた布または絞った湿った布で拭いてください。
2. 清掃するときは、必ず電源アダプタをシャットダウンしてプラグを抜いてください。
3. 洗浄剤や洗浄剤を使用しないでください。汚れがひどい場合は、アルコールなどの揮発性物質を含む消毒剤で拭き取ってください。涼しい場所に置き、物質が蒸発するのを待ってから組み立ててください。
4. 製品を長期間使用しない場合は、バッテリーを定期的に充電する必要があります。

ストレージ

1.高温多湿、直射日光、ほこり、塩辛い場所に保管しないでください。傾斜、振動、衝撃のある場所に置かないでください。化学薬品や腐食性ガスに近づけないでください。
2.傷を防ぐために、硬くて鋭利な材料がシリコンフィッティングに接触しないようにします。
3.洗浄した製品は完全に乾燥させ、要件を満たす環境で保管する必要があります。
保管条件：温度：-10℃～+ 55℃;相対湿度：≤80%;大気圧：（70.0～106.0）kPa

サポート

最終的な解釈権は天津フルーツテクノロジー株式会社に帰属します。
ご不明な点がございましたら、お問い合わせください。
中国本土のユーザーは 400-900-5115（9：00-18：00）に電話できます
他の地域については feedback@fruitech.cn にメールしてください

CERTIFICATION

Product model: P1

Manufacturer: Tianjin Fruitech Technology Co.,Ltd.

Shelf Life: 5 years

Production Date:

Examiner:

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

•Reorient or relocate the receiving antenna.

•Increase the separation between the equipment and receiver.

•Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

•Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

©2021 Tianjin Fruitech Technology Co.,Ltd. All rights reserved.

G-1101-15 & G-1101-32,No.6 Haitai Development Ave.,Huayuan Industrial Development Zone
Tianjin,Tianjin, 300384

Made in China

www.fruitech.cn
(E-mail) feedback@fruitech.cn