该文档是极速PDF编辑器生成,
如果想去掉该提示,请访问并下载:
https://www.jisupdfeditor.com/

WIRELESS KEYBOARD AND MOUSE COMBO



USER MANUAL

Packing List

1. Keyboard x1
2. Mouse x1
3. USB receiver x1
4. USB-C charging cable*1
5. USB C to USB adapter x1
6. User manual x1

Overview









Operation Guides

1.Fetch the wireless keyboard and mouse, USB receiver.

2.Turn on the power switch of keyboard and mouse.

3.Plug the receiver into the USB port of your computer.

4.When the computer installs driver automatically, they start serving.

Multimedia Key Descriptions



Backlight Function

Keyboard Backlight:

1.The keyboard has 7 kinds of lighting effects.
2.Press keys to adjust the keyboard Backlight off/on
3.Press keys to adjust the keyboard the backlight brightness decreases.
4.Press keys to adjust the keyboard increased backlight brightness.
5.Press keys to adjust the keyboard Backlight effect switch.
6.Press FN + keys to adjust the keyboard backlight speed up
7.Press FN + keys to adjust the keyboard backlight speed slows down.

Mouse Backlight :

1. The mouse has 7 kinds of lighting effects.
2. Press and hold the DPI button for 3seconds to turn off/on the light.
3. Adjustable mouse DPI levels: 800-1200-1600 (default setting is 1200).

Functionsof Combination Keys

KEY	Win	Mac
Win	Switch to Win system	/
Mac	/	Switch to Mac system
FN+F1	Screen brightness -	Screen brightness -
FN+F2	Screen brightness +	Screen brightness +
FN+F3	Convert Window	Convert Window
FN+F4	Calculator	Not for Mac OS
FN+F5	Microphone	Exhale Siri
FN+F6	Search	Search
FN+F7	Previous Track	Previous Track
FN+F8	Play/Pause	Play/Pause
FN+F9	Next Track	Next Track
FN+F10	Mute	Mute
FN+F11	Volume -	Volume -
FN+F12	Volume +	Volume +
FN+ Esc	**F1-F12 Lock/Unlock**	**F1-F12 Lock/Unlock**
FN+ Ins	Switch to the Scrlk function	Switch to the Scrlk function

Notice

1) Please fully charge the keyboard at first time when you use it, this will help preserve battery life.

2) Please unplug the power supply after full charge.

3) It is recommended to turn off the power switch of the keyboard if it's not used for a long time,

4) Do not expose this product to water, otherwise it may cause a short circuit and damage the product.

5) Do not drop or hit this product, as the impact may damage the internal components.

6) Do not put this product near extreme heat or fire.

Solutions for connection exceptions:

Keyboard:
1. Unplug the receiver from the computer
2. Turn on the keyboard switch and press the ESC+K key to pair again
3. Plug the receiver into the computer again, and it can be used normally

Mouse:
1. Unplug the receiver from the computer, and then reinsert it into the computer
2. Turn on the mouse switch, press the scroll wheel and the right button at the same time, you can use it normally

Correct Disposal Of This Product

(Waste Electrical &Electronic Equipment)
This Marking shown on the product or its literature, indicate that it should not be disposed with other household wastes at the end of its working life.

To prevent possible harm to the environment or human health from uncontrolled waste disposal,please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources Household user should contact either the retailer where they purchased this product,or their local government office,for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contact.This product should not be mixed with other commercial wastes for disposal.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment.
The device has been evaluated to meet general RF exposure requirement.
This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter.

Contact Us:

Whatever you need, we're here to help.

Just get in touch, and we'll try our best to respond within 24 hours.

After-sales email：csforcustomer@gmail.com

折叠尺寸：75×100(mm)　展开尺寸：375×100(mm)

材质及工艺：80g书纸 四折页 哑油

印刷颜色：单色 双面印刷