89mm 20231122更新 认证用

127mm

XMCOSY+ Smart

2PK Smart Wall Lights

User Manual

Download Free APP:

Download on the App Store | GET IT ON Google Play

XMcosy+ XMcosy

Can't connect? Need help?

Email:service.2@xmcosy.com

INTRODUCTION

Thanks for choosing XMCOSY+ Wall Lights. Please read the user manual carefully and keep it for future reference.

SAFETY INSTRUCTIONS

Read and follow all safety instructions before installing the smart wall lights.

- **These light fixtures are designed to fit standard junction boxes as defined by the National Electrical Code. Always install wiring connections in accordance with local codes, ordinances, and the National Electric Code. If you are unsure of the installation process, please consult your local electrician.**
- **Install light fixtures in the event of a power outage.**
- **Please keep children away from these lights.**
- **Keep lights away from flammables and fire sources.**
- **Avoid placing the lights near potentially dangerous sources.**

DO NOT EXCEED RATED CAPACITY.

FCC Notice:

This device complies with Part 15 of the FCC Rules. Operation is subject to the two following conditions:

1. This device may not cause harmful interference.

2. This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

CAUTION: Suitable for indoor and outdoor use.

CONTENT

Specifications ---------- 1
Package Contents ---------- 2
Assemble ---------- 3
Lampshade angle adjustment ---------- 6
Service & Warranty ---------- 7
APP Download & Registration ---------- 8
Distribution Network & APP Connection ---------- 11
APP Functions ---------- 15
Alexa Pairing Instruction ---------- 21
Google Assistant Pairing Instruction ---------- 26
Troubleshooting ---------- 29
Contact ---------- 30

SPECIFICATIONS

Brand	XMCOSY+
Model	XMWLA-2
Dimension	10.83" x 3.54" x 4.45"
Base Dimension	4.72" x 4.72"
Weight	2.6KG
Material	Aluminum+ Frosted PC+ Plastic
Light Source	SMD LED
Luminous Flux	1400LM/EA
Color Temperature	2200-6500K
Output Voltage	DC 31V
Wattage	16W
Rotation Angle	350°
Controlled By	APP Control
Dimmable	YES
Junction Box	Standard

PACKAGE CONTENTS



1. Wall Light * 2
2. Screw A M4x30 * 8
3. Screw B M4x20 * 4
4. Wire Nut * 6
5. Arm Hex Key * 1
6. Mounting Bracket * 2
7. User Manual * 1

Notes:

After unpacking, please check the product accessories.

If there are any missing or damaged accessories, please contact us as soon as possible, and our customer service team will solve it in time.

Use Screw A when installing through drilled holes.

Use Screw B when installing on a junction box.

service.2@xmcosy.com

ASSEMBLE

Step - 1

Turn off the main power.



Step - 2

Unscrew the screws to separate the mounting bracket and the wall light.

(Please save these 2 original screws for later installation.)



ASSEMBLE

Step - 3

First of all, remove the mounting bracket from the wall light. Then align and install the mounting bracket to the junction box with screw B.



Step - 4

Choose a wall wire with the same nature as the light wire, and turn the wire nut to connect the two wires together.



White: LIVE Black: NEUTRAL Green: EARTH

ASSEMBLE

Step - 5

Mount the wall light to the mounting bracket with the original screws.

Glue around the base to better prevent water from entering.



Step - 6

Turn on the main power.



LAMPSHADE ANGLE ADJUSTMENT

350° Rotating Head

Each wall light has two lamp heads, which can be freely adjusted within 350°. You can adjust the lighting effects you want according to the needs of the scene.



1. **Long press - Enter the APP connection & network mode**.
   Long press the button for 5S, the light flashes quickly, and the product enters the distribution network mode. (When the product is used for the first time, it will automatically enter the network distribution state after connecting to the power supply, without pressing any buttons.)
2. **Short press - ON/OFF & Change scene modes**
   8 modes(4 kinds of warm white and 4 kinds of color light)
   Short pressing the button, the mode changes in turn as follows:
   * ON(Gorgeous)
   * Good night
   * Reading
   * Working
   * Leisure
   * Grassland
   * Colorful
   * Dazzling
   * Gorgeous
   * OFF

For more scene modes and functions of the product, please connect to the XMcosy APP.

SERVICE & WARRANTY

Thank you for your support of XMCOSY+!

XMCOSY+ provides a regular 1-Year Warranty.

Not Satisfied?

If there is any problem with our product while using, Please Contact

service.2@xmcosy.com

We will provide you with a 100% Satisfied Solution!

Satisfied?

We are glad that you didn't encounter any problems with our smart wall lights.

XMCOSY+ is committed to providing better products and services. Please feel free to contact us if you have any problems with the product.

Scan to email

APP DOWNLOAD & REGISTRATION

Step 1: Download the XMcosy App from App Store or Google Play.



Scan the QR code to download

APP DOWNLOAD & REGISTRATION

Step 2: Register

1. Enter your mobile phone number or email address.

2. Enter the verification code.



APP DOWNLOAD & REGISTRATION

3. Create a password and Log in the App.

4. Please enable the XMcosy App to get your Bluetooth while using the App.



DISTRIBUTION NETWORK & APP CONNECTION

Step 1:



Notes:

1. After power on, the light will automatically enter the connecting state (fast blinking);

2. If the light does not blink, please press and hold the button for 5~7 seconds to make the light flash and enter the APP pairing mode.

DISTRIBUTION NETWORK & APP CONNECTION

Step 2: Register

1. Click the "+" in the home page upper right corner. The devices in the connecting state will be displayed at the top of the page. Click "Add".

2. Click the device you want to add and please make sure that the network you connected is 2.4GHz.



DISTRIBUTION NETWORK & APP CONNECTION

3. Fill in your 2.4GHz network name and password, then click "Next".

4. The product starts to connect until it is 100% completed.



Please keep the router, mobile phone, and product as close as possible to ensure a good reception signal.

DISTRIBUTION NETWORK & APP CONNECTION

5. After you edit the product name and save it, click "Done" at the top right.

Congratulation!

Now you can use XMcosy App to control your wall lights.



Tips:

1. The device name will be used again when paired to Amazon Alexa & Google Home for voice control.

2. The device name is suggested to consist of English words and Arabic numerals, please do not use special characters.

APP FUNCTIONS

WHITE MODE& COLOR MODE

You can choose to turn on the wall light in color light or white light.

RGB Color Mode

*** Color Wheel - Slide the color wheel up and down to adjust the color of the light from a broad spectrum of colors. Drag the button on the wheel from right to left to adjust the color temperature.**

*** Brightness - Slide the brightness bar to adjust the brightness from 1% to 100%.**

*** Default Color - There are 7 default colors, you can click the round color icons to choose a default color.**

White Mode

*** Color Wheel - Slide the color wheel up and down to adjust the color of the light from warm white to cool white. Drag the button on the wheel from right to left to adjust the white's temperature.**

*** Brightness - Slide the "brightness" bar to adjust the brightness of wall light from 1% to 100%, you can freely brighten or dim the lights.**



DIY Your Color

APP FUNCTIONS

*** Scene Mode:**

XMcosy App has a scene selection function. Press the scene button to enter the scene selection interface. You can choose your favorite scenes from 32 default scenes.

You also can customize a new scene based on your favorite.

Default Scenes **Customize A Scene**

APP FUNCTIONS

*** Music Sync Mode: The wall lights react in real-time when your app detects the songs.**

*** Plan: You can set the time and customize favorite light mode when you fall asleep/wake up.**

Detect Music **Set A Plan**

APP FUNCTIONS

*** Schedule: Turn on/off automatically at preset times.**

*** Left Time: The lights will turn off automatically after the countdown.**

*** Power-on Behavior: Power Memory mode.**



Schedule **Power-on Behavior**

APP FUNCTIONS

*** Group Control: Each wall light is controlled separately with a module inside.**

If you want to control more wall lights together, you can create a group.



APP FUNCTIONS

Click the pencil upon of the product page, create group, select the wall lights and save.



ALEXA PAIRING INSTRUCTION

1. Download the Amazon Alexa APP

Search the keywords"Amazon Alexa" in the App Store for iOS device and in the Google Play for Android device.

2. Sign in or register a new account

3. Pair the Amazon Alexa APP to Amazon Echo Device (follow the Amazon Echo User Manual)

4. Log in your Amazon Alexa APP

Important tips: please make sure the "XMcosy" app, Amazon Alexa APP "Amazon Echo" are connected to the same Wi-Fi network.



ALEXA PAIRING INSTRUCTION

5. Enable "XMcosy" skill in Alexa APP

a. Click "Skills & Games" in the MORE MENU on the Alexa APP's home page.



ALEXA PAIRING INSTRUCTION

b. In the popup page, input "xmcosy" in the search bar, click "XMcosy" in the search result and click " ENABLE TO USE" in the popup page to enable the skills.



ALEXA PAIRING INSTRUCTION

c. Click "Agree and link", then "Your XMcosy account has been successfully linked".



ALEXA PAIRING INSTRUCTION

6. Enjoy Amazon Alexa Control

Now with Amazon Alexa, you can take control the smart wall lights by asking it to change colors, turn lights on and off by using simple commands.

For example, using these Alexa commands below:

"Alexa, Turn on/off {Specific light}"

"Alexa, Set the {Specific light} to green"

"Alexa, Set the {Specific light} to red"

"Alexa, {Specific light} lights fifty"

"Alexa, {Specific light} out"

Tips:

{Specific light} is the device name you named on XMcosy APP.

GOOGLE ASSISTANT PAIRING INSTRUCTION

1. Download the APP

Search "Google Home" in the App Store for iOS device and in the Google Play for Android device to install.

2. Sign in or register a new account

3. Pair the Google Home APP to Google Home Device (follow the on-screen steps)

4. Link XMcosy account in set up devices

a. Click the "+" icon in the upper left corner of home page, then click "set up device".



Important tips: please make sure the XMcosy app, Google Home APP and Google Home devices are connected to the same Wi-Fi network.

GOOGLE ASSISTANT PAIRING INSTRUCTION

b. Click "Works with Google"

c. Input "XMcosy" in the search bar.

d. In the new window, select your XMcosy account's region, input your XMcosy account and password, then click "Next Step" and "Authorize".



GOOGLE ASSISTANT PAIRING INSTRUCTION

5. Enjoy Google Home Control

Now you can take control the smart wall lights through Google Home by asking it to change colors, turn lights on and off by using simple commands.

For example, using these voice commands below:

"Google, Turn on/off {Specific light}"

"Google, Set the {Specific light} to green"

"Google, Set the {Specific light} to red"

"Google, {Specific light} lights fifty"

"Google, {Specific light} out"

Tips:

{Specific light} is the device name you named on XMcosy APP.

TROUBLESHOOTING

Cannot connect to the XMcosy App.

1. Check if the light is powered on.

2. Check if the Bluetooth on the smartphone is enabled.

3. When pairing, please ensure the smartphone is near the light.

4. If the connecting error still exists, please try to clean all apps that are running in the background then reopen the XMcosy App, or uninstall and reinstall the XMcosy App then repeat the setup.

Cannot connect to your Wi-Fi network/Disconnected.

1. Check if the light is powered on.

2. Please make sure your Wi-Fi router is under the 2.4 GHz setting, and the entered router password is correct. If the Wi-Fi signal is too weak, reset your Wi-Fi router and try again.

3. Please enable the XMcosy App to get your local location and Bluetooth.

Home network is 5GHz.

The wall penetration capability of 5.0GHz is weaker than 2.4GHz, which means that the outdoor signal of 5.0GHz is worse than 2.4GHz. Therefore, most smart devices support 2.4GHz networks or dual-frequency networks of 2.4GHz and 5.0GHz.

1. If you are using a dual-band router(2.4GHz and 5GHz frequency share a Wi-Fi account.), you can connect the device using the AP mode.

2. Or you can log in to the management page of your router and change the SSIDs of the 2.4 GHz and 5 GHz networks to differentiate them.

CONTACT

For questions, assistance, or support, Please Contact:

service.2@xmcosy.com

or scan to email

*** Required Information**

1. Amazon Order ID

2. Product Model NO.

XMCOSY+ Customer Service Team will reply within 24 hours.

For more info. or news about XMCOSY+, pls follow XMCOSY+ social website.

@Xmcosy+ @XMCOSY+

@xmcosylights @xmcosy

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located for operating in conjunction with any other antenna or transmitter.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and

(2)This device must accept any interference received, including interference that may cause undesired operation.

If there is any problem with our product while using

WE CAN HELP!

YOU DON'T NEED TO RETURN IT TO AMAZON

WE WILL PROVIDE YOU WITH A 100% SATISFIED SOLUTION

XMCOSY+ Customer Service

service.2@xmcosy.com

XMCOSY+

Lighting Expert,Brighten up Your Life