反

WIRELESS CHARGER

WIRELESS SPEAKER+LED LAMP

PRODUCT INSTRUCTIONS

Thank you so much for choosing our product,
please read the manual carefully before using the product.

FEATURES

- Simple and exquisite.
- Night light.
- Radio.
- Wireless speaker
- Alarm clock.
- Wireless fast charger.
- Charging distance≤5mm.



CHARACTERISTIC



① Aluminum handle.
② Lampshade
③ Wireless charging area
④ Silicone buttons
⑤ Clock display area
⑥ Speaker cavity
⑦ Mobile phone stand
⑧ Sillicone anti-slip mat
⑨ Type-C input port
⑩ Exhaust hole

OPERATION METHOD

1. Connect the USB port of the USB data cable to the power adapter, and the Type-C port to the wireless charger. The clock display area has a " **DC** " indicator.
2. Please put the wireless charging device in the charging indication area,The charging indicator " ⚡ " above the clock display area is always on, and it enters the charging state.



NIGHT L IGHT FUNCTION

- Touch the switch for the first time to start the light, and the light brightness is 30%.
- Touch the switch for the second time to start the light, and the light brightness is 70%.
- Touch the switch for the third time to start the light, and the light brightness is 100%.
- Touch the switch for the fourth time to turn off the light.
- Turn on the lights in turn.

BUTTON FUNCTION



ALARM CLOCK TO USE

In normal clock display mode:

1. Short press 【⏲ MODE】→Clock setting→Alarm setting→12/24h →year→Month/day.
2. Short press 【＋ ⏰】→Reduce the number.
3. Short press 【☼ －】→Increase the number.
4. Short press 【SWITCH】→Switch clock . hour/minut →Switch alarm.Hour/Minute→Switch 12/24h →Year- > Month/day.
5. Long press 【⏲ MODE】→Finish setting and return to time display.

When the time is not set:

1.Long pres 【＋ ⏰】→Alarm on/off.
2. Short press 【☼ －】→Adjust the brightness of the clock screen.
3.Alarm sounds, touch the aluminum handle →Snooze.
The snooze time lasts for 5 minutes, 3 times in total.

Unplug the power:

1.Unplug the power and the screen will be on for another hour, it will automatically become a power saving mode!
2. Low battery! There will be a sound.

USING BLUETOOTH SPEAKER METHOD:

When the power cord is plugged in, short press the switch 【BT】,there is a prompt, the blue function is turned on, and it is in the state of preparing for pairing. At this time, turn on the blue function of your phone, and in the blue device, search for blue The words " WT-C411" appear on the sound, click to select the device name of " WT-C411"; the pairing is automatically entered, and there will be a prompt after the pairing connection is successful. Short press the switch 【BT】again to exit the Bluetooth function.
When speaker playing:
1.Shortpress 【►】→play/stop.
2. Short press 【☼ －】→decrease the volume,.
Long press 【☼ －】→switch to the next;
When volume adjusted to the minimum, there will be a boost.
3. Short press 【＋ ⏰】→increase the volume;
Long press 【＋ ⏰】→switch to the next;
When volume adjusted to the maximum, there will be a boost.

USING RADIO METHOD:

After plugging in the power cord, short press the switch 【FM】, there will be a beep, turn on the radio function;
When using, first long press 【】to search all surrounding channels and add radio stations;
short press the switch 【FM】again to exit the radio function.

When Radio playing:
1. Short press 【►】→play/shop, .
Long press 【►】→auto search for radio stations.
2. Short press 【☼ －】→switch to the next channel;
press 【☼ －】→decrease the volume, the volume will be adjusted to the minimum, and there will be a beep.
3. Short press 【＋ ⏰】→switch to the previous channel;
press 【＋ ⏰】→ increase the volume, the volume will be adjusted to the maximum, and there will be a beep.



APPLICABLE DEVICE

This product supports fast wireless charging, which complies with the QI wireless charging standard; it realizes short-distance wireless power transmission through magnetic induction. **This device supports all wireless charging devices that meet the QI standard.** When using a 5V output adapter , Wireless charging supports 5W load. When using an adapter that meets QC2.0 and above standards,the wireless charging supports 10W load; Support overcharge protection (9V) and overcurrent protection (2A).

ATTENTION POINTS

●Do not use or store the product in direct sunlight or high temperature places for a long time.
●Do not charge in places too close to magnetic cards, magnetic recording media, and precision instruments.
●Do not disassemble or modify this product.
●Do not touch the AC adapter with wet hands.
●Keep this product away from water or other liquids.
●If you want to clean the product, please disconnect the power.
●Product working environment temperature range: -20~45°C.

WIRELESS CHARGING SPECIFICATIONS

Material:Imported ABS+PP+Hardware
Input:DC5V/2.1A 9V/2A
Charging efficiency:75%
Battery capacity:1800mAh
Power:5W/7.5W/10W/15W
Product size:225*116*87mm
Charging port:Universal Type-C

SPEAKER SPECIFICATIONS

Bluetooth version:5.0
Bluetooth distance:10m
Speaker power:4Ω1W×
Speaker specifications:50mm

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,
which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body; Use only the supplied antenna.

CE RoHS Made in China