品名：SoundAce S6
材质：铜版纸128g
尺寸：316*156mm

SKYWING

User Manual

IPX7 Portable Waterproof Speaker Soundace S6

Thank you for choosing SKYWING product. Please read this manual to enhance your user experience. We hope you will enjoy it very much!

Product Features:

1.The SKYWING Soundace S6 portable waterproof speaker is a sturdy and compact speaker that can be used indoors or outdoors, which will easily fit your bag or backpack. Depending on your phone's Bluetooth version, your phone can display the speaker's battery life.
2.Certified IPX7- 100% Waterproof . The SKYWING Soundace S6 portable waterproof speaker is great around water as it's not just water resistant. it can be fully immersed in water up to 3 feet. You can enjoy your shower, have fun with your friends by the pool or on a boat.
3.The SKYWING Soundace S6 Portable Waterproof Bluetooth Speaker brings a fast and stable connection. When fully charged it will provide you up to 10hrs of play time. The pairing process is easy and the speaker is compatible with all Bluetooth devices.
4.Automatic shutdown function: The speaker will shut down when Bluetooth is disconnected for 10 minutes, which is helpful to save power when the unit is accidentally left on.And the LED light show design colors your music time.

Technical Data:

The Pairing Name:SKYWING SoundAce S6
Charging Input: 5V / 1A
Operating Range: 10m/33ft
Output Power: 4O5W
Signal Noise Ratio: ≥85dB
Unit Weight: 201g
Battery Capacity: 2000mAh
Charging Time: 2-3hours
Charge: Micro USB
Frequency Response: 100Hz-19KHz
Distortion Degree: ≤1%
Unit Size: 110*110*48mm

What's Included:

- SKYWING SoundAce S6
- USB Charging Cable
- User Manual
- Carabiner Clip
- Lanyard
- Feedback Card
- Warranty Card

FAQ:

1.How do you charge the speaker?
Please use your phone charger or USB port on your computer/laptop.
2.What if the unit doesn't charge and the LED is off?
Please check your USB and cable connections to make sure they are working properly.
3.Why won't the unit connect/pair?
Delete the pairing record(s) on your device ,restart the device and reset the speaker.
4.Why is there a delay or corrupted audio?
In some rare cases, your phone's Bluetooth version may be out of date or some phone apps have poor compatibility with Bluetooth, resulting in playback issues. We may be able to provide an update file to resolve this.
5.How to pair 2 speakers together?
-First use of TWS function, please follow the steps below:
1) Turn on both of the speakers(please do not turn on your Bluetooth-enabled device's Bluetooth function at this time)
double press the" ⏻/☼ "button of one speaker. you will hear a chime, and one of the speaker's flashing light LED indicator is stable while another's is flashing,which means the 2 speakers pairing completes
2)Then connect to your phone .Two speakers will connect automatically as TWS.
- If you want to use TWS function again, please turn on the both speakers directly ,no need to repeat above steps.
- In TWS mode: No matter which one of the speakers can control to play or pause the music.
double press the" ⏻/☼ "will cut off the connection between them.

Warranty:

You can feel confident using our SKYWING brand speaker. We offer a 3-Year warranty for quality-related issues, and Lifetime technical support.

Notice: As Amazon separates customer orders and product reviews, we can not find your order ID and email address depend on product reviews. if you have any questions, please contact us directly via the email below, we hope that our after-sales service can make you satisfied.

support@skywingtek.com
US: skywing.us@skywingtek.com
EU: skywing.eu@skywingtek.com
JP: skywing.jp@skywingtek.com

www.skywingtek.com

*please note that unauthorized reselling of SKYWING products is prohibited.

Product Model:





Compatible Devices:

iPhone, Android Phone, Tablets, Computers, Laptops, Mac Book, Echo Dot, Kindle, MP3 Players, PSP, TV, and more.

" ⏻/☼ "Button:

1.How to Turn on/off the speaker:
Long Press and hold for 3 seconds to turn the speaker on or off.
2.Flash Light Mode:
When there is music, it automatically switches to solid color light mode.
Shore Press " ⏻/☼ " button to switch light mode:solid white color light mode- flash color light mode - turn off the light- turn on the light-solid color light mode.

" ▶II/ℓ/🎤 "Button:

1.During play music, short press once : play music /pause music
2.When there is a phone call coming in,short press once: answer the call, when the call is finished,short press once to hang up; short press twice: reject a call.
3.Double press quickly: redial the last call in Bluetooth mode.
4.Hold this button,Voice Assistant is awakened, you can let voice assistant,like "Siri" to control the the speaker's volume up or down,next song or previous song,call somebody.

LED Charging Indicator/Light Mode:

1)The LED light is solid red when charging,it will be off when the battery is full.
2)LED Flashes when the speaker is waiting for connection, and turns solid color after the Bluetooth connected successfully
3)There are general two led light effects,solid color light and flash color light, short press the led button to change the led light effect, if no need any led light, just short press the led button to turn off the led light.

How to Pair with Your Device:

Turn on the speaker and it will automatically enter Bluetooth mode. On your device, under Bluetooth, look for "SKYWING SoundAce S6." (For devices with Bluetooth versions under 2.1, press "Yes" to confirm pairing.) Enter a password or PIN code "0000" (four zeros), then press "Yes" or "OK" to finish pairing.

Phone/Tablet:

Turn on the speaker--Open the Phone/Tablet Settings--Bluetooth--On--Searching/Scanning--SKYWING SoundAce S6--Paired/Connected--Play music.

Computer/Laptop:

Turn on the speaker--Open the Laptop Settings--Devices--Bluetooth and other devices--turn on the Bluetooth--Add Bluetooth or other devices--Bluetooth--Searching device--SKYWING SoundAce S6--Paired/Connected--Play music.

Notice: If the computer does not have Bluetooth, please insert the Bluetooth adapter and download the Bluetooth driver to use it normally.

Mac Book:

Turn on the speaker--Open the Mac Book System Preferences--Bluetooth--turn Bluetooth on--searching device--SKYWING SoundAce S6--Paired/Connected--Play music.

Echo Dot:

Turn on the speaker--Open Alexa APP--settings--set up a new device--Bluetooth--Pair a new device--Searching Device--SKYWING SoundAce S6--Paired/Connected--Play music.

Kindle:

Turn on the speaker--Open Kindle Settings--Wireless--Bluetooth--Enable Bluetooth(ON)--Search for Device--SKYWING SoundAce S6--Paired/Connected--Play music.

Microphone / Call:

1.When your phone is connected via Bluetooth, press the " ℓ " button to answer a phone call.
2.To Hang up the phone: After the call is over, press the " ℓ "button to hang up.
3.To redial the last call: Double press the " ℓ " button quickly.
4.Refuse to answer a call: When the call comes in, long press" ℓ "button to reject a call.
Notice: For higher call quality, please speak near the microphone.

Tips:

1.Homtek Technology has worked across R&D and sales in the audio industry for many years. Based on consumer feedback, we designed this wireless speaker with waterproof technology. The buttons are located seamlessly at the top of the unit for convenient use.
2.With the speaker located under the unit, sound is balanced via high fidelity speakers including a compact subwoofer. Sound is engineered so that it's clear and voluminous when reflected off the surface underneath.
3.For most small speakers, usually it has only a little bass, it focuses on treble and clarity. For Dual stereo speakers, it has big bass, it combines bass and stereo sound.
4.Our consumers let us know they love our speaker because the sound is clearer and louder compared to other brands on the market. Consumers also report better overall sound quality, the longest battery life, and they love our waterproof technology!
5.As a reliable manufacturer, we listen to and directly incorporate this consumer feedback into our product development to constantly improve and meet the needs of our consumers.

DE Aus- und anschalten:

Halten Sie den " ⏻/☼ " Knopf für 3 Sekunden gedrückt.

Den Lautsprecher mit Ihrem Gerät verbinden

Smartphone/Tablet:

Schalten Sie den Lautsprecher ein – Öffnen Sie Einstellungen des Smartphones/Tablets—Bluetooth—Ein—Suchen-- SKYWING SoundAce S6—Verbunden—Musik abspielen

Computer/Laptop:

Schalten Sie den Lautsprecher ein – Öffnen Sie Einstellungen des Laptops—Geräte—Bluetooth und andere Geräte—Bluetooth einschalten—Hinzufügen von Bluetooth oder anderen Geräten—Gerät Suchen-- SKWING SoundAce S6—Verbunden—Musik abspielen

Echo Dot:

Encienda el altavoz- Abra la aplicación Alexa- configuración- configure un nuevo dispositivo- Bluetooth- Empareje un nuevo dispositivo- Dispositivo de búsqueda --SKWING SoundAce S6- Emparejado / conectado- Reproduzca música.

Laufsprecher miteinander verbinden:

1. Schalten Sie die beiden Lautsprecher an und deaktivieren Sie Bluetooth am Handy.
2. Drücken Sie den „ ⏻/☼ " Knopf der beiden Lautsprecher gleichzeitig- das Paaren beginnt- das Licht wird aufhören, zu blinken- die beiden Lautsprecher sind miteinander verbunden- schalten Sie Bluetooth am Handy ein

FAQ:

1.Wie wird der Lautsprecher aufgeladen?
Bitte verwenden Sie das Ladegerät Ihres Handys oder den USB Anschluss an ihrem Laptop/Computer.

2.Was mache ich, wenn der Lautsprecher nicht lädt und das LED Licht aus ist?
Bitte überprüfen Sie die Verbindung Ihres USB Anschluss und des Kabels.
3.Warum stellt der Lautsprecher keine Verbindung her?
a.Bitte überprüfen Sie, ob Bluetooth an Ihrem Gerät aktiviert ist.
b.Versichern Sie sich, dass Ihr Gerät sich innerhalb von 3 Fuß/einem Meter von dem Lautsprecher befindet.
4.Warum ist die Wiedergabe verzögert oder unterbrochen?
In seltenen Fällen kommt es vor, dass die Bluetooth Version Ihres Smartphones veraltet ist oder andere Apps eine schlechte Kompatibilität mit Bluetooth haben, was zu Problemen in der Wiedergabe führt. Um dies zu lösen, können wir Ihnen eine Update Datei anbieten.

FR Cómo encender / apagar:

Mantenga presionado el botón " ⏻/☼ " durante 3 segundos.

Comment faire l'appareillage avec votre périphérique

Téléphone et Tablette:

Allumer le haut parleur et ouvrez les réglages--Bluetooth-- Rechercher et tapez sur SKWING SoundAce S6—Appareillage-/Connecté Et Lancez la musique

Ordinateur et Portable:

Allumez le le haut parleur et ouvrez les réglages, Bluetooth, Rechercher et tapez sur SKWING SoundAce S6--pparaillage-/Connecté Et Lancez la musique

Echo Dot:

Allumez le haut parleur--ouvrez Alexa --settings—configurez un nouveau périphérique --Bluetooth—Appareillez un nouveau périphérique --Rechercher périphérique--SKWING SoundAce S6--Paired/Connected—Lancez la musique

Comment connecter deux enceintes ensemble :

1. Allumer ces 2 enceintes, garder le Bluetooth du téléphone éteint.
2. Appuyer sur la touche " ⏻/☼ " des 2 enceintes ensemble- L'association commence
- La lumière de l'indicateur arrêtera de clignoter- Les 2 enceintes sont associées l'une avec l'autre- Allumer le Bluetooth du téléphone.

FAQ:

1.Comment charger le haut parleur
Merci d'utiliser votre chargeur de telephone ou un port USB sur votre portable
2.Que faire si le haut parleur ne se charge pas et si la led reste sur Off ?
Merci de vérifier les connexions et le cable USB.
3.Pourquoi le haut parleur ne s'appraille pas ?
a.Merci de verifier que le Bluetooth est activé.
b.Vérifiez que le haut parleur est à moins de 3 mètre du périphérique
c.Supprimer les périphériques enregistrés sur votre telephone et ré-essayez
4.Pourquoi il y a du délai ou de l'audio corrompu?
Dans de rares cas, la version Bluetooth de votre telephone est obsolete, ce qui peut provoquer des problems de lecture. Nous pourrons peut etre apporter des mises à jour pour corriger ce problème.

IT Come attivare/disattivare :

Premere il pulsante ⏻/☼ per 3 secondi.

Come associare il dispositivo

Telefono/Tablet:

Accendere l'altoparlante--aprire impostazioni del tefono/tablet--attivare bluetooth --ricerca o scansione--SKWING SoundAce S6--associare il dispositivo--riproduci musica.

Computer/Laptop:

Accendere l' altoparlante--aprire le impostazioni del computer--dispositivi--Bluetooth e altri dispositivi--attivare il bluetooth--aggiungi bluetooth o altri dispositivi--cerca il dispositivo--SKWING SoundAce S6--associato/connesso-riproduci musica.

Echo Dot:

Accendere l'altoparlante--Aprire Alexa APP--impostazioni—imposta nuovo dispositivo --Bluetooth—Associa un nuovo dispositivo—Cerca dispositivo--SKWING SoundAce S6--Associato/Connesso—Riproduci musica

Come collegare 2 altoparlanti insieme:

1. Accendere gli altoparlanti, spegnere il Bluetooth del telefono.
2. Premere il tasto ⏻/☼ dei 2 altoparlanti insieme- Inizia l' associazione- Se la spia dell 'indicatore smetterà di lampeggiare significa che l 2 altoparlanti si sono accoppiati- Accendere il Bluetooth del telefono

Domande più comuni:

1.Come si carica l'altoparlante?
Si prega di utilizzare il caricabatteria del telefono o la porta USB del computer/laptop.

2.Cosa succede se l' altoparlante non si carica ed il Led è spento?
Si prega di controllare il cavo USB per assicurarsi che funzionino correttamente.
3.Perché l' altoparlante non viene associato/accoppiato?
a.Verifica che il Bluetooth del tuo dispositivo sia attivato.
b.Assicurarsi che il dispositivo si trovi ad una distanza inferiore ad 1 metro dall' altoparlante.
c.Elimina i precenedti dispostivi associati e ripristina l' altoparlante.
4.Perché c'è un ritardo o l'audio risulta danneggiato ?
In alcuni casi molto raramente,la versione Bluetooth del tuo telefono non è aggiornata oppure alcune app del telefono non sono compatibili causando dei problemi di riproduzione.Potremmo essere in grado di risolvere il problema nel fornire un file di aggiornamento.

ES Cómo encender / apagar:

Mantenga presionado el botón " ⏻/☼ " durante 3 segundos.

¿ Cómo unir/acoplar su dispositivo?

Smartphone / tableta:

Encienda el altavoz- Abra la configuración del teléfono / tableta- Bluetooth- Encendido- Búsqueda / Escaneo- SKWING SoundAce S6- Emparejado / Conectado- Reproduzca música.

Portátil / sobremesa:

Encienda el altavoz- Abra la configuración del portátil- Dispositivos- Bluetooth y otros dispositivos- encienda el Bluetooth- Agregue Bluetooth u otros dispositivos- Bluetooth- Dispositivo de búsqueda- SKWING SoundAce S6- Emparejado / conectado--Reproducir música.

Echo Dot:

Encienda el altavoz- Abra la aplicación Alexa- configuración- configure un nuevo dispositivo- Bluetooth- Empareje un nuevo dispositivo- Dispositivo de búsqueda --SKWING SoundAce S6- Emparejado / conectado- Reproduzca música.

Cómo conectar 2 altavoces juntos:

1. Encienda estos 2 altavoces, mantengalos alejados del telefono.
2. Presione la tecla " ⏻/☼ " de los 2 altavoces a la vez-Comience a emparejar- La luz indicadora dejará de parpadear cuando los 2 altavoces estén emparejados entre sí- Encienda el Bluetooth del teléfono

Preguntas frecuentes:

1. ¿Cómo se carga el altavoz?
Utlice el cargador de su teléfono o el puerto USB en su ordenador / portátil.
2. ¿Qué sucede si la unidad no se carga y el LED está apagado?
Compruebe sus conexiones de cable y USB para asegurarse de que funcionan correctamente.
3. ¿Por qué la unidad no se conecta / empareja?
a. Verifique para asegurarse de que el Bluetooth de su dispositivo esté habilitado.
b. Asegúrese de que su dispositivo esté a menos de un metro del altavoz.
c. Elimine los registros de emparejamiento en su dispositivo y reinicie el altavoz.

4. ¿Por qué hay un retraso o audio dañado?
En algunos casos raros, la versión de Bluetooth de su teléfono puede estar desactualizada o algunas aplicaciones del teléfono no son compatibles con Bluetooth, lo que resulta en problemas de reproducción. Es posible que podamos proporcionar un archivo de actualización para resolver esto.

JP オン/オフを切り替える方法：

「⏻/☼」ボタンを3秒間押し続けます。

Bluetoothペアリング方法：

スマートフォン/タブレット端末：

本スピーカーの電源をOnにした状態で、スマートフォン/タブレット端末上で 設定画面 → Bluetooth → 端末の検索 を開き"SKWING SoundAce S6"を接続/ペアリング完了状態にした後、音楽を再生してください。

デスクトップPC/ノートブックPC：

本スピーカーの電源をOnにした状態で、PC上で 設定画面 → デバイス → Bluetoothとその他のデバイス を開き、Bluetoothを起動してください。Bluetoothとその他のデバイスの追加メニューからBluetoothを選択し、端末の検索を開き"SKWING SoundAce S6" を接続/ペアリング完了状態にした後、音楽を再生してください。

Echo Dot：

本スピーカーの電源をOnにした状態で、Alexa Appを開きます。Alexa App上でEcho Dotデバイスを選択し、Bluetoothデバイス → 新しいデバイスをペアリング を選択します。デバイスを検索し、"SKWING SoundAce S6" を接続/ペアリング完了状態にした後、音楽を再生してください。

2つのスピーカーを接続(ペアリング)する方法：

1.スマートフォンのBluetoothをオフにした状態で、2つのスピーカーをオンにします。
2. 2つのスピーカーの⏻/☼ ｊキーを同時に押します-接続(ペアリング)が開始されます-インジケーターライトの点滅が停止すると、2つのスピーカーは接続(ペアリング)されます-スマートフォンのBluetoothをオンにします。

FAQ：

1.どうやってスピーカーに充電するのですか？
お使いのスマートフォン充電器やパソコン上のUSBポートをご使用ください。
2.スピーカーに充電できない場合、LEDランプが消えてしまう場合はどうすればいいですか？
お使いのUSB端子、USBケーブルの接続をチェックし、正常に動作していることを確認してください。
3.なぜスピーカーが接続/ペアリングできないのですか？
お使いのデバイスのペアリング履歴を削除してください。
そしてお使いのデバイスを再起動、本スピーカーをリセットしてください。
4.なぜ音楽再生時に遅延や音飛びが発生するのですか？
まれに、お使いのスマートフォンのBluetoothバージョンが古くなっているか、一部のスマートフォンアプリとBluetoothとの相性の問題で、再生に問題が発生する場合があります。
この問題を解決するためのアップデートファイルを提供する可能性があります。

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.