FW03

USER MANUAL OF SMART WATCH

Please read and observe the "safety and precautions" before using and operating the equipment

User Manual Version Number: V4.0-20211217

01 Product Introduction



TIPS: The illustrations of products, accessories and user interface in the manual are schematic diagrams for reference only. Due to the upgrade of the product, the physical product may be slightly different from the reference figure. Please take the physical product as the standard.

02 Operating instructions



Screen Operation

❶ Slide down on the main interface to open the control panel
❷ Slide up on the main interface to open the message notification
❸ Slide right on the main interface to open the side quick entrance
❹ Slide left on the main interface to open the today's data
❺ Slide left on other interfaces to return to the previous level



Key Operation

❶ Long press to turn on / off
❷ Short press on the main interface to enter the main menu
❸ Short press in other interfaces to return to the main interface
❹ Press twice in the main menu to switch styles
❺ Rotate in the main interface to switch the dial
❻ Rotate in the main menu interface to Slide / flip / zoom
❼ ❽ When the screen is off, short press to light up the screen
❾ Short press to enter Multi Sport mode
❿ Short press in the multi motion interface to start the middle motion mode
⓫ Short press in motion mode to end the movement

03 Connect APP

1. Scan the QR code on the right with your mobile phone, or download and install the "FitCloudPro" client in the mobile application market / APP Store
2. Turn on Bluetooth
3. Open "FitCloudPro" app
4. Click"Device"--"Add Peripheral Now"
5. Click"Search Now"
6. Follow the page prompt to complete the binding

TIPS:

- After the watch is successfully bound, when the client is opened,the watch will automatically connect with the mobile phone, and the data will be updated synchronously.
- A watch can only be connected to one mobile phone. If you need to connect a new mobile phone, please untie it first.

04 Connect Mobile Bluetooth

Operation steps on Android:

1. Open "Bluetooth interface" on your phone
2. Select "FW03" in the "AVAILABLE DEVICES" list
3. The "Bluetooth pairing request" page will pop up
4. Click "PAIR" to connect successfully

Operation steps on Apple:

1. Open "Bluetooth interface" on your phone
2. Select "FW03" in the "OTHER DEVICES" list
3. Connection succeeded

05 Charging、Wearing and Maintenance

Charging

1、Before charging, please wipe the charging contact to avoid sweat and moisture.
2、If the watch cannot be turned on, the charging icon will be displayed only after charging for about 30 seconds.
3、The watch can be fully charged in about two hours later. When the charging indication shows 100%, it indicates that the battery is fully charged.

Wearing

1、Please adjust the watchband tightness to ensure that the heart rate sensor can collect data normally.
2、Place the watch on the charger so that the charging contacts on the back of the watch fully fit the metal contacts on the charging stand.Connect the charging stand to the regular channel purchase of a standard USB charger with an output voltage of 5V and an output current of 0.5A and above.

Maintenance

1、Please clean the equipment regularly to avoid fouling and breeding bacteria.
2、The watch display does not support underwater operation. When it is stained with water, wipe water with soft cloth and then operate.
3、Watches are waterproof in daily life and can be worn when washing hands and swimming in shallow water, but they are not suitable for hot air, high-speed water and deep water environments such as hot water shower, diving and diving.

06 Safety and Precautions

- Please keep the equipment dry, and do not use external heating equipment such as oven or blower for drying.
- Do not use chemical products, detergents or strong detergent cleaning equipment or accessories.
- Do not store or transport watches and flammable liquids or gases in the same box.
- Use the watch in the temperature range of-10 °C -45 °C, when the ambient temperature is too high or too low, will cause watch failure.
- Put the watch where children are not exposed to avoid danger or use it under adult guardianship.
- Keep your wrist still while measuring heart rate on your watch。
- Watches are not medical equipment and any data provided should not be used as a basis for diagnosis, treatment and prevention of diseases.
- Keep the contact area dry and clean the watchband regularly. If it appear red swelling, please stop using and consult the doctor.
- Please use the charging stand attached to the watch, and select the adapters produced by regular manufacturers.
- When the watch is charged, do not touch water. Please keep the charger, charging stand and watch dry.
- The built-in battery of watch cannot be disassembled by itself, and improper replacement may cause explosion risk. If you need to replace, please contact the original factory. The battery shall not be exposed to such conditions as sunshine, fire baking or similar overheating.
- Do not disassemble, impact, squeeze or throw into fire. If the battery is severely inflated, do not continue to use.
- It is forbidden to throw watches or batteries into the fire to avoid explosion.

07 Warranty Instructions

This product if there is a non-human quality problems, please contact the sales office or point of purchase after-sales service. Within 12 months from the next day of signing and receiving, the performance failures listed in the ' Product Performance Failure Table ' of the product are determined by the after-sales center and free to enjoy maintenance services.

一、Non-warranty Regulations

1、Unauthorized maintenance, misuse, collision, negligence, abuse, infusion, accident, change, incorrect use of non-product accessories, or tearing, changing label, anti-counterfeiting mark; 2、has exceeded the validity period ; 3, damage caused by force majeure ; 4 、 Not in line with the ' product performance failure table ' listed performance failures. 5. For human reasons

二、Product Performance Failure Table

name	performance failure
Watch body	Display abnormal vibration failure failure to start Display touch failure Cannot synchronize with the specified device
Charging Stand	Cannot charge watch normally

08 Environmental protection

Please do not dispose of this device and its accessories as ordinary household waste.It is recommended to comply with local laws and regulations and support recycling actions.

Name and content of hazardous substances

Part name	Hazardous substances					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Watch cases	×	○	○	○	○	○
Battery	×	○	○	○	○	○
Watch strap	○	○	○	○	○	○
Desktop charger	×	○	○	○	○	○

○: It means that the content of this hazardous substance in all homogeneous materials of this part is under the limit requi-rements stipulated in GB/T26572.
×: It means that the content of the hazardous substance in at least one homogeneous material of the component exceeds the limit requirements stipulated in GB/T26572, and there is currently no mature alternative in the industry, which meets the environmental protection requirements of the EU RoHS directive.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.