USER MANUAL

iSearching

Get it on Google play

Available on the App Store

Apple,APP Store,iPhone,iPad and iPod touch are trademarks of Apple Inc. Google play is a trademark of Google Inc. All other trademarks are properties of their respective owners.

This guide is for your benefit to make sure you fully understand how to use the product.

This product is a Bluetooth wireless device running the 'isearching' application. Before using it, you need to place the things that are easily lost with the product together. In the effective Bluetooth connection range (About 25meters/75fft no barrier), you can make the product beeps to find your things with your phone's app, you can double-click the product's button to cause your phone ring, and you can use the product to take photos. (With these features, you can find anything you want to find with ease. Such as,keys,bags,remote control, wallet, mobile phone...)

*When the product is out of range with your phone's Bluetooth, the alert will be triggered in both of the product and your phone, and last lost location will be marked on the map in the 'isearching' app. (To use this feature, you need to open '**Phone Alarm While Lost function'** in the setting. With these features, your belongings and mobile phone will be protected in a specified range. If you forget to take your belongings, you will be reminded with your phone's alert. If your phone is left behind, you will be reminded with the tracker's alert.)*

In order to use the product, your device will need both of the following:
1. Bluetooth 4.0
2. IOS 8.0 and higher, Android 4.4 and higher.

APP DOWNLOAD AND INSTALL

1. You can download the 'isearching' APP from the APP Store.
2. You can download the 'isearching' APP from the Google Play.

POWER ON/OFF

Power On:
Hold down the tracker's function button for at least 3 seconds.
You will hear two beeps, the tracker is now powered on.
Power Off:
Hold down the tracker function button for at least 3 seconds.
You will hear a long single beep. The tracker is now powered off.

START APP

Open the app on your smart phone. Please take time to review the tutorial page.Please click the "Allow" of the notifications of the APP.



Tap here or drop-down interface to add devices



Tap 'Connect' to connect device.

Tap 'Find Device' to make the tracker beeps.

Tap 'Cancel' to stop the beeps.

When your tracker is connected and within range, you may use your tracker to find your lost phone.Press the button 2 times in succession and it will cause your phone to alert. Tap 'Confirm' to stop the alert.



Go settings

Slide it to the left, you can delete the device.



You may edit the device name- such as Wallet, Key, Dog etc. You can take a picture and save for your reference.

TO USE THE ANTI-LOST ALARM FEATURE, YOU MUST TURN ON THIS BUTTON.



SELFIE

Press 'Camera', the camera will show up. Press the connected tracker's button to take the photo, it works as a remote shutter.

Switch the front and rear camera.



Switch 'No disturbance' on, alarm function of all devices will be deactivated.

Setting for alarm or voice recording.

Voice records will be here.

LOCATION

Location History: When you park your car, press the tracker's button, it will mark your current location on the map.Press the location history you will find your vehicle.

Lost History: If you lost your tracker, you can find it in 'Lost History'. A pin-drop will be marked automaticall on map and it will tell you the tracker's location. Just press 'Lost History' to find the record.

BATTERY REPLACEMENT

Battery type: CR2032
The CR2032 is a standard sized battery and easy to purchase.
Open the case from the button of the device and replace the battery.

FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.