BM70中英文说明书

一．菜单操作

1.1 电话薄

- 添加联系人：选中此项，进入下级菜单可增加联系人，先输入联系人名称，再输入号码。
- 联系人：选中联系人，按拨号键可直接拨出电话，按左软键可以进行查看，发送短信，呼叫，编辑，删除，复制，查看存储状态
- 电话薄同步：按'# 软键进入，向下按可看到电话薄同步。如果没有跟蓝牙主机相连，则不能同步。

1.2 信息

- 建立信息：可通过此菜单进去写信息，发送信息
- 收件箱：接收别人发送到本机 SIM 卡的短信
- 草稿：可写草稿，保存，便捷发送
- 发件箱：发送失败的信息会保存至此菜单
- 已发信息：发送成功的信息会保存到此菜单

★：进入收件箱、草稿、发件箱、已发信息可通过 *# 键切换至蓝牙收件箱同步智能机短信。如果没有跟蓝牙主机相连，则不能同步。

1.3 通话记录

- 未接电话、已接电话、已接电话、所有电话：可以分别查看本机和从智能主机上蓝牙同步过来的最近电话等相关通话记录以及通

和从智能主机上蓝牙同步过来的最近电话等相关通话记录以及通话时间。
- 删除通话记录：可删除本地通话所有电话记录或者单项未接电话、已接电话、已接电话的通话记录

★：进入到通话记录菜单里可通话 *# 键切换至蓝牙电话本，蓝牙电话本可以选择查看、呼叫、发送短信、保存到电话薄。

1.4 多媒体

只支持蓝牙音乐，需要连接上蓝牙才可使用播放器，需要在智能机上选择好媒体音频可以同步歌曲播放

1.5 蓝牙拨号

- 搜索蓝牙装置：可以搜索附近的所有蓝牙设备，连接搜索到的智能机，可以将智能机上的电话本、信息等同步。
- 搜索之后，显示搜索到的蓝牙设备
- 连接中装置：显示连接中蓝牙设备，按左键可选择断开连接，删除，帮助选项。

蓝牙拨号：从本机可以控制智能机拨出任意号码或电话本中号码，从本机接听和挂断。

1.6 工具箱

- 魔音：可选择原声、男声、女声、童声 4 种音色，拨号后对方听到的声音会根据选中的音色而变化

- 闹铃：可设置 5 个闹钟。每个可独立设置打开关闭，时间，重复类型和闹铃铃声。

1.7 设置

情景模式：标准模式，静音模式、会议模式、户外模式。

- 时间与日期：设置时间与日期；设置格式。
- 待机显示设置：自动锁屏；设置键盘自动上锁时间
- 手机设置：语言，可选中文和英文；首选输入法，默认是智能拼音，也可设置为其它项为首选；飞行模式：正常模式与飞行模式
- 安全设置：手机安全设置→ 手机锁：可设置开和关；更改手机锁密码；
- 外部连接：蓝牙：可激活关闭蓝牙；本机可被搜索；设置本机可见性；本机装置名称；可修改本机装置名称；防丢失设置：可开启关闭防丢失设置

★：连接蓝牙默认密码为： 0000

- 通话设置：可设置呼叫等待呼叫转移
- 恢复出厂设置：输入密码，进行恢复出厂设置，默认密码为1234

二．蓝牙拨号功能基本操作

本产品是一款通过蓝牙与主机配对以后，通过操作本产品，可以控制主机实现通话功能的产品；本产品通过蓝牙支持主机端的音乐播放。

2.1 蓝牙连接

蓝牙拨号器和主机连接：

蓝牙拨号器开机，主机打开蓝牙且设为可被所有设备搜索，在蓝牙拨号器中按蓝牙切换键 一显示是否激活蓝牙 一是一搜索蓝牙装置一搜索到主机蓝牙一配对一连接成功。

注：

1. 在 WIFI 网络环境下，蓝牙信号会受影响，尤其主机为蓝牙和 WIFI 共用天线时，某些极端情况下，主机的蓝牙受WIFI 影响会导致蓝牙连接断开，为获得好的蓝牙使用，请关闭WIFI 或及时连接蓝牙。
2. 在长时间播放蓝牙音乐时，偶尔会出现停止播放情况，此种现象为某些情况下蓝牙进入深度睡眠模式后会将多媒体连接断开，只需在主机端重连一下蓝牙即可。
3. 蓝牙连接，请尽量从主机端蓝牙进行连接。

蓝牙拨号器和主机断开：

当从主机断开蓝牙连接以后，或者蓝牙拨号器也可以通过操作路径：蓝牙拨号—>我的装置—>连接上的主机—>选择断开连接，此时，主机和子蓝牙拨号器就断开联系，蓝牙拨号的功能关闭了。

注： 本蓝牙拨号器默认蓝牙为自动打开。

2.2 拨打电话

2.2.1 未连接蓝牙状态

在此状态下，接打电话，是由本产品上的 SIM 卡拨出和接听的。当网路供应商的标志在显示屏上出现时，您就可以拨打或接听电话了。显示屏左上角的信息条显示网路信号强度（其中有 5 条信息条时表示信号最强）。

2.2.2 连接蓝牙状态

以下操作是在蓝牙拨号器和主机连接的时候进行

接听电话：

主机和蓝牙拨号器都会收到来电提示。按下主机或者 蓝牙拨号器的接听键都可以接听来电，主机的通话声音全部转到子机，用子机通话。

拨打电话：

蓝牙拨号器无 sim 卡时，从蓝牙拨号器按号码后拨号，效果相当于直接从主机的 sim
卡拨号；拨号中， 蓝牙拨号器和主机都有呼出界面；挂通后，声音同样转到蓝牙拨号器，用蓝牙拨号器通话。挂机时，按主机的挂机键和蓝牙拨号器的挂机键都可挂机。
蓝牙拨号器有 sim 卡时，从蓝牙拨号器拨号，会提示选择本机拨号和蓝牙拨号，选择蓝牙拨号则由蓝牙拨出，选择本机拨号则有本机 SIM 卡拨出。拨号中，子机和主机都有呼出界面；挂

通后，声音同样转到子机，用子机通话。挂机时，按主机的挂机键和子机的挂机键都可挂。

2.3 通话记录

本机 SIM 卡和蓝牙拨号器通过蓝牙通话时通话后,通话记录三种：未接电话，已接电话，已拨电话。主机的蓝牙通话记录只有蓝牙连接中且电话薄同步后才会显示通话记录的已存联系人名称。
注：通话质量受障碍物的影响比较大，所以在小范围内的移动可以有效提高通话质量。

2.4 播放音乐

本产品支持蓝牙远程音乐播放。在本产品与主机进行多媒体功能连接后，在主机端播放音乐时，会通过蓝牙自动传到本产品上播放。本产品播放音乐声音从后端耳机端可听到；在本产品端蓝牙音乐界面可以实现播放，暂停，上一首和下一首选择控制主机端音乐播放状态功能。按键+控制音量加，按键-控制音量减。按键上控制上一首，按键下控制下一首。按键左功能键控制开始和暂停。

WARM TIPS

1.请注意SIM卡插入方向。

2.手机右侧有个电源开关，使用前用回形针将其滑动解锁。

Nano SIM

(SIM卡的尺寸大小同iphone6/7/8/X)

3.手机支持2G GSM网络，四频800/900/1800/1900，第一次使用请给手机充电。

Menu operation

1.1 phone book

Add a contact: select this item, enter the lower menu to add contacts, first enter the contact name,and then enter the number

Contact: select contacts, press the dial key can directly dial the phone, view, click the left key can send text messages, call, edit, delete, copy, store

- phonebook synchronization: according to *# key to enter, press and you can see the phone book synchronization. If not connected with the Bluetooth, then it won't be able to sync.

1.2 message

- message: writemessage, send message

Inbox: receive messages sent to SIM card

- drafts: can write drafts, save, send

Outbox: send failed messages to save this menu

- send a message: send messages successfully

B: inbox, drafts, outbox, sent messages through *# key to switch to the Bluetooth Smartphone inbox messages.

1.3 call records

You can view the recent phone call history, talk time once you get your Smartphone and BM70 connected by Bluetooth.

Delete call records: delete all local call log or single missed calls, dialed, received telephone call records

B: to calllog menu, you can press * # key to switch to the Bluetooth phone book, you can use view, call, send SMS, saved to the Bluetooth phone book.

1.4 multimedia

Only supports Bluetooth music, and need to connect to the Bluetooth player. You can synchronize your smart devices for the music play.

1.5 Bluetooth dial

- search for Bluetooth devices: you can search all Bluetooth devices around you, and get your smart device and your BM70 connected by Bluetooth. to the search to the smart machine, you can synchronize the phone book, information, etc.
- displays the search for the Bluetooth device
- connect device: display Bluetooth devices in the

connection, press the left button to select disconnect, disconnect, delete, and help options

Bluetooth dial-up: from the machine can be controlled by the smart phone to dial any number or phone book number, from the machine to answer and hang up

1.6 toolbox

Magic sound: options available to select, original, male, female, children

The voice the phone receiver hears depends on the timbre you select (original, male, female, children)

- Alarm: You can set 5 alarms in total. You could set on/off time, repeat type and alarm tone on each alarm.

1.7 settings

Profile: standard mode, silent mode, meeting mode, outdoor mode

Time and date: set the time and date

Standby display settings: auto lock screen: set the keyboard auto lock time

phone settings: language: English, Spanish, Portuguese,

Dutch, French, Portuguese, Russian, German.

flight mode: normal mode and flight mode

Security settings: mobile phone security settings —>phone lock:can be set to open and close; change the mobile phone password lock;

External connection: Bluetooth: Bluetooth can be activated to turn off; the machine can be searched: set the visibility of the machine; the device name: can modify the device name of the device; anti loss settings: can be turned off to prevent the loss of settings

B: connect Bluetooth default password: 0000

Call settings: call waiting call transfer can be set

Restore factory settings: enter the password to restore the factory settings, the default password is 1234

2.1 Bluetooth connection

By default, Bluetooth is automatically turned on

open the Bluetooth dialer of BM70 , search the smart devices around, activate the Bluetooth function and pair it to your smart device, get it connect successfully.

1.The signal of Bluetooth can be greatly affected by the wifi network around. Please switch off your wifi when you turn your Bluetooth on.

2. The Bluetooth music player will occasionally stop paying the music after a long time work.

3 . Please connect your Bluetooth from your main phone

2.2 phonebook

2.2.When you turn off Bluetooth of BM70, It can be used as a standalone phone, you can inserta SIM card and make or receive phone calls.

2.2. turn your Bluetooth on

When you turn your Bluetooth on, and get your Smartphone and BM70 connected successfully,the two phones(BM70 and your Smartphone) can both receive phone calls. Press the answer key on either of phones could be able to receive phone calls.

2.3 call log

If you insert a SIM card in your BM70, get your BM70 connected to your Smartphone successfully,then your BM70

can synchronize with your call contacts and call log from your Smartphone.

2.4 Music player

BM70 can support remote Bluetooth music play Get your BM70 and your Smartphonesuccessfully connected, then once you play the music from your Smartphone, it will automatically be played on your BM70 as well.

You can listen to the music on BM70 by earphone. Press " #" *"to increase/decrease the volume of music. Press the up button to play the last song, and the down button to play the next song, and the left function key to start play or pause.

WARM TIPS

1.Please pay attention to SIM card insert direction.

2.There is a switch on the right side of the phone，you can use a paperclip and please slide it to unlock before using，then it'll work.

Nano SIM

(Same SIM size as iPone6/7/8/x)

3.Support Global 2G GSM Network. Quad Band GSM 850/900/1800/1900. Please fully charge the phone before first use.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Specific Absorption Rate (SAR) information:

This mobile phone meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies.

The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. FCC RF Exposure Information and Statement the SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: mobile phone has also been tested against this SAR limit . This device was tested for typical body-worn operations with the back of the phone kept 10mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain an 10mm separation distance between the user's body and the back of the phone. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.