产品说明书

蓝 牙 耳 机 V5.4

产品图解



1. 充电盒指示灯
2. 充电盒充电口
3. 耳机多功能按键
4. 耳机指示灯
5. 耳机充电触点
6. 喇叭

产品参数

产品型号：F6
蓝牙版本：5.4（EDR）
语音支持：中文、英文
传输半径: 10m
待机时间：＞180小时
持续音乐: 11 - 12小时(左右)
操作方式：一键操控
电池类别：锂聚合物电池3.7V
电池盒容量：500mAh
耳机电池容量：100mAh
接口类型：TYPE-C
充电时长：1.5小时
充电电流：DC 5V—100mA
颜色分类: 黑色/白色

使用方法

开机/关机

打开盖子自动开机: 耳机放回充电仓，盖上盖子自动关机;
手动关开机:长按5秒多功能键，开机/关机。

左右耳机配对

1.自动配对：打开盖子后左右耳机自动配对（对耳机自检配对）
2.配对成功：配对上之后有一只耳机会灯灭（副机），另一只红蓝灯交替闪（主机），此时可跟手机配对连接。



与手机配对连接

离开充电仓，耳机自动开机并进行左右耳自动配对，对耳配对完成后，其中一只耳机会红蓝灯交替闪（耳机自动配对时不要按任何按键），此时打开手机蓝牙搜索并连接；如果对耳此前已经跟手机连接过，对耳会自动回连手机。

温馨提示：当您收到本产品后，请在首次使用前先充满电。

多功能键介绍

电话

双击任意耳机：接听/挂断电话
拒接电话：长按任意耳机2秒(挂断电话有du的提示音)
来电报号：来电语音播报来电号码

音乐

播放/暂停：双击任意左右耳机（播放音乐状态下）
下一曲：长按右耳2s (每调节一下都有du的提示音)
上一曲：长按左耳2s (每调节一下都有du的提示音)

语音助手

三击任意左右耳机激活语音助手（例：Siri、Google、小爱）

声音控制

音量 +：单击一下右耳机（每调节一下都有du的提示音/达到最大音量嘟2声）
音量 -：单击一下左耳机（每调节一下都有du的提示音/最小音量无提示音声）

其他功能介绍

语言切换: 配对状态下，快速单击5下（不要连接上手机的状态下）
自动回连：开机后自动与已配对的手机连接（部分手机需要点确认）
游戏模式/音乐模式：游戏模式/音乐模式连接状态下，快速单击4下左右任意耳机MFB键，提示音会“嘟”一声。

指示灯指南

名称/状态	有电状态	低电量	正在充电	充满电量
耳机	/	语音提示（不亮灯）	红灯长亮	蓝灯长亮（60秒后灭灯）
充电盒	20 - 100	0 - 10，显示屏闪烁	个位数字在闪烁	100

听力保护

●请勿长时间在高音量状态下使用，以防损害听力。
●请勿将声音调整过大以防听不到周围的声音。
●请勿在开车时使用耳机听歌。

包装内含

- 耳机 x 2 (左耳&右耳)
- 充电线 x 1
- 充电盒 x 1
- 说明书 x 1

安全事项

特别注意

- 请勿将蓝牙耳机摔落、撞击、刮擦、扭曲、敲打、碾压、投入水中等。
- 使用蓝牙耳机时请将其远离磁体、电器和扬声器附近;
- 尽量避免将蓝牙耳机放置于极端温度中(使用环境工作温度范围-10℃~45℃)
- 避免将蓝牙耳机暴露在潮湿的环境中;
- 请勿私自更换电池，如果电池更换不当会有短路导致耳机完全损坏。
- 产品含有电池，不得暴露在诸如日照、火烤或类似过热环境中，以免造成危险。
- 请勿在雷电天气使用耳机以防意外情况。
- 请使用干软布擦拭，避免使用刺激性化学物或强力洗涤剂清洗。
- 请勿在严重高温/潮湿/腐蚀性环境下使用本产品。

USER’S MANUAL

Bluetooth headset V5.4

IDENTIFYING KEY PARTS



1. Charge box indicator lamp
2. TYPE-C charging port
3. Multi-function Button(MFB)
4. Earphone indicator lamp
5. Earphone charging contact
6. Trumpet

Basic Parameters

Model: F6
Version: 5.4(EDR)
Voice support: Chinese、English
Connection Range: 10m
Standby time: ＞ 180 hours
Play music: 11 - 12 hours
Operation Method: One-key button
Battery type: lithium polymer 3.7V
Box capacity: 500mAh
earphone capacity: 100mAh
Interface type: TYPE-C
Charging time: 1.5 hours
Charging current: DC 5V-100mA
Color: Black / White

Usage

Power On/Power Off & Pairing

1. Open the lid and the headset will Power on automatically. Or, long press the Multi Function Buttons both sides for about 5 seconds.
2. Put the headset back into the charging box,then close the lid, and the headset will be turned off automatically.
2. Put the headset back into the charging box,then close the lid, and the headset will be turned off automatically.



To power off the device, put the headphones back to the charging case, or long press the Multi Function Buttons both sides for about 5 seconds.

Note: Please fully charge it with the charging case before the first use when you receive the product.

Touch Multi-function Button(MFB)

CALL

Answer/End Call: Double press any Multi Function Button.
Reject Call: Long press any Multi Function Button for about 2 seconds
Call in：Call in and broadcast the number.

Music

Play/Pause: Double press any Multi Function Button to play/ pause music. (Some phones may require you to start a media player first).
Next Track: Long press Multi Function Button (R) for about 2 seconds.
Previous Track: Long press Multi Function Button (L) for about 2 seconds.

Voice Assistant

Triple press any Multi Function Button to active the voice assistant.

Volume Control

Short press Multi-Function Button (R) to volume up.
Short press Multi-Function Button (L) to volume down.

Other Function

Language switch: In paired state, quickly click 5 times (Do not connect to the phone)
Automatic reconnection: automatically connect with paired phones after power on (some phones need to be confirmed)
Game mode / music mode: game mode / music mode connection state, quickly click on any headset MFB button 4 times, the prompt will beep.

Guide to indicator lights for earphone

	Enough Electricity	Low Power	Charging	Full Charge
Earphone	/	Voice Prompt	Red LED ON	Blue LED ON (About 60 seconds)
Box	20 - 100	0 - 10	Display flicker	100

Hearing Safety

●To avoid hearing damage, do not listen for long time at high volume.
●Do not turn the volume so high that you're unable to hear your surroundings
●Please do not use earphones to listen to music while driving.

Packing List

- Earphone x 2(Left & Right)
- USB Cable x 1
- Charging box x 1
- Manual x 1

Safety Rules

Attention

- Do not drop, hit, scratch, twist, knock, crush, throw into the water, etc.
- When using a Bluetooth headset, keep it away from the vicinity of magnets, appliances and speakers.
- Try to avoid placing the Bluetooth headset in the extreme temperature (using the ambient operating temperature range of-10 ℃ ~ 45 ℃)
- Avoid exposing Bluetooth headsets to damp conditions
- Do not replace the battery privately, if the battery is not properly replaced, there will be a short circuit and the headset will be completely damaged.
- The product contains batteries and should not be exposed to conditions such as sunshine, fire or similar overheating to avoid danger.
- Do not use this earphone during a thunderstorm to avoid irregular function and increased risk of the electric shock.
- Clean with a dry, soft lint-free cloth, do not use harsh chemicals or strong detergents to clean.
- The product shall not be exposed to excessive hot or wet.

FCC Caution:
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception,
which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different
from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.