F1海外说明书
80g书纸

打印装订方式：骑马钉（即为页树应设为4的倍数）
总页数：44页

英语：

66

92

usmile

User Manual

Future One Smart Sonic Electric Toothbrush

Model: Future One

Contents

English ——— 1
日本語 ——— 22

Thank you for choosing a product from the usmile brand. Please read this manual carefully and pay attention to the safety tips before using the product. Keep it in mind for future reference.

usmile は、ご購入いただきまして、ありがとうございます。ご使用前に、説明書をよくお読みになり、安全上のご注意をお守りください。大切に保管してご活用ください。

Safety Precautions:

Do not ingest or expose to acids, such as fruits, electric shocks, bodily injury, fire and explosion or property damage, please observe the following precautions:

1) Do not use the product in a flammable environment.
2) Do not place the product in a high temperature environment, such as near a heat source, or in a place of exposure to direct sunlight for a long time, to prevent deformation and damage to the product.
3) Do not use the provided cables for charging.
4) Do not use the product while it is charging, and the product should not be left attached to the charger for a long time.
5) Do not attempt to modify, disassemble or repair the product by yourself.
6) Do not place the charger cable in water or in humid environments, to prevent short circuits, fire, electric shock, or damage to the charger. Should you find any concern in regard to a power supply, please contact the manufacturer or its authorized service center.
7) When charging, always ensure that the charger plate faces the product and is fully attached.
8) Do not use an all-in-one charger (cable, which can charge the toothbrush and other devices at the same time).
9) Please use the charger provided with the product. Using other chargers may cause product damage or even a fire hazard.
10) Please keep the product out of reach of children and infants, to prevent accidents such as choking on small parts or swallowing the brush head. Please prevent children from swallowing foam, the brush head, and other small parts during brushing, to avoid choking.
11) Please keep the product out of reach of children and infants, to prevent accidents such as choking on small parts or swallowing the brush head. Please prevent children from swallowing foam, the brush head, and other small parts during brushing, to avoid choking.
12) Please do not use the product if it is damaged or has a sharp edge, to prevent injury to the user.
13) Please do not use the product if the brush head is damaged or has sharp edges, to prevent injuries to the user.
14) Please do not use the product if the brush head is worn out, to ensure optimal brushing performance.
15) Please do not use the product if the brush head is damaged, to prevent injuries to the user.
16) Please do not use the product if the brush head is worn out, to ensure optimal brushing performance.

Schematic Drawings of Components

Handle of the usmile F1 Smart ElectronicTooth-brush

(Comes 12 hours after initiating the brush head)

* For the usmile mode, you can adjust the "Polish Mode, Gum Care Mode, Cleaning Mode and Tongue Mode" in the app.

ASO1 Portable Sanitizer

Usage:

How to Install a Special usmile Brush Head

Please use the product together with a special usmile brush head. Align the protrusion on the inner side of the brush head with the notch on the brushing unit. Gently push it up to ensure proper installation and secure it in place.

When you install a brush head, bristles and the top indicator should face the same direction. To remove the brush head, gently pull it upward while the brush head. After the brush head is removed, it is normal for a small amount of residual water to drip from the brush head and the top of the handle. This ensures normal vibration.



Battery Status and Charging

The product and its usmile charger are charged units. It is shipped from the factory. So you can use them immediately. When the battery is low, please use the charger to charge the battery. Please fully charge it as soon as possible.



The product and the usmile charger are integrated units, protected against changes and flattening strong compatibility and have charging and discharging protection functions. The charging time is about 2 hours. Overcharge protection is in place to charge the product and prevents overcharge, current leakage, voltage, whether or not charge the current.

To charge the product, first open the charger port cover at the bottom of the handle. Then, place the charger port of the handle into the charging port of the usmile charger. Ensure the charger is properly connected. Place the electronic toothbrush in a stay upright in the charging stand to initiate the charging process. The charging indicator will turn on to indicate the charging status.



The lower indicator will blink when the product is charged. It will stay on when the charging is complete.

When the battery level is detected to be low, the power indicator will blink red. The product will automatically shut down to save energy. Please charge it soon.

During charging, the power indicator will turn blue when it is fully charged.

Be sure you have covered the charger port after charging before you use the product in the bathroom.

When charging, the product or its usmile charger may get warm. This is normal. It will not affect your safety.

Power On/Off Switch Between Modes

On/Off Button/Mode Button Operating Instructions for the Electronic Toothbrush:

1. Power on: Under the power off mode, short press the On/Off button to turn on the device.
2. Switch between different mode: Under the power on mode, short press the mode button to switch between modes.
3. Power off: Under the power on mode, short press the On/Off button to suspend the product. You can continue to brush your teeth after the product has been suspended for 3 minutes.
4. Power off: Under the power on mode, short press the On/Off button for 3 seconds to turn off the product. The product will turn off after being suspended for 10 minutes.

Explanation of Brushing Modes:

1. Clean mode: Tooth and brushes in normal force at a fixed frequency. The frequency will change once to remind you of shifting your brushing area. The frequency will change twice to remind you of frequency and change time once to a minute.
2. Gum care mode: Tooth and brushes in gentle force at a fixed variable frequency to fixed frequency for time second and take a minute to remind you of shifting your brushing area. The frequency will change once to remind you of shifting to another section of your mouth. Before the timed brushes, the frequency will change twice to remind you of frequency.
3. Soft mode: Tooth and brushes in moderately gentle force at a fixed variable frequency to fixed frequency for time second and shifting to another section of your mouth. Before the timed brushes, the frequency will change twice to remind you of frequency.
4. Massage mode: Gum and massaged in specific alternating frequency and time second and shifting to another section of your mouth. Before the timed massage, the frequency will change twice to remind you of frequency.
5. Polish mode: Tooth and brushes are polished in a strong force at a fixed variable frequency to fixed frequency for time second and shifting to another section of your mouth. Before the timed brushes, the frequency will change twice to remind you of frequency.
6. Sport Gum mode: Tooth are brushed in a gentle force at a fixed frequency. The frequency will change once to remind you of shifting your brushing area. The frequency will change twice to remind you of frequency and change time once to a minute.
7. Customized force mode: Tooth are brushed in a strong force at fixed variable frequencies or fixed frequency for time seconds and then shifting to another section of your mouth. Before the timed brushes, the frequency will change twice to remind you of frequency and change once to remind you of shifting to another section of your mouth. Before the timed brushes, the frequency will change twice to remind you of frequency.

usb charge three times as a minimum

Charge the product with the charging cradle specific force of a fixed frequency. The product will automatically cut off after the overall time second. Lasting time is adjusted in the app. Before the timed charge, the frequency will change twice to remind you of frequency.

Explanation of Customized Forces:

1. Relatively adjust the customized forces of all modes in the brush handle and app. Customized force.

Operating Instructions of the Portable Sanitizer:

1. Power on: Open the carry bag, pull the brush head cute the handle, and the sanitizer will automatically turn on. Automatically cut off 3 minutes after.

Adjust the Brushing Mode and Start to Brush Your Teeth

1. Adjust the brushing mode customized, or 4. Pick the brush head into your mouth and press the On/Off button on the handle to start brushing.

5. Begin to brush teeth surface (see the figure below)

Correct Tooth Brushing Method

Do not press the brush head too hard when using the product. Maintain the contact between bristles and teeth surfaces and move the brush head slowly and gently to clean your teeth.

It is suggested that when brushing the outer and inner surfaces, you place the bristles at a 45° angle to the gum line, roll the bristles to the Tapes Bottom, to better clean your teeth.

Cleaning and Storage

After brushing, press the On/Off button on the handle to stop the electronic toothbrush. Move the brush head and the handle. There is a small amount of residual water in the brush head. It is normal.

Keep the product upright when it is not in use.

The portable sanitizer is not waterproof. Place it in a well-ventilated place. Do not rinse or soak it. Wipe it with a clean cotton cloth.

Travel with the Product

To travel with the product, remove the brush head and place it in the dust proof case.

Place the sanitizer product and the brush head in the special carry bag.

Please use the handle to avoid other objects from pressing the button on it.

Installation Instructions of the usmile Oral Care

Install the usmile Oral Care

Turn the QR code on usmile's official Oral Care Mini app store, download and install it.

If you have already downloaded the app, be sure it is the latest version.

Add a Device

Be sure your mobile phone network connection is normal. Turn Bluetooth on. Be sure your Bluetooth location permission is enabled.

Firmly pay more attention to safety alerts.

1.Press Be sure your toothbrush has battery life. Then the Bluetooth pairing mode will be turned on.

2.Open the usmile Oral Care app. Click "Add Device" in the "Device Management" interface. Select the "Oral Care Mini".

3.If there is no pop-up, but after going to the home screen of the app, the device is still not found, please check the following:

1)Ensure that your Bluetooth indicator turns blue, it indicates the toothbrush has been connected to the app.

2)Ensure that you have the right to obtain the mode and force of the toothbrush in the app.

App FAQ

1.Why does the Android app request location permission? No precise location information is collected, only Bluetooth scanning is used.

2.Possible reasons for the failure to find the device: Bluetooth is not enabled, location permission is not granted, or the device is not in pairing mode.

3.The app will prompt Bluetooth and location permissions; please grant them in your phone's settings.

4.If the toothbrush still no longer appears in the search, try to re-bind, delete the toothbrush first.

5.Ensure the toothbrush is charged; a low battery or the gap between the charging cradle and the handle is removed may prevent connection.

6.The Bluetooth is your phone is enabled.

Environmental Protection

The product contains built-in rechargeable battery. Do not dispose of it with other waste. Please take it to a recycling center or to the retailer. Do not dispose of the product in the trash or throw it into a fire. Improper disposal may cause a battery to explode or leak and release the battery, please adopt the product to a recycling center or contact your local waste disposal authorities for information on proper disposal. Thank you for your efforts in environmental protection.

Remove the rechargeable battery

Before you dispose of the product, you need to discard it. Before discarding, you should ensure that the product has been properly disassembled. Ensure that the battery is fully discharged and the battery is removed.

Use a screwdriver to remove the battery. Be careful not to damage the circuit board or other components during the disassembly process. Ensure that the battery is properly disposed of in accordance with local laws and regulations to avoid environmental pollution.

Faults and Processing Methods

Fault	Possible Reasons	Solutions
Fail to turn on the power button on the OLD toothbrush	The product is in the Deep Sleep Mode (entering sleep mode)	Stop charging 5 minutes
	The battery is too low.	Connect to the power charger to charge the product
	The battery level of the	Charge the product
	The product is not charged for a long time.	Charge and use the product for 2 minutes
Fail to turn on the power button on the NEW toothbrush	The battery level of the	Charge the product
	The battery level of the	Charge the product

Product name: Portable Oral Care Smart Sonic Electric Toothbrush

Model: Future One
Model: Future One
Rated input power: 5W
Rated input voltage: 5V
Battery capacity: 2,000mAh
Battery type: Built-in rechargeable lithium-ion battery
Portable sanitizer product model: ASO
Portable sanitizer product rated power: 5W
Electrical rating of portable sanitizer: 5V
Bluetooth version: Bluetooth 5.0

Manufacturer: Tongxiang Smart Pioneer Co., Ltd.
Factory: Nine FOOD, JINFU, JING, SHIFANG 225, 226 Tunhe North Road, Wutong Street, Tongxiang City
Made in China

日本語：

安全注意事項:

usmile 製品を酸、フルーツ、感電、火災、爆発、怪我、または財産の損害から保護するために、次の安全上の注意事項を遵守してください。

1) 本製品は可燃性環境内で使用しないでください。電気的短絡、発火、または製品の変形や損傷を防ぐために、熱源の近くや、長時間直射日光にさらされる場所に製品を置かないでください。
2) 提供されたケーブルを使用して充電しないでください。
3) 充電中は製品を使用しないでください。製品は長時間充電器に接続されたままにしないでください。
4) 製品を自分で改造、分解、または修理しないでください。
5) 充電器ケーブルを水や湿気の多い環境に置かないでください。ショート、火災、感電、または充電器の損傷を防ぐためです。電源に関する懸念がある場合は、メーカーまたは認定サービスセンターにお問い合わせください。
6) 充電中は、常に充電器プレートが製品に向いていることを確認し、完全に取り付けられていることを確認してください。
7) オールインワン充電器（ケーブル、同時にトゥースブラシおよび他の機器を充電できる）を使用しないでください。
8) 製品に付属の充電器を使用してください。他の充電器を使用すると、製品の損傷や火災の原因となる可能性があります。
9) 製品は子供や乳幼児の手の届かない場所に保管してください。小さな部品を飲み込んだり、ブラシヘッドを飲み込んだりするなどの事故を防ぐためです。ブラシ中に子供が泡、ブラシヘッド、その他の小さな部品を飲み込まないようにしてください。窒息を防ぐためです。
10) 子供や乳幼児の手の届かない場所に製品を保管してください。事故を防ぐためです。
11) 子供や乳幼児の手の届かない場所に製品を保管してください。事故を防ぐためです。
12) 製品が破損したり、鋭利な刃がある場合は、ユーザーの怪我を防ぐために使用しないでください。
13) ブラシヘッドが破損したり、鋭利な刃がある場合は、ユーザーの怪我を防ぐために使用しないでください。
14) ブラシヘッドが摩耗している場合は、最適な歯磨きパフォーマンスを確保するために使用しないでください。
15) ブラシヘッドが破損している場合は、ユーザーの怪我を防ぐために使用しないでください。
16) ブラシヘッドが摩耗している場合は、最適な歯磨きパフォーマンスを確保するために使用しないでください。

Schematic Drawings of Components

usmile F1 Smart ElectronicTooth-brush

(Comes 12 hours after initiating the brush head)

ASO1磁器ポータブルケース

正確な使用方法

usmile専用ブラシの取り付けについて説明する

専用ブラシを使用してください。ブラシヘッドの内側の突起をブラシユニットの切り欠きに合わせます。ブラシヘッドを優しく上に押し、ユニットにしっかりと固定されていることを確認します。ブラシヘッドを取り外すには、ブラシヘッドを上に引き上げます。ブラシヘッドを取り外した後、ブラシヘッドとハンドルの上部に少量の残留水が滴下することは正常です。これにより、正常な振動が確保されます。

電池状態及び充電

製品とusmile充電器は、充電ユニットです。工場出荷時に充電されています。そのため、すぐにご使用いただけます。バッテリーが低くなったら、充電器を使用して充電してください。製品を可能な限り早く充電してください。

製品とusmile充電器は、充電ユニットです。保護されています。強力な互換性があります。充電および放電保護機能があります。充電時間は2時間です。過充電保護は、製品を充電するように設計されており、過充電、電流漏れ、電圧、充電電流の有無を防ぎます。

充電するには、まず、ハンドルの底にある充電ポートカバーを開けます。次に、ハンドルの充電ポートをusmile充電器の充電ポートに挿入します。充電器が正常に接続されていることを確認してください。電子歯ブラシを充電ステーションに立てて、充電プロセスを開始します。充電インジケーターが点灯して、充電状態を示します。

インジケーターが点滅すると、製品が充電されていることを示します。インジケーターが点灯すると、充電が完了したことを示します。

充電中、電源インジケーターが青色に点灯すると、完全に充電されたことを示します。

バッテリーが低いと検出された場合、電源インジケーターが赤く点滅します。製品は自動的にシャットダウンして、エネルギーを節約します。充電してください。

製品を使用する前に、充電ポートカバーをしっかりと閉じてください。

充電中、または充電器自体が温かくなることがあります。これは正常です。安全性に影響を与えません。

Power On/Off Switch Between Modes

オン/オフボタンとモードボタンの操作説明：

1. 電源オン：電源オフの状態で、オン/オフボタンを押して電源をオンにします。
2. モードの切り替え：電源オンの状態で、モードボタンを押してモードを切り替えます。
3. 電源オフ：電源オンの状態で、オン/オフボタンを押して製品を一時停止します。3分間一時停止した後、歯磨きを続けることができます。
4. 電源オフ：電源オンの状態で、オン/オフボタンを3秒間押します。10分間一時停止した後、製品は自動的にオフになります。

フレームボタン
モードボタン
クリーンモード
ホワイトモード
ソフトモード
ジャンボモード
ブラシモード
ジャンボモード
ブラシモード
クリーンモード
ホワイトモード
ソフト