PLAYBULB

miffy × MIPOW

Sphere Instruction



playbulb.com | mipow.com

产品参数:

型号：BTL308
输入：5V⎓1A
RGB色彩：1600万色彩
蓄电：6小时
电池容量：4000mAh/3.7V/14.8Wh
执行标准：GB7000.1-2015 GB7000.204-2008

品名：智能球型氛围灯
无线距离：10米
工作温度：0-45度
使用时间：8小时

按键接口说明:



①蓄电接口：连接电源为灯蓄电。
②电源键：按下开关灯

App下载:

下载并安装 PLAYBULB X 应用到移动设备上。

Download on the App Store　Get it on Google play

适用苹果设备:
iPhone 8以上手机

支持大多数安卓4.3和蓝牙4.0及以上版本的安卓设备

产品连接:

- 打开移动设备上的蓝牙.
- 打开安装好的PLAYBULB X 应用，从设备列表中选择PLAYBULB sphere图标连接进入。



群组:

- 在组栏目下，可选取多个Playbulb设置为一组，同时控制多个Playbulb.
- 可添加多个组.



App菜单:

- 设备
 显示可连接的Playbulb列表.
- 定时器
 可设置Playbulb启动时开/关或显示不同的色彩(Playbulb Color还可以设置闹钟)
- 偏好
 1. 可设置移动设备与Playbulb自动连接
 2. 可设置移动设备震动作感器的灵敏度.
 3. 可设置APP密码
- 关于
 MIPOW公司相关信息.



定时:

例如，如何设置“唤醒”定时器。
1.连接到PLAYBULB
2.进入定时器界面
3.开启“唤醒”模式
4.设定时间
5.设定灯光亮起的周期时间。比如，选择0分钟，灯光在预定的时间立刻全亮；选择1分钟，灯光在预定的时间逐渐亮起，1分钟后全亮
6.开启颜色（不开启的话灯亮时为白光，可选择亮度）
7.设定灯的颜色
8.保存设置，灯光会在预设时间开启。



光控:



摇动：晃动手机 灯 会随之变换颜色
颜色：可从颜色盘选取各种颜色,关闭后只有白光.
颜色盘/颜色块：可点选颜色控制相应的色彩
亮度：调节 灯光的亮度.

效果:

控制不同的灯光效果.
- 蜡烛效果
- 闪烁
- 渐变
- 彩虹
- 彩虹渐变



场景:

- 可在默认的三个照片上点选颜色，灯光会对应的色彩.
- 可从手机中添加照片.



设置:

- 更改Playbulb的名称
- 恢复出厂设置



产品中有害物质含量

有害物质

部件名称	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr (VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
主机	×	○	○	○	○	○
配件	○	○	○	○	○	○

本表格依据SJ/T 11364的规定编制。
○：表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下。
×：表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。
备中标记“×”的部件，根据欧盟RoHS法规豁免清单或相关的中国法规是可以使用的。
印刷线路板组装件：包括印刷线路板及其零部件，电子元器件等
电缆及电缆组件：包括各种电线电缆及其零部件，电子元器件等
根据产品型号不同，包括所有以上或部分部件
在中华人民共和国销售的电子电气产品必须标明此环保使用期限。此环保使用期限只适用于产品在用户手册或产品技术规范书要求的条件下工作使用。

保修卡须知

多谢选购MIPOW产品。本产品出厂时符合相关规定 标准并经过严格测练。
我司为客户提供自购买之日起十二个月内的保修服务。需要保修服务时，请出示正本和发票正本，并详细填写保修相关内容。保修服务只限于产品在正常使状态下出现的质量问题。不适用于因人为损坏、粗暴操作、不正确的使用、人为摔伤、外力挤压、进水、人为拆装修改、过度高温、外壳人为腐蚀或不可抗力的损坏如地震、水灾、火灾、飓风或战争等),保修逾期的,保修服务将会收取相应的维修费。

注:MIPOW拥有对上述所有条件之最终裁决权,并随时对条款和条件作出更改,而无需另行通知。

保修卡

品名：
型号：
购买日期：
销售点：
客户姓名：
移动电话：
联系地址：
故障描述：

请仔细填写您的信息。请将此保修卡剪下，连同需维修产品一起寄回我司维修中心 。

RoHS

售后服务中心
售后客服电话:400-0064769
www.mipow.com|www.playbulb.com

扫码关注

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
--- Reorient or relocate the receiving antenna.
--- Increase the separation between the equipment and receiver.
--- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
--- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

caution: this device is intended used in a uncontrolled environment, please keep at least 0cm away from the device while it works

Product Parameters:

Model: BTL308
Input: 5V⎓1A
Speaker Power: 8W
Charging: 6 hours
Battery Capacity: 4000mAh/3.7V/14.8Wh
Operating Temperature: 0-45 degrees

Product Name: Sphere
Wireless Distance: 10 meters
RGB Color: 16.0 million colors
Use Time: 8 hours

Keys and Port:



①Recharging Port: recharge light with power supply
②ON/OFF Button: press to turn on/off light

PLAYBULB X App Download

Download and install the PLAYBULB X App onto mobile device


Download on the App Store　Get it on Google play

Apple devices:
iPhone 8 and above

Android version:
Support most Android device of Android 4.3 and Bluetooth 4.0 or above version

Connection:

- Turn on your mobile device's Bluetooth.
- Open the PLAYBULB X App, choose and connect the PLAYBULB Sphere from the device list, after connected, tap the PLAYBULB sphere icon /name into App main interface.



Group:

- choose several PLAYBULBs as one group to control them at the same time.
- available to create several groups



App Menu:

- Devices
 show all connectable PLAYBULBS
- Timer
 set up PLAYBULB on / off or colors display at certain time (PLAYBULB color supports alarm clock function.)
- Preferences
 1.set up automatic reconnection.
 2.Set up the sensitivity of the mobile device vibration sensor.
 3. Set up App password.
- About
 MIPOW introduction.



Timer:

how to set "Wake Up" timer:
1.Connect your PLAYBULB.
2. Go to "Timer".
3.Slide the OFF/ON button to ON.
4.Set the time.
5. Set cycle time for lights on.
For example,
Select 0 minute, the light will be fully lit at the predetermined time
Select 1 minute, the light will be gradually lit at the predetermined time, and full lit after 1 minute
6. Turn on the color (default color is white when the color is turn off, brightness is optional)
7. Set the color of the light
8. Save the Settings, the light will turn on at the preset time.



Light Control:



Shake: shake your phone to change color randomly.
Color: select color on the color wheel. If turn off, PLAYBULB will only show white light.
Color wheel/block: tap to select color to make it show on PLAYBULB.
Brightness: adjust the light brightness of PLAYBULB

Effect:

make PLAYBULB display different light effects.
- candle
- flashing
- pulsing
- rainbow
- rainbow fading



Scene:

- tap to select colors on the three default pictures and PLAYBULB Will display the Corresponding colors.
- available to add scene pictures from your mobile device.



Setting

- rename PLAYBULB
- factory reset



WARRANTY CARD:

Thank you for your purchase MIPOW's product. MIPOW warrants this producthas been tested and proved to be qualified for delivery in conformity with standard. This Limited Warranty for the product shall last for twelve (12)months from the date of original purchase. This original warranty card and original invoice must be presented at the time you require warranty service or such warranty will be voided. This limited warranty is valid only if the product is used for the purpose for which it was designed. It does not apply to damageor loss caused by negligence; physical abuse; misuse; accident; exposure to moisture; dampness or extreme temperatures; unauthorized modifications; unauthorized opening or repair; forces of nature; or other actions beyond the reasonable control of MIPOW. In case of when the warranty does not apply, repair or replacement charge will be incurred. The customer shall be responsible for sending the defective product to and collecting the repaired or replaced product from the service center.

MPOW reserves the right to amendment and the final interpretation of the above terms without prior notice.

WARRANTY CARD

Product Name: _____
Model No.: _____
Purchase Date: _____
Dealer Shop: _____
Customer Name: _____
Order No./ Website Name: _____
Mobile Phone No.: _____
Contact Addr.: _____
Postal Code: _____
Failure Description: _____

For more efficiency on handling your case,pleaseprovide correct info and mail with the failure productto MIPOW authorized repair center.

RoHS

MIPOW Customer Support Center:
www.mipow.com |support@mipow.com
www.playbulb.com