Mobile Wireless Gamepad
User Manual

Model NO: PG-9083S

Compatible with iOS & Android System

Perfect works for COD & Genshin Impact Games

Notices:

1. Mobile system required: iOS14+ or Android 6.0+.

2. For Andorid devices, this gamepad does not support **MTK** chips Android phones.

3.When using this product, please placed the device horizontally.

4. Support most controller designed games & download from App Store/Google Play.

5. The input power of the charge cable is 5V/1A, please use 5V/1A charging plug, if plug is more than 1A will damage gamepad.

Keys Instruction:

Tips Before Playing Game

① Some games do not support the controller mode, please check if the game supports controller operation on 'Ludu Mapp' App. If the game cannot be found in the the APPs, it means that controller operation is not supported.

You can scan the QR code to download App.

Ludu Mapp | On Apple Store | On Google Play

② Some controller supported games need to select 'controller mode' in the game settings before you using the controller to play. **For example: Genshin Impact, COD.**

③ If you want to test if the controller can work normally or not, you can download 'Combat Modern 5' or 'Asphalt 9 Legends' to test, they fully support direct play.

iOS Wireless Connection Guideline

Bluetooth Connection

①Required system: iOS14.0+ version.

②Turn Swich mode to (iOS mode), then press 'HOME' key for 3 sec until LED 2 light flashes.

③Tum on Bluetooth function on your iPhone or iPad.

④Searh and select 'DUALSHOCK 4 Wireless Controller', once the connection has done, LED 2 light will be keeps on.

⑤Bluetooth connection is done, just choose the supported game that you want to play and enjoy it.

⑥ **Notice:**

●When the controller enters the bluetooth pairing mode with the LED 2 light flashes slowly, but cannot connect to your iPhone successfully, please delete the device - 'DUALSHOCK 4 Wireless Contoller' on the iphone, and then reconnect it.

Android Wireless Connection Guideline

Notice: for Android system, you need to download a App (ShootingPlus V3) for Key Mapping.

ShootingPlus V3 | Scan for dowmloading APP

Note: You need to allow the app to open suspention window (Floating Window) permission on your phone.

Bluetooth Connection

①Required system: Android 6.0+ version.

②Turn Swich mode to (Android mode), then press 'HOME' key for 3 sec until LED 1 light flashes.

③Tum on Bluetooth function on your Android phone or tablet.

④Searh and select 'PG-9083S', once the connection has done, LED 1 light will be keeps on.



⑤Bluetooth connection is done, let's go to key mapping setting.

⑥**Notice:**

●When the controller enters the bluetooth pairing mode with the LED 1 light flashes slowly, but cannot connect to your phone successfully, please delete the device 'PG-9083S' on the phone, and then reconnect it.

Android Key Mapping Guidelines

Operation Steps: IMPORTANT

Step 1: Open 'ShootingPlus V3' APP, make sure 'PG-9083S Connected' (if you done Bluetooth connection, the app will connect automatically, if app do not connect, please disconnect bluetooth and reconnect it)



Step 2: Do not close V3 APP, enter into the game (such as Genshin).

Step 3: In the gaming interface, press 'START' key on the gamepad, it will appear the menu on game as below:

Step 4 : Press 'New' then can assign key layout to your preference.

How to assign key button?

1.Press any button on gamepad, then reflection key will be shown on the screen, drag it to match function buttons on game. (drag the reflection key to ' ' can delete the reflection key).

2. Set the gamepad button one by one in the above way.

3. If all button set done, press 'Save' to store your settings.

4. Now enjoy your funny gaming time.

PC - Wired Connection Guidelines

PC Wired Connection

① Windows System Required: Win 7- Win 11 version.

②Turn Swich mode to (PC mode).

③ Connect controller and PC by the Micro USB cable (included in package), then controller will boot automatically and LED1 light will be keeps on.

④ If the controller is successfully connected, 'Xbox 360 Controller for Windows' will be displayed on device list of the computer.



⑤ Connection is done, just choose the supported game that you want to play and enjoy it.

⑥Supported game:
Most controller supported game download from Steam.

Q&A (1)

1. Q: I can't reconnect my phone with gamepad again even the Bluetooth shows has connected.
A: Remove or delete the Bluetooth connection on your phone and reconnect it again.

2. Q: Do i need to keep mapping keys before i attempt to play with the same game?
A: One setting takes per time, after settings has done, you don't need to set it again.

3. Q: How to reset default setting for the gamepad?
A: There is a 'Reset' hole on back of the gamepad, you can long press it until all LED lights flash to reboot it back to default setting.

4.Q: Why LED 4 on gamepad flicker when i am playing game?
A: It indicates that the power of gamepad is running out. Please charge it in time.

5.Q: How do I know if the gamepad is fully charged?
A: When the gamepad is charged, LED 4 flicker, and Led 4 will be keeps on if fully charged.

6.Q: Does the Left/Right rocker can be click be L3/R3?
A: Yes, they can.

7.Q: Does the gamepad can support game in vertical/portrait mode?
A: No, the gamepad does not support game in vertical/portrait mode.

Q&A (2)

9. Q: Why the gamepad can't control 2 keys at the same time, like shooting and running?
A: This could be the result of the key too close when you layout it.
Please try the following 3 solutions:
Solution 1: Reallocate the key as follow picture:

Solution 2: Update fireware on V3 app

Solution 3: Reset the gamepad, the reset hole is on the back of gamepad, beside L2.



Thank you
for your purchase!

Thanks for choosing our gamepad, we commit ourselves to provide the first class product and service for all customers, if you are facing any issue, please do not hesitate to contact us, thank you!

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

•Reorient or relocate the receiving antenna.
•Increase the separation between the equipment and receiver.
•Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
•Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.