Product description



XL 03

Function description



1. Long press to turn on / off / click to switch light mode / double click to turn off or turn on atmosphere light
2. Short press previous song / long press to increase volume
3. Short press a song / long press to decrease the volume
4. Pause / play / double click TWS tandem function
5. Short press microphone voice change mode switch / double click play mode switch
6. DC5V interface, the red light is on when charging
7. TF card is connected. When the TF card is inserted, it will play by default
8. Disk data read in. Can be used as mobile power output
9. Audio input interface
10. Microphone input interface

Turn on / off / switch atmosphere lamp mode

- ▲ Long press the power button for 2 seconds to turn on / off. After power on, the indicator light near the charging port flashes quickly.
  - ❶ After power on, the speaker directly enters the Bluetooth pairing state.
- ▲ Short press the power button to switch the atmosphere lamp mode, double-click to turn off the atmosphere lamp. The top atmosphere lamp is beating with the music.
  - ❶ Six lights flash.

Link to mobile phone

- ▲ Bluetooth pairing: turn on the speaker, and the blue indicator light near the charging port flashes quickly to indicate waiting for the Bluetooth link. Open Bluetooth of mobile phone and search xl-03 in Bluetooth setting interface. Click xl-03 link pairing, the link is successful, and the blue indicator light flashes slowly.

TWS series play

- ▲ Start two speakers at the same time, double-click " ▶II " key of one speaker, one indicator will flash, and the other indicator will be on for a long time, which indicates that the series connection is successful. Re link Bluetooth xl-03 to play synchronously.

❶ You need to disconnect the Bluetooth link before connecting. Make sure the speaker is disconnected.

matters needing attention

- ▲ Long press the power on button for 10 seconds to restore the factory settings.
  - ❶ It can be used when the speaker has no response.
- ▲ Use or store the product in normal environment, do not use it in fire or overheated environment.
- ▲ Do not immerse the product in any liquid for a long time.
- ▲ Please use the charger with CCC certification and meet the standard requirements to charge the product.
- ▲ Do not disassemble, refit, drop, impact or squeeze the equipment without permission. In order to avoid the battery internal short circuit overheating, leakage, fire or explosion.

Product parameters

- ▲ Product model: xl-03
- ▲ Power output: 2 * 10W
- ▲ Frequency effect: 100Hz ~ 18khz
- ▲ Power input: 5V ⎓ 2A
- ▲ Product size: 85 * 85 * 210mm
- ▲ Product weight: 700g
- ▲ Playing time: 4-20h
- ▲ charging time: 4H
- ▲ Battery capacity: 18650 3.7v/5200mah

Product list

Charging line | Audio cable | Lifting rope | instructions | loudspeaker box

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

This device may not cause harmful interference, and

This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.