180g铜版纸双面彩色印刷，风琴折页

3.6”　3.6”　3.6”　3.6”

FCC

These devices comply with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) these devices may not cause harmful interference, and (2) these devices must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

•Reorient or relocate the receiving antenna.
•Increase the separation between the equipment and receiver.
•Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
•Consult the dealer or an experienced radio/TV technician for help.
Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

Warranty 180 days from purchase date
For support please email **icelabs.co@gmail.com**

©2026 Best Brands Consumer Products LLC
2147 Lincoln Highway
Suite 402
Edison, NJ 08817-3365
RN# 22195 • Made in China

FCCID:2A6QJOS2461

*Photos are for illustration purposes only
Ice Labs LLC
All trademarks and copyrights are property of their respective owners.

FUNCTIONAL BUTTONS



① On/Off slide button
② Charging port
③ Indicator light
④ TF slot
⑤ USB
⑥ Next Music/Increase Volume Button
⑦ Mode button, RGB light mode.
⑧ Play/Pause
⑨ Previous Music/Decrease Volume Button

SOUND CORE



USER MANUAL

Notice: Please read user manual carefully and keep it for your records

3.6”

BEFORE FIRST USE

- Fully charge the speaker before using it for the first time.
- Use only a certified 5 V USB power source.
- Avoid playing music while the battery is charging for optimal battery performance.
- Recharge the speaker after hearing the "Low Battery" voice prompt.
- If the speaker announces "Please Charge," recharge it immediately.
- Keep the speaker within approximately 10 m (33 ft) of your Bluetooth device for the best connection.

SPECIFICATIONS

- Material: ABS
- Bluetooth Version: 5.3
- Rechargeable Battery: 2400 mAh Lithium Battery
- Speaker Power: 1 × 10 W
- Functions: Bluetooth / FM / TF Card / RGB Light / TWS / USB Playback
- Charging Port: USB Type-C
- Product Size: 230 × 91 × 136 mm

PACKAGE INCLUDES

- 1 × Wireless Speaker
- 1 × USB Type-C Charging Cable
- 1 × User Manual

BLUETOOTH PAIRING

1. Slide the Power switch to turn on the speaker.
2. The speaker will automatically enter Bluetooth mode and announce: **"Bluetooth Mode."**
3. Enable Bluetooth on your phone, tablet, or computer.
4. Search for available Bluetooth devices.
5. Select **BU55263** from the device list.
6. Once connected successfully, the speaker will announce: **"Paired."**

If the Bluetooth connection is interrupted, the speaker will announce: **"Disconnected."**

POWER SWITCH

Slide the Power switch to turn the speaker on or off. When powered on, the speaker plays the startup sound before entering Bluetooth mode.

MODE BUTTON

Press briefly to cycle through the available RGB lighting effects. Press and hold to switch between:

- Bluetooth
- TF Card Playback
- USB Playback

A voice prompt will announce the selected playback mode.
Double-press to turn the RGB lighting on or off.

PLAY / PAUSE / TWS

Music Playback

- Press once to play or pause music.

TWS Pairing

- Press and hold to connect or disconnect True Wireless Stereo (TWS) mode.

VOLUME UP / NEXT TRACK

- Press briefly to skip to the next track.
- Press and hold to increase the volume.

When the maximum volume is reached, the speaker will play a voice prompt.

VOLUME DOWN / PREVIOUS TRACK

- Press briefly to return to the previous track.
- Press and hold to decrease the volume.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

TWS STEREO PAIRING

Note: TWS mode requires two identical Sound Core speakers.

1. Turn on both speakers.
2. Make sure neither speaker is connected to a Bluetooth device.
3. Press and hold the Play/Pause button on one speaker
4. Wait for both speakers to pair automatically.
5. Only one BU55263 device will remain visible in your Bluetooth device list.
6. Connect your mobile device to that Bluetooth device.

The speakers are now paired in True Wireless Stereo (TWS) mode.
To disconnect TWS mode, press and hold the Play/Pause button again.

CHARGING

Connect the supplied USB Type-C cable to the speaker. **Connect the other end to:** a USB wall charger (not included), or a powered USB port on a computer.

Charging Status:
Red LED On: Charging
Red LED Off: Fully Charged

When the battery level becomes low, the speaker announces: **"Low Battery."**
When the battery reaches a critically low level, the speaker announces: **"Please Charge."**
Recharge the speaker as soon as possible to avoid automatic shutdown.

3.6”