PETKIT

USER MANUAL

PETKIT FRESHELEMENT SMART

Please read this manual carefully before using your product.

01 PRODUCT SUMMARY

01 PRODUCT SUMMARY

Note: Food Dispenser Lock Button and Bowl Lock Button are located on the bottom of the product.

01 PRODUCT SUMMARY

02 SCAN QR CODE TO WATCH INSTRUCTIONAL VIDEOS

Product Video

Scan the QR code to watch the product video.

Warning and Instructions

Scan the QR code to view the warning and instructions.

Scan the QR code to download the PETKIT app. Follow the app instructions to complete the device setup.

03 QUICK START GUIDE (DEVICE SETUP)

Connect to a power source

Connect the power adapter to the power port on the back of the product. Ensure the power cord is properly connected and secure to avoid any disconnections during operation.

Connect to power adapter

Connect the power adapter to a standard power outlet.

Connect to the PETKIT app

- Ensure your smartphone's Bluetooth and location services are enabled.
- Open the PETKIT app and select "Add Device" from the main interface.
- Follow the app's instructions to complete the device setup.
- Ensure your smartphone and the device are within the Bluetooth range for a successful connection.

04 QUICK START GUIDE (OPENING THE LID AND ADDING FOOD)

Open the lid

- Press the lid lock button on the rear of the silo to unlock the lid.
- Lift the lid to open it.

Add food

- Pour food into the silo.
- Ensure the food does not exceed the maximum capacity marked on the silo.
- Avoid overfilling to prevent food from spilling when the lid is closed.

Close the lid

- Gently close the lid and ensure it is properly locked to prevent any food from spilling during operation.

05 HOW TO USE

Manual Feeding

- Press the food dispenser button on the feeding port to manually dispense food.
- Ensure the bowl is in place before pressing the button to avoid spillage.

Use the app to remotely control food dispensing

- Open the app and select your device from the main interface.
- Tap the "Feeding" button to remotely dispense food.
- Ensure your smartphone and the device are within the Bluetooth range for a successful connection.

Manual Feeding

- Press the food dispenser button on the feeding port to manually dispense food.
- Ensure the bowl is in place before pressing the button to avoid spillage.

06 INDICATOR LIGHT

Solid Green	Normal
Solid Yellow	Low Food Level Warning
Solid Red	Food Dispenser Jam Warning
Flashing Red	Power Failure Warning

07 HOW TO CLEAN

- Remove the food dispenser and bowl from the silo.
- Remove the silo from the base.