说明书 105G普通纸,折页 ,单色 单面 印刷, 成品尺寸:40*130MM

40MM

130MM

折叠虚线 折叠虚线 折叠虚线 折叠虚线 折叠虚线 折叠虚线 折叠虚线 折叠虚线 折叠虚线

TV Stick

User Guide

1. Parts

TV Stick x1

User Guide x1

Remote Controller x1

Power Cable x1

HDMI Cable x1



TV Stick x1



Remote Controller x1

User Guide x1

80CM

Power Cable x1

HDMI Cable x1

2. TV Stick General information



1 HDMI Port

2 LED Indicator

3 USB Port

4 IR

5 USB/5V 2A

3. Remote Controller Button Functions



1 Power
2 Menu
3 Up
4 Left
5 Down
6 Return
7 Home
8 Volume +
9 Volume -
10 YouTube app
11 Disney+ app
12 Mouse
13 Voice
14 Setup
15 OK/Selection
16 Right
17 Iptv
18 Channel +
19 Channel -
20 Volume-
21 Netflix app
22 Google play app

Pless and hold the "OK"and "-" buttons at the same time. Close to the TV stick,release the button after the light on the remote control flashes,and wait for automatic pairing.

4. Installation

1 Plug the HDMI cable to the HDMI port of your TV set, then the power cable to the USB port. Afterwards, plug both cables in the respective ports of the TV stick.



2 Connect the TV Stick to the WiFi network



5. LED indicator working status

The TV stick LED indicator has a two-color light: green and red.

*The LED indicator will turn green when the device is on. The system will start automatically when the power supply is connected.

*The LED indicator will turn red when the system is on standby.

*The LED indicator will be turned off whenever the power supply is cut off.

6. About the adapters that can be used to load TV stick:

If you connect the USB power cable to an adapter, the ideal voltage is from 4.8V to 5.3V, and the input current should not be less than 1A. Some quick charge adapters are not suitable for the TV stick because the output voltage of these adapters may become very high during use.

Exemption clause

The illustrations included in this guide are for reference only. Due to the constant upgrade of the goods, the physical product may differ slightly from the illustrations. Always refer to the physical product.

Tips:
HDMI only supports output mode; Access to a laptop; Will not work properly

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.