TRUE WIRELESS EARBUDS

User Manual

QUICK START

CHARGE

Fully charge your ToGo True Wireless Earbuds charging case with the included USB-C charging cable and any USB charger.

PAIR

Open the charging case and remove earbuds.
Insert them in your ears and you will hear "Power On"
Pairing mode is automatically enabled when you first power on your new earbuds or when a previously paired device is not detected
On your Bluetooth® audio source, add a new device and look for "ToGo Wireless"
You will hear a "connected" voice prompt

PLAY

Your True Wireless Earbuds are now charged, paired, and ready to use.

ADVANCED FEATURES

TOUCH CONTROLS:

Your ToGo True Wireless Earbuds are equipped with touch controls for your mobile device. See below for a complete list of controls:

	MEDIA CONTROLS		DURING AN ACTIVE CALL	
	Left Earbud	Right Earbud	Left Earbud	Right Earbud
ONE TAP	volume -	volume +	Answer/End Call	
TWO TAPS	Pause/Play			
THREE TAPS	Previous Track	Next Track		
HOLD	Summon Virtual Assistant		Ignore incoming call	

CHARGING:

Earuds

As soon as they are inserted into the charging case, a red light on each earbud will illuminate to indicate they are charging. The light will turn off when the earbuds are fully charged.

Charging case

Connect one end of the supplied USB-C charging cable to any USB charger and the other end to the USB-C port of the charging case.
A flashing red light next to the USB-C port indicates the case is charging.
When the red light stops flashing and is on steady, case charging is complete.
A blue light next to the USB-C port indicates that the case is charging the earbuds inside.
The blue light will turn off when earbud charging is complete.

TECHNICAL SPECIFICATIONS

Charging case:

Input: 5V DC 1000 mA
Output for Earphone charging: 5V DC 100 mA

Earbuds:

Rated Listening time on a single charge 2-3 Hours
Charging Time 1hr
Maximum 10m range, 3-5m effective range

Thank you for choosing BlueDiamond™! Since 1987, our mission has been to create products which make technology accessible and empower people to use it more effectively. We would love any feedback or comments you may have regarding this, or any other BlueDiamond™ product you own.

Contact Us: help@blue-diamond.ca

TRUE WIRELESS EARBUDS

Manuel de l'Utilisateur

DÉMARRAGE RAPIDE

CHARGEMENT

Chargez entièrement l'étui de vos écouteurs sans fil ToGo en utilisant le câble de chargement USB-C fourni et n'importe quel chargeur USB.

APPAIRAGE

Ouvrez l'étui de chargement et retirez les écouteurs.
Placez les écouteurs dans vos oreilles : vous entendrez le message « Power On » [« Appareil activé »].
Le mode d'appairage s'active automatiquement quand les écouteurs sont activés pour la première fois, ou quand ils ne détectent pas d'appareil précédemment appairé.
Sur l'appareil audio source équipé du système BluetoothMD, activez la fonctionnalité de recherche des nouveaux appareils et cherchez « ToGo Wireless » dans la liste.
Vous entendrez le message audio « Connected » [« Appareil connecté »].

LECTURE

Vos écouteurs sans fil sont maintenant chargés, appairés et prêts à être utilisés.

FONCTIONNALITÉS AVANCÉES

COMMANDES TACTILES :

Vos écouteurs sans fil ToGo sont équipés de commandes tactiles pour votre appareil mobile.
Vous trouverez une liste exhaustive de ces commandes ci-dessous :

	COMMANDES POUR LES FICHIERS AUDIO		PENDANT UN APPEL	
	Écouteur gauche	Écouteur droit	Écouteur gauche	Écouteur droit
TOUCHER UNE FOIS	Baisser le volume	Augmenter le volume	Répondre/Mettre fin à un appel	
TOUCHER DEUX FOIS	Pause/Lecture			
TOUCHER TROIS FOIS	Piste précédente	Piste suivante		
MAINTENIR LE CONTACT	Activation de l'assistant virtuel		Ignorer un appel entrant	

CHARGEMENT :

Écouteurs

Dès que les écouteurs sont insérés dans l'étui de chargemeiode rouge s'allume sur chaque écouteur pour indiquer que le chargement est en cours. La diode s'éteint dès que les écouteurs sont entièrement chargés.

Étui de chargement

Branchez une des prises du câble de chargement USB-C fourni sur n'importe quel chargeur USB, et l'autre au port USB-C de l'étui de chargement.
Une diode clignotante rouge s'allume à côté du port USB-C pour indiquer que l'étui est en cours de chargement. Une fois que la diode cesse de clignoter et reste allumée en continu, le chargement de l'étui est achevé.
Une diode bleue s'allume à côté du port USB-C pour indiquer que l'étui charge les écouteurs qui se trouvent à l'intérieur. Cette lumière bleue s'éteindra une fois le chargement des écouteurs achevé.

CARACTÉRISTIQUES TECHNIQUES

Étui de chargement:

Courant d'entrée : 5 V (C.C.), 1 000 mA
Courant de sortie pour le chargement des écouteurs : 5 V (C.C.), 100 mA

Écouteurs:

Temps nominal d'écoute sur une charge complète : de 2 à 3 h
Temps de chargement : 1 h
Portée maximale : 10 m; portée efficace : de 3 à 5 m

Merci d'avoir choisi BlueDiamond™! Depuis 1987, notre mission est de créer des produits qui rendent la technologie accessible et permettent au public de l'utiliser de manière plus efficace. Nous serions ravis de connaître votre avis ou vos commentaires concernant ce produit, ou tout autre produit BlueDiamond™ que vous possédez.

Communiquez avec nous : help@blue-diamond.ca

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1)This device may not cause harmful interference.
(2)This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
Note:This equipment has been tested and found to comply with the limits for a class B digital device,pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequence energy and,if not installed and used in accordance with the instructions,may cause harmful interference to radio communications.However,there is no guarantee that interference will not occur in a particular installation.if this equipmemt does cause harmful interference to radio or television reception,which can be determined by turning the equipment off and on,the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an autlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.