材料：100g双铜-4折页，单色正反印

320.00 mm

80.00 mm

无线对耳+充电仓
使用说明书

KLV-61



❶：触摸：手动开机/关机/暂停/播放/接听电话/挂断电话/上一曲/下一曲/语音助手
❷：LED指示灯以及拾音口
❸：耳机充电铜柱
❹：充电盒指示灯
❺：Type-c充电口

开机/关机

开机
充电盒开盖即自动开机，开机时白色指示灯亮1S，提示音Power on。耳机关机状态下触摸5S手动开机，开机时白色指示灯亮1S，提示音Power on。
无线配对
首次配对，开机后耳机等待无线连接，白色指示灯缓慢闪烁。打开手机开启无线，点击无线列表中"KLV-61"设备进行配对，成功配对后提示音：Connected，耳机白色指示灯长亮，此时手机上显示耳机已连接。若无配对，耳机将在5分钟后自动关机。
此后开机，耳机将自动进入回连状态，如附近有曾经配对过的设备，将自动回连曾经配对过的设备。如需要配对连接新的设备，请在耳机配对连接时关闭上一台设备的无线连接功能，耳机自动进入设备配对模式。
关机
耳机放入充电盒后，合盖自动关机。
耳机开机状态时长按5S手动关机，关机单耳时两耳机会同时关机，橙灯长亮1S，提示音：Power Off。如只需使用其中一只耳机，只需要将另一只耳机放回充电盒并且合盖。
5分钟无连接设备或者电池电压低于3.2V时，耳机将自动关机
恢复出厂设置
耳机在出厂时都已经完成对耳互配，如出现人为打散对耳互配，需要恢复出厂设置，在不连接无线的情况下，连续触摸6次，白橙灯快速闪烁，耳机恢复出厂设置，等待约10S后按照无线配对步骤重新连接设备即可。

常规功能

暂停/播放：轻触两次任意耳机
上一曲：轻触三次左耳
下一曲：轻触三次右耳
接听电话：来电时，轻触两次任意耳机，提示音：滴
挂断电话：通话时，轻触两次任意耳机，提示音：滴
拒接电话：来电时，长按2S耳机触摸，提示音：滴
唤醒/退出语音助手：已连接手机状态下长按2S任意耳机触摸唤醒手机语音助手，再次长按2s退出语音手机助手

指示灯状态

耳机
开机：开机时白色指示灯亮2S
关机：关机时橙色指示灯亮1S
待连接设备状态：白色指示灯缓慢闪烁
已连接设备状态：白色指示灯长亮
低电量报警：耳机橙灯每5S闪烁一次
耳机互配时：耳机恢复出厂设置，白橙指示灯快速闪烁
充电盒
充电盒充电状态：充电时，红色指示灯长亮；电量充满后，指示灯熄灭
耳机在充电盒充电状态：耳机充电时，蓝灯长亮；耳机充满电后，指示灯熄灭

产品参数

- 无线版本：V5.4
- 工作温度：-5C°到45C°
- 工作电压：3.0V-4.2V
- 电池容量：耳机[60mAh]，充电仓[400mAh]
- 充电盒可对耳机提供充电次数：3次
- 充电时间：约90分钟
- 待机时间：10-20天
- 音乐时间：约8小时（中等音量）
- 通话时间：约7小时
- 连接距离：15米
- 音频解码：AAC,SBC
- 频率（Hz）：20Hz-20KHz

配件

- USB充电线一条

-注意事项
1.请防止耳机摔落、撞击、扭曲、刮擦、投入水火当中。
2.使用耳机时，尽量远离磁体附近
3.尽量避免将本产品暴露于极端温度以及潮湿环境中。
4.为避免损伤听力，请将音量保持在适度水平，避免长时间高音量听音乐，这可能对听力造成永久性伤害或失聪。
5.请在驾驶，骑自行车，过马路等需要您的注意力集中的情况下不要使用
6.充电完成后，请把充电线从机身拔出，避免让产品长时间处于充电状态。
充电器输出电压和电流不大于5V/1.5A，如因充电器的输出电压和电流超出指定，这会对本产品造成严重损害，产品保修将同时失效。

OPEN WIRELESS HEADSET
User Manual

KLV-61



❶: Touch Controls: Manual power on/off, Touch control: Manually power on/off, pause/play, answer/hang up call, previous/next track, voice assistant.
❷: LED indicator and microphone port.
❸: Earphone Charging Contacts.
❹: Charging case indicator light.
❺: Type-C Charging Port.

Power On/Off

Power On:
The earbuds automatically power on when the charging case is opened, with a white LED indicator lighting up for 1 second and a "Power on" prompt tone. Touch and hold for 5 seconds to manually power on the earbuds when they are off; the white LED indicator will light up for 1 second with a "Power on" prompt tone.
Wireless Pairing
For first-time pairing, the earbuds enter Wireless pairing mode after power on, with the white LED indicator flashing slowly. Turn on Wireless on your phone, select "KLV-61" from the Wireless list to pair. Once successfully paired, you will hear a "Connected" prompt tone, and the earbuds' white LED indicator will stay on, indicating the earbuds are connected to the phone. If not paired, the earbuds will automatically power off after 5 minutes.
Upon subsequent power ons, the earbuds will enter reconnection mode automatically. If a previously paired device is nearby, they will reconnect automatically. To pair with a new device, turn off the Wireless connection of the previously connected device while the earbuds are in pairing mode, and the earbuds will enter device pairing mode automatically.
Power Off
The earbuds automatically power off when placed back into the charging case and the lid is closed.
Touch and hold for 5 seconds to manually power off the earbuds while they are on. Powering off one earbud will turn both off simultaneously; the orange light will stay on for 1 second, with a "Power Off" prompt tone. If you only want to use one earbud, simply place the other back into the charging case and close the lid.
The earbuds will automatically power off after 5 minutes of no connection or when the battery voltage drops below 3.2V.
Factory Reset
The earbuds are factory paired. If pairing is disrupted and needs to be restored, touch either earbud 6 times continuously without a Wireless connection; the white and orange LED indicators will flash rapidly. The earbuds will reset to factory settings. Wait about 10 seconds and then reconnect the device following the wireless pairing steps.

Common Functions

Pause/Play: Double-tap either earbud.
Previous Track: Triple-tap the left earbud.
Next Track: Triple-tap the right earbud.
Answer Call: Double-tap either earbud when receiving a call; you will hear a "beep".
Hanging Up: Double-tap either earbud during a call; you will hear a "beep".
Rejecting Calls: Long press on the touch area of either earbud for 2 seconds during an incoming call; you will hear a "beep".
Wake/Exit Voice Assistant: While connected to a phone, long press the touch area of either earbud for 2 seconds to wake the voice assistant; long press again for 2 seconds to exit.

Indicator Light Status

Earphones:
Power On: The white LED indicator lights up for 2 seconds.
Power Off: The orange LED indicator lights up for 1 second.
Awaiting Connection: The white LED indicator flashes slowly.
Connected to Device: The white LED indicator stays on.
Low Battery Alert: The earbuds' orange light flashes once every 5 seconds.
During Earbuds Pairing: For factory reset, the white and orange LED indicators flash rapidly.

Charging Case:
Charging: During charging, the red LED indicator stays on; it turns off when the battery is fully charged.
Earbuds Charging in Case: The LED indicator stays on while the earbuds are charging; it turns off when the earbuds are fully charged.

Product Specifications

- Wireless version: V5.4
- Operating temperature: -5C° to 45C°
- Operating voltage: 3.0V-4.2V
- Battery capacity: Earbuds [60mAh], Charging case [400mAh]
- Number of charges provided by the case: 3 times
- Charging time: About 90 minutes
- Standby time: 10-20 days
- Music time: About 8 hours (at medium volume)
- Talk time: About 7 hours
- Connection distance: 15 meters
- Audio decoding: AAC, SBC
- Frequency (HZ): 20Hz-20KHz

Accesorries:

- One USB cable

-Notes
1.Prevent dropping, impacting, twisting, scratching, or submerging earphones.
2.Maintain distance from magnets during earphone usage.
3.Avoid exposing the product to extreme temperatures or humidity.
4.To avert hearing impairment, maintain volume at moderate levels and limit prolonged high-volume music listening to prevent permanent hearing damage or deafness.
5.Refrain from using earphones while driving, cycling, crossing roads, or during activities requiring full attention.
6.After charging, unplug the charging cable to prevent prolonged charging.
Charger output should not exceed 5V/1.5A, as exceeding these specifications may lead to product damage and void the warranty.

Warning Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.