MAGCAM 2 PHONE GRIP

MAGCAM 2 手机摄影手柄

PGYTECH

包装清单/In the Box



安装示意/Installation Instructions



拆卸示意/Disassembly Instructions



功能解析/Functions

使用模式/Using Modes



EN

Specifications

Product Name: MagCam 2 Phone Grip
Model: PGYTECH-P-MG-004 (QSHT-P-YC-0801/P-YC-0821)
Product Weight: 0.32kg
Main Materials: ABS+PC, Aluminum Alloy, Zinc Alloy
Battery Capacity: 1000 mAh (3.7V)
Battery Capacity: 3000 mAh (3.85V)
Rated Capacity: 1800 mAh
Type-C Port Input: 5V/2A
Type-C Port Input: 9V/2A
Type-C Port Output: 5V/2A
Wireless Charging Output: 5V/1A
Electrical Contact Pins Output: 5V/3A

PlugCam 2 Charging Module



Type-C port functions as both a charging port and a 10W output port, allowing direct connection to charge your phone. The built-in battery supports both magnetic wired and Bluetooth remote via electrical contact pins. (The stand's built-in wireless coil charges the phone).

Specifications

Battery Capacity/Voltage	1000mAh 3.7V
Charging Port	Type-C
Charging Time	About 2 hours
Operating Temperature	10°C to 35°C

Status Indicator Lights

Battery Indicator Lights During Charging

As the battery charges, the indicator lights will illuminate and display the current charge level, showing the current charge level.

1. First White Light Blinks Slowly: Charging Initiated

2. First Light Solid, Second Light Blinks Slowly: Battery level is approximately 25%-50%.

3. First and Second Lights Solid, Third Light Blinks Slowly: Battery level is around 51%-75%.

4. First, Second, and Third Lights Solid, Fourth Light Blinks Slowly: Battery level is approximately 76%-99%.

5. All Four Lights Solid: Battery fully charged (100%).

Note: The first indicator light is positioned closest to the Type-C port. All indicator lights will turn off immediately upon disconnecting the external power source.

Battery Indicator Lights During Discharge

When the device is connected to the Type-C port for discharge, it functions as a power bank. When discharging via the wireless charging output, press the power button to activate the battery indicator lights. This will also start the wireless charging output and supply 5V to the Bluetooth remote. As the battery depletes, the indicator lights will sequentially turn off from top to bottom.

1. All Four Lights Solid: Battery level is approximately 76%-100%.

2. First, Second, and Third Lights Solid: Fourth Light Off: Battery level is about 51%-75%.

3. First and Second Lights Solid: Third and Fourth Lights Off: Battery level is around 26%-50%.

4. First Light Solid: Second, Third, and Fourth Lights Off: Battery level is approximately 6%-25%.

5. First Light Off: Battery level is below 5%, indicating the grip needs recharging immediately.

Note: When using wireless charging, the battery indicator lights will stay on for 5 seconds after removing the device, then automatically turn off to save power. When using wired charging, the lights will turn off immediately and power will be cut as soon as you remove the device.

Checking Battery Level

To check the battery level when not charging or discharging, press the power button. The battery indicator lights will illuminate and stay on for 3 seconds to show the remaining battery level.

Get to Know Your Bluetooth Remote



Compatible Devices

Android: Phones with Bluetooth, Android 8.0 or above.
iOS: iPhone 12 series or later, iOS 11 or above.

Specifications

Battery Capacity/Voltage	80mAh 3.7V
Charging Port	Electrical contact pins
Operating Temperature	10°C to 35°C
Transmission Range	10 meters

Status Indicator Lights

Charging/Low Battery/Remote Waiting for Pairing/Remote Paired

1. When the Bluetooth remote is powered off, the yellow indicator light is steady to indicate charging. When it turns blue and steady, the battery is fully charged (100%).

2. When the Bluetooth remote is powered on, the red indicator light steady indicates low battery (0-25%).

3. When the Bluetooth remote is powered on, the yellow indicator light steady indicates the remote is charging and waiting to pair; the blue blinking light indicates the remote is not charging and waiting to pair.

4. When powered on, the blue steady light indicates the remote is paired with the phone/cast charging); yellow steady light indicates paired while charging. When the yellow light turns blue and steady, battery is 100%.

Pairing Guide

Power On

- Press and hold the "Power" button for 1 second to turn on the remote.

Power Off

- Press and hold the "Power" button for 1 second to turn off the remote.

Pairing

- Turn on your Phone Camera. Power on the remote, enable Bluetooth on the phone, select "PGYTECH MagCam 2" from the device list to pair. Remote auto-shuts down after 5 min if unpaired; after pairing, auto-shuts down after 10 min idle. Once paired, subsequent power-ons automatically reconnect to the same device.

Note: If the Bluetooth remote is not detected, the Bluetooth must be configured in iOS Native Camera:
Go to Settings > Accessibility, enable Assistive Touch, set Zoom Region to Full Screen (screen will magnify when Zoom is on single-tap to exit; while other settings remain unchanged).

- To customize the function of the "Custom Dial" in the PGY Tech App Store, open the app, tap settings > Basic Settings > Unlock Pro version > Connect New Device > select "PGYTECH MagCam 2" > Connect.

Custom Dial

- In the PGYTECH App, swipe the "Custom Dial" left/right to set custom button functions.

Camera Flip

- Android: Swipe the "Custom Dial" left/right to switch between Photo/Video mode.
- iPhone Camera: In portrait mode, swipe "Custom Dial" left/right to switch Photo/Video.
- OPPO Camera: Swipe the "Custom Dial" left/right to adjust global EV by default, or selected in camera parameters.

Clear Bluetooth Pairing

- Press and hold the "Shutter/Record/Focus Button" and "Power Button" for 5 seconds to disconnect previous phone and re-pair.

Camera Flip

- On camera screen, double-tap "Power/Quick Start/Mode Switch/Flip/Pair Button" to switch front-rear camera.

Note: The PGYTECH App must be launched and connected to "PGYTECH MagCam 2", customize single/double-tap in Hardware Settings.

Zoom

- Swipe the "Zoom Adjustment Button" left/right to adjust one step; left to decrease, right to increase. Long swipe for continuous adjustment; release to stop.

Focus

- Half-press the "Shutter/Record/Focus Button" to autofocus.

Shutter/Video Recording

- Fully press the "Shutter/Record/Focus Button" to take a photo or start video recording.
- OPPO Camera: Long-press "Shutter/Record/Focus Button" to enable burst-shooting.

Quick Start

- Double-tap "Power/Quick Start/Mode Switch/Flip/Pair Button" to quickly open the camera.
- iPhone Camera: Triple-tap "Power/Quick Start/Mode Switch/Flip/Pair Button" to quickly open camera from screen-off state.
- OPPO Camera: Double-tap "Shutter/Record/Focus Button" to quickly start, configurable in Camera Settings.

Mode Switch

- On camera screen, tap "Power/Quick Start/Mode Switch/Flip/Pair Button" to switch Photo/Video mode.
- iPhone Camera: Double-tap "Power/Quick Start/Mode Switch/Flip/Pair Button" to switch modes in Camera Settings.
- OPPO Camera: Tap "Power/Quick Start/Mode Switch/Flip/Pair Button" to switch between modes, e.g., Portrait, Pause.

⚠ Warnings

1. Please charge the phonegrip/grip handle before use.
2. Pre-installation: Ensure the surface meets adhesive requirements and is clean. Allow the magnetic ring to set for 24 hours after installation.
3. Compatible Surfaces: Suitable for smooth, non-porous surfaces, such as metal, glass, or certain plastics. Not recommended for rough, textured, or uneven surfaces (e.g., fabric, leather, unpainted wood). Also unsuitable for curved glass, silicone, leather, wood, fabric, or waterproof-coated surfaces. The surface must be flat for the adhesive to work effectively.
4. Adhesive: Use non-reusable 3M300LSE adhesive. Ensure the correct placement on your first attempt.

Safety Instructions

- Keep away from water. Do not expose the product to any liquids. Never submerge it in water or use it in rainy or humid conditions. Contact with water may cause corrosion, leading to battery combustion or even explosion.
Fire Response: In case of fire, use water, water mist, sand, fire blanket, dry powder, or CO2 fire extinguishers in the Operating Temperature: Use the product in environments with temperatures between 10°C and 35°C.
- Battery Safety: Do not use damaged batteries. Damaged batteries, including dismantling can cause electrolyte leakage, fire, or explosion.
- Avoid Excessive Charge: Do not subject the product to mechanical impact, crushing, or throwing. Avoid placing heavy objects on it. Do not heat the product or place it in a microwave or pressure cooker.
Avoid Heat Sources: Do not place the product near heat sources (such as ovens or heaters) or in a hot car. The storage Battery Care: Do not leave the battery completely discharged for long periods, as this can damage the cells and make the battery unusable. To keep the battery in good condition, recharge and discharge it about every 3 months.
- Battery Replacement: Battery replacement requires a model that is certified with CCC and compliant with relevant national safety standards.

Disclaimer

Please read this disclaimer carefully. Using this product means that you acknowledge and accept the terms of this disclaimer. By using this product, you hereby acknowledge and agree that you are solely responsible for your own conduct and any consequences arising from your use of this product. You agree to use this product at your own risk. To the maximum extent permitted, PGYTECH accepts no liability for any and all misuse, consequences, damages, injuries, penalties, or any other legal responsibility arising from your use of this product. PGYTECH reserves the right to:
Before every use, make sure that your product is functioning properly. If there's any damage or incapacity, stop using it immediately. Within the scope of state laws and regulations, PGYTECH reserves the right of final explanation and revision for the commitment.

FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

让创作更轻松

MAKE CREATION EASIER

LEARN MORE

Question & Support: support@pgytech.com