B35S

HELMET BLUETOOTH HEADSET

USER MANUAL

PRODUCT INTRODUCTION

In order to make riding safer and easier, the B35S Bluetooth helmet headset is designed for taking phone calls and listening to music or navigation while riding. The advanced CSR Bluetooth chipset and the integrated headphone amplifier provide a better audio experience regardless of use type. The delicate,small, and water-proof design makes the B35S an amazing riding companion.

PRODUCT PARAMETERS

Bluetooth Chipset Version: EDR Bluetooth CSR 8635	Battery Capacity: 950mAh
Frequency: 2. 4GHz	Working Duration: ~40 hours
Bluetooth Profile: A2DP and AVRCP	Charging Voltage: DC 5V/210mA
Amplifier: HT4832SQ	Maximum Mobile Phone Distance: 10 m/30ft

ITEMS INCLUDED



BUTTON FUNCTIONS

" ⏻ "
- Long press for 2 seconds to boot the device. If there is no available Bluetooth device, the B35S will automatically enter pairing mode. The red and blue LED lights flash alternately. If there is a previously connected device, the B35S will automatically connect.
- Long press for 3 seconds to shut down device after the power is on.
- Long press for 1 second to start Siri for iOS and Google Assistant for Android devices.
- Double-click the power button when the headset is power on BUT a Bluetooth device is NOT connected in order to change the B35S device language.

" + "
- Short press the plus button for volume increase.
- Long press the plus button to change to the next song.

" — "
- Short press minus button for volume decrease.
- Long press the minus button for the last song.

" ⏻ "

When In Standby/Listening to Music/Listening to Navigation
- Short press the multi-function button to play and pause music.
- Long press the multi-function button to redial the last outgoing call.

Incoming Call
- The B35S will automatically answer the incoming calls if no input is given within in 10 seconds.
- Long press the multi-function button for 2 seconds to reject an incoming call.
- Short press the multi-function button to answer an incoming call.

Calling
- Short press the multi-function button to hang up after calling.

FUNCTIONAL OPERATION

Boot: Long press" ⏻ "button for 2 seconds.
Shut Down: Long press" ⏻ "button for 3 seconds.
First Time Paring:
Step 1: Long press" ⏻ "button for 2 seconds to boot the device and wait for the red and blue LED lights flash alternately.
Step 2: Open the mobile device Bluetooth list, select "B35S" and and connect. Once connected, only the blue LED light will flash.
Automatic Paring: Open the Bluetooth settings page of the last connected phone. Long press the" ⏻ " button for 2 seconds to boot the B35S, then the device and Bluetooth phone will automatically be paired within 15 seconds as indicated by the blue LED light slowly flashing.
Automatic Power Off: If the device has no previous connections with any nearby Bluetooth devices for 5 minutes, it will automatically power off.

BATTERY CHARGING

- Connect the device to your PC USB or any USB charge socket to charge the battery.
- The red LED light indicates that the unit is charging.
- When charging is completed, the red LED light will turn blue.

HARDWARE RESET

Charge the device if the system has any issues.

HOW TO MOUNT THE HEADSET

1. Mounting headset device on the helmet.
Main Method: Use the provided mounting clip to find a suitable position on the edge of the helmet and clamp the mounting clip to the helmet.
Alternate Method: You can use Velcro to mount the device on the edge of the helmet.

2. To attach the ear speaker and microphone arm to the inside of the helmet. Take the Velcro pads which the speaker will attach to and test the best position for placement. The Velcro pad should be fixed at the height of your ear within the helmet's speaker cutouts. You will need to put the helmet on a few times to find the optimum position to apply the pad. When the correct positioning is found, remove the protective strip and apply the Velcro pads to the inside of the helmet.
3. Take the ear speaker and stick it to the Velcro pad. Run the microphone arm down and around to where your mouth will be. The microphone arm is flexible so you can adjust it so that it sits in the optimum position in front of your mouth. Some helmets have removable padding, if yours does, it is recommended to put the speaker and microphone under the padding.
4. Insert the headphone plug into the headphone jack on the device and make sure it is firmly in place, otherwise the quality of the sound will be affected and calling may not be possible.
5. Secure the cord with the headset plug inside the helmet. Tuck any extra lengths of wire into the helmet as well. Ensure that only few centimeters (or an inch) of the cord slack sticks out.

COMMON FAULTS AND SOLUTIONS

Fault Symptom	The Reason	How to Fix the Issue
The connection is suddenly interrupted	There is an obstacle stopping the signal path or the distance is beyond the effective distance between phone and B35S	Clear any obstacles between the two devices or make sure the B35S and phone are within the effective distance
Automatic shut-down	The battery is low or the B35S has been under unpaired mode for over 5 minutes	Charge with an accessory charging cable or connect the available Bluetooth device
Monosyllabic /murmurs or unable to call	Audio input or output exception	Check the audio output with the input plug in just the right place
All buttons ineffective	Hardware failure	Reset the hardware by charging the headset with the USB cable

1. Prevent water from getting into the internal circuits. Short circuits resulting from water damage will break the device.
2. Do not open the device. Doing so will void your warranty.
3. Please use the product accessories charging cable to connect the corresponding charger.
4. Make sure that there are no obstacles between the transmitter and receiver and both are within an effective distance for better signal.

Warnings:
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,which can be determined by turning the equipment off and on,the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be u sed in portable exposure condition without restriction

Warranty Card

User Name: _____ Tel: _____
Address: _____
Purchase Date: _____ Model: _____
Problem Description: _____
_____
Date: _____

QUANTIFIED CERTIFICATE

CHECKER: _____
DATE: _____

CE FC

型 214-117116

MADE IN CHINA

455mm X 95mm

B35S

BLUETOOTHヘルメットヘッドセット

取り扱い説明書

製品紹介

B35Sは弊社最新のヘルメット用イヤホン製品です。本体とイヤホンが分離される設計で、運転中の操作は楽になり、音質も飛躍的に向上しました。
その上、従来の薄型イヤホンと長時間待機も対応しています。
この商品を十分に活かすため、利用前は必ず本書をお読みください。また、お読みの後、いつでもご覧になれるところに保管してください。

製品仕様

Bluetoothチップ:EDR BT CSR 8635	電池容量:950mAh
周波数:2.4GHz	利用時間:~40時間
BluetoothプロファイルA2DPとAVRCP	充電電圧/電流:DC5V/210mA
アンプ:HT4832Q	通信距離:10メートル以内

内容リスト



ボタン機能

" ⏻ "
- 2秒長押して製品を起動し、利用可能なデバイスがない場合は待機状態になり、LEDライトは赤青で交互に点滅します。
- 電源オンの時で3秒長押して電源を切ります。
- 1秒長押してSIRIを起動させます。(アップル端末のみ、一部のアンドロイド端末で音声アシスタントを起動させます。)
- 電源オンの状態、Bluetooth未接続の状態で電源ボタンを2回に連続押して、言語を変更します。

" + "
- 一回押したら音量増加
- 2秒長押したら次の曲(3秒以上に押して次の曲に切る操作を繰り返します。)

" — "
- 一回押したら音量減少
- 2秒長押したら前の曲(3秒以上に押して前の曲に切る操作を繰り返します。)

" ⏻ "

待機中 / 音楽を聴く/ 航法を聴く
- 音楽再生中に一回押したら音楽再生/停止
- 3秒長押したら最後にかけた番号をかけます。
着信
- 操作しない場合、番号音声10秒再生した後、着信を自動的に受けます。
- 電話が来た時、2秒長押すと着信を拒否します。
- 電話が来た時、一回押すと電話を受けます。
通話中
- 電話中に、一回押すと電話を切ります。

ペアリング

電源入れ:" ⏻ "ボタンを2秒長押し　　電源切れ:" ⏻ "ボタンを3秒長押し

はじめのペアリング:
ステップ1: " ⏻ "ボタンを2秒長押して起動し、LEDライトは赤青で交互に点滅してペアリングモードに入ります。
ステップ2:スマホのBluetoothリストを開き、「B35S」を選択すると、本製品の青色LEDライトがゆっくりと点滅することで、「connected」の提示音があり、ペアリングが成功したことを示します。
自動ペアリング:
最後にペアリングしたデバイスのBluetoothをオンにし、" ⏻ "を2秒長押しして製品を起動します。その後、本製品とデバイスが15秒内で自動にペアリングされます。青色LEDライトがゆっくりと点滅することで、ペアリングが成功したことを示します
自動電源切れ:
5分以内にBluetoothが接続されていない場合、本製品は自動的に電源をオフにします。

充電について

- 付属のケーブルを利用してPCやUSBスマホの充電器と接続して充電します。
- 充電中、電源は自動オフします。電源ボタンを押して製品を起動できます。
- 充電中にLED指示ライトは赤と表示されます。
- 充電が完了した後、LED指示ライトは青になります。

リセット

- 商品はフリーズなど機能に異常がある時、充電をして商品を強制的に電源オフできます。電源を再起動したら、商品が正常になります。

取付方法

1.本製品本体をヘルメットに取り付けます。
取付方法:付属の固定クリップを使用してヘルメットの縁に適切な位置を見つけ、固定クリップをヘルメットに挟んで本体に固定します。



図1.固定クリップをヘルメットに固定します。　図2.本体を固定クリップに差し込みます。　図3.取り出し時に赤色の位置を押さえて本体を上に出します。

オプション:付属するマジックテープ(3M)を直接に使用し、本体をヘルメットの縁に貼り付けることができます。

2. イヤホンとマイクを固定する最適な位置を見つけます。付属のマジックテープにある両面テープを剥がし、ヘルメットの内面の決めた位置に貼り付けます。最適な場所を見つけるために、ヘルメットを何度も着用する必要があります。

3. イヤホンとマイクスタンドを固定したマジックテープに貼り付けます。マイクアームは弾力性があるため、口の前の最適な位置に調整することができます。

4.本体のイヤホンソケットにイヤホンケーブルのプラグを差し込んで、手でしっかり押さえます。そうしないと音質が悪くなったり、通話ができなくなったり可能性があります。

故障と対策

故障現象	原因	対策方法
急に信号が中断	送信経路を妨げる障害物があったり、スマホと本製品との間の有効距離を超える距離があったりする	送信経路の障害物を除去するか、またはスマホと本製品との間との間の有効距離が範囲内であることを確認する
自動電源切れ	バッテリー残量が少ない、5分間内にペアリングされていない	充電するスマホとペアリングする
片方だけ声が出たり、電話ができない	イヤホンの入力/出力が異常になる。	イヤホンのプラグが正しい位置にしっかり挿入したかを確認する。
すべてのボタンは効かない	電量不足	充電する

ご注意

1.本製品に適用される保存温度は－20℃から50℃までです。温度が高すぎるや低すぎる環境内で保存すれば製品の寿命が減少する可能性があります。

2.爆発の恐れがありますので、本製品に火をつけないでください。

3. ショートを防ぐため、本体内部に水が直接入らないようにしてください。

4.長時間に本製品を利用しない場合、乾燥の場所に保管し、定期的に製品を充電してください。(3ヶ月に1回充電する)

保 証 書

本保証書は、保証期間中に本製品を保証するもので、付属品類(充電器など)は保証の対象になりません。保証期間内に本製品が故障した場合は、保証規定によって無償修理いたします。

1.本保証書の有効期間はお買い上げ日より1年です。
2.次の修理等は保証期間内であっても有償となります。
●お取扱い方法が不適当のために生じた故障。
●天災(火災、浸水等)によって生じた故障。
●故障の原因が本製品以外の他の機器にある場合。
尚、当社が修理した部分が再度故障した場合は、保証期間外であっても、修理した日より3ヶ月以内に限り無償修理いたします。
3. 本製品の故障、または使用上生じたお客様の直接、間接の損害につきましては、弊社は一切の責任を負いかねますのでご了承ください。本保証書は、保証規定により無償修理をお約束するためのもので、これより お客様の法律上の権利を制限するものではありません。

本保証書は、保証規定により無償修理をお約束するものです。

お買い上げ日 ____ 年 __月 __日　　販売店名 _____

■修理を依頼される前に
故障かなとお思いになったら、まず取扱説明書をよくお読みのうえ、もう一度ご確認ください。

型 214-117116