**Dear Users,**
**Thank you for using Vanvision intelligent webcam. No matter where you are, Vanvision is your first choice for security!**

## Operation manual of Vanvision intelligent webcam

Please read the operation manual carefully before use and keep it properly. It is very important!

Warm tips:
please be sure that the camera is configured well, and the network phone can see the surveillance picture, and then fix it.



## Part1,Scanning of two dimensional code

**Get Ready**

Know your Wi-Fi network and password
Make sure your mobile device is running iOS 8 or higher or Android TM 4.1xor higher
·Make sure you're connecting to a 2.4GHz Wi-Fi network (It can't connect to 5GHz networks)

**1 Download the Seetong app from App Store**

Download on the App Store

ANDROID APP ON Google Play



## Part2, Connection diagram of line interface

**Connection of ball machine line**

**Note:**

**The manual is to show the correct installation method,**

**The appearance of the product is subject to the actual product.**



**The normal installation method of the power supply:**




**Wall-mounted anti-rain Special tips! ! !**

When installing the power supply, it must be ensured that the power supply is 90 degrees in the vertical direction of the wall, and the reinforcement cannot be swung!

## Part 3, configure network

**Register an account on your Seetong app**

Enter your mobile phone number or email address.

Enter the verification code and create a password.






**Add device (configure WIFI)**

manipulation steps
1.press "+"
2.Press wireless camera
3.Device scan addition
4.Select your WiFi account, enter your password and click next.






5.When you hear the "beep" or "wait for configuration" sound, click.
6.When you hear the "WIFI connection" sound, click.
7.The device is connected to the Internet successfully (if the registration platform fails, please disconnect the router power, restart it, and then forget the WIFI password to reconnect to WIFI).






8.Choose a usage scenario and start experiencing it.






9.Configuration of AP hotspots (no WIFI use, viewing within 10 meters)

Operation steps:
1. Open the screw at the bottom of the camera and press the reset button 4 times with a small screwdriver. The camera will make 2 beeps and enter the (hot spot) AP mode as shown in the figure below.






2.Open the mobile phone Settings, open the WIFI link, select the device hotspots"AP_TST_08XXXXXX" without password, make the mobile phone link to the device hotspots (this hotspot cannot access the Internet, turn off the mobile phone data), open seetongAPP and watch directly (the APP will prompt confirmation of connection, click to keep the connection).
3. Password modification: open Settings - Advanced Settings - modify AP






## Part 4:functional introductions of devices

**Introduction to home page functions**




A.Local video B.Phone screenshot
C.Two-way intercom D.Real-time monitoring
E.Definition adjustment
F.Multiple images at the same time
G.Screen switching and playing of multiple devices
H.View video playback video
I.Other function settings
J.PTZ controls rotation
K.The device makes a sound to drive away



**Introduction to settings**

(1)Device alias: customize the name of camera saved by mobile phone, which is convenient to view when multiple cameras are used.
(2)OSD configuration: Camera title, screen preview, storage camera title
(3)Image configuration: if the camera is installed reversely, the video flip, brightness, contrast saturation and definition can be adjusted;
(4)Light control lamp: light switch can control the light (soft photosensitive infrared white light), light mode (camera working mode can be set, default dual light, single infrared, single white light can be set);
(5)Volume control: adjust the speaker output volume, adjust the microphone pickup sound;
(6)Alarm setting can adjust the sensitivity, offline push, light alarm (white light) alarm length alarm time. The sound alarm horn can customize the voice alarm (the recording duration of 15 seconds can be customized, and the text can be converted into speech) the sound alarm time can be customized;
(7)Video setting: Can set the timing of video recording. Alarm video, TF card status, format TF card options;
(8)About the device: Check the device information, serial number, device cloud ID, software version, hardware version, lamp board type, lamp board brightness, audio input, device time zone, access method, IP address, etc.;
(9)Advanced Settings: video parameters and network of device subcode stream/main code stream can be modified. Settings, time zone setting, camera firmware upgrade, factory Settings recovery, remote restart, etc.
(10)Unbind and delete device; If the device is not bound to the account, other accounts can be bound;



**PTZ control**






**Lighting control**

**Alarm setting**






**Device playback**

Install the memory card and select card playback






**Device sharing**

1.Download and register SeetongAPP for the second mobile phone
2.Register account click share icon
3.Scan QR code
4.Open Seetongon the second phone and click the upper left corner to scan the QR code
5. Click to connect


Devices
Search device
Living room
Home
Mine
Sharing to Friends
Device Sharing
Sharing to friends
Device Sharing & Joint
Sharing to friends
Sharing to friends
Sharing to friends