FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

界探 JIETAN 大金刚

制造商：深圳市禾健科技有限公司

地址：广东省深圳市坪山新区江岭社区群代路5号

服务热线：[redacted]

Bluetooth Speaker

JT289

1.Accessories



2.Key Function Description



1. Power on/off RGB light on/off
2. EQ Mode Switching
3. Bluetooth key /TWS pairing key
4. Volume up plus/next
5. Volume down/PREV
6. The audio input is mixed Microphone switch
7. Play/Pause/speakerphone
8. Type-C Charger port
9. TF-card input
10. AUX Audio input
11. USB Play input
12. bluetooth/Charging status indicator
13. TWS Connection status indicator
14. EQ Status indicator
15. Microphone Connection status indicator

3.Remote control Function Description



1	POWER ON/OFF
2	MUTE ON/OFF
3	Audio input selection
4	TWS pairing key
5	Microphone reverberation up/down
6	Microphone volume up/down
7	Microphone turn on key
8	Volume up/down
9	Previous /Next/Play pause control key
10	Original song switch
11	Disconnect the Bluetooth connection
12	Still button
13	Sound selection button
14	Loop play switch
15	Accompaniment switch

4.Instructions

S/N	Function	Function operational specification	LED Statements
⏻	Starting up	Press "⏻" for 2 seconds to power on the speaker; automatically enter the Bluetooth search state, and wait for the device to connect	Search status, Bluetooth status The blue indicator blinks quickly,The Bluetooth connection status indicator is steady on In AUX USB TF-Card mode, it blinks slowly
	Power off	Press "⏻" for 2 seconds to power off the speaker	The Bluetooth status indicator is off
	RGB ON/OFF	Press "⏻" to switch the RGB light	RGB lights on both sides are off/on
	forced shutdown	Press and hold "⏻" for 8 seconds to power off the device	The Bluetooth status indicator is off
EQ	Sound mode Switching	In the boot state, press the "EQ" key to switch the sound mode, the default mode is 3D, press once to switch to the voice mode, and press again to switch to the bass mod	The green indicator is in human voice mode The Bluetooth indicator is in bass mode
✱	TWS In the case	Short press "✱" key to enter TWS pairing mode, exit TWS mode, and long press for 3 seconds to disconnect Bluetooth connection TWS Box connection operation: 1.Turn on the two speakers (IF other Bluetooth devices are connected, disconnect the BLUETOOTH so that the speakers are in Bluetooth SEARCH state). 2.Select a speaker and press "✱" or the TWS key on the remote control. When the yellow light flashes, TWS mode will be entered 3.After the pairing is successful, the yellow indicator of the two speakers will light up with a prompt tone, the Bluetooth indicator of the host will blink and wait for the phone to connect, and the blue indicator of the secondary will turn off 4.When TWS is connected, press "✱" to release the TWS box.The yellow light will turn off and an announcement will be made.Return to normal state	The yellow light on the TWS main speaker blinks, and the TWS is connected to the rear main speaker.Deputy speaker yellow light long bright;The blue light of the main speaker blinks until the phone is connected, and the Bluetooth of the secondary device is off

S/N	Function	Function operational specification	LED Statements
+	Volume plus	Short press the "+" key to increase the volume. When the volume reaches the maximum, there will be a prompt tone	
	Next song	Long press the "+" key to play the next song, which is effective in Bluetooth /USB/ TF-CARD mode	
−	Volume down	Short press the "−" key to reduce the volume. When the volume decreases to the minimum, a prompt tone will be played	
	PREV	Long press the "−" key to play the next song, which is effective in Bluetooth /USB/ TF-CARD mode	
M	Switching Mode	Press the "M" key to switch the audio input mode. This mode takes effect after the device is connected	When entering AUX/USB/TF-Card mode, the Bluetooth indicator blinks slowly
	Microphone switch	Long press the "M" key for 3 seconds to turn on or off the microphone, at which time the sound will pause	After the microphone function is enabled, the microphone indicator blinks slowly ; After connecting the microphone, the indicator light is always on ; If the microphone indicator blinks slowly, the microphone is not connected The indicator light turns off to turn off the microphone function
▷	Play Pause	Short press the "▷" key on Bluetooth /USB/TF-Card to play and pause music ; In AUX mode, short press "▷"to mute music	
	answer the telephone	Short press "▷" to answer incoming calls when Bluetooth is connected	
	Hang up	To hang up a call, press the " ▷ " key	
	EasyBusy	Long press the "▷" key to hang up a call when the phone is connected to Bluetooth	
	Tail number redial	In the Bluetooth connection state, long press the "▷ " key to redial the tail number	

5.Interface Function



1	Type-C Charging port DC5V/3A Intelligent charging (the red light is always on when charging, and the red light is off when full)
2	TF-card Port Insert the TF-CARD Card to automatically play (Bluetooth indicator blinks slowly)
3	AUX audio input port Insert 3.5MM audio cable for automatic playing (Bluetooth indicator blinks slowly)
4	USB (software control) port Insert the USB disk and play automatically (Bluetooth indicator blinks slowly)
5	Intelligent power saving function, automatically shut down when the device is not connected for 15 minutes
6	Low power Alarm When the battery voltage is lower than 6.6V, it will give a low power alarm. When the battery voltage is lower than 6.2V, it will automatically shut down

warm prompt If you use a power adapter for charging, please use a power adapter that has been certified by 3C and meets the standard



温馨提示

If the consumer uses the power adapter fo
It shall be purchased for supporting use, c
Standard power adapter

Safety Instructions for Batteries, Rechargeable Batteries

Tips
Safety Instructions for Batteries, Rechargeable Batteries cause the follo

- Deliver the scrapped products to the regular waste recycling center or professional dealers.
- Only use the battery recommended by the manu
- Only charge the batteryinan ambient temperature 10t040°℃.
- Turn off the battery powered products after use.
- Charge the battery regularly even if it is not used for a long time
- Do not heat the rechargeable battery more than 70c. Do not throw the rechargeable battery into the fire.

Product inspection certificate

QUALITY INSPECTIOT:_____
INSPECTOR:_____QUANTITY:_____
CODE:_____DATE OF MANUFACTURING:_____
EXECUTIVE STANDER:_____

Warranty card (please keep this card for warranty)

USER PROFILE: _____MONTH___DAY___YEAR

UserNam e	
Contact Address	
Aontact Number	
model	
Dealer's signature	

WARRANTY CARD
1.ONLY SPECIALLY MARKED USERS CAN CHOOSE TO RETUR THE PRODUCT DUE TO ITSOWN QUALITY
SOLUTIONS(NOT PRODUCT SOFTWARE FAULTS)FROM THE DATE OF PURCHASE THE RETURN PERIOD IS 7DAYS.THE REPLACEMENT PERIOD IS 15 DAYS AND THE WARRANTY PERLOD IS 12 MONTHS.
2.IF THE USER ENCOUNTERS PRODUCT QUALITY PROBLEMS WE SHE MAY REQUEST THE SERVICE OF THE WARRANTY SERVICE PROVIDER.WARRANTY SERVICE HAS TO BE DELIVERY BY HIMSELF/HERSELF IS REQUIRED.THE USER SHALL BEAR THE RELATED COSTS OF DELIVERY BY HIMSELF/HERSELF
ADDRO GSN
WHEN THE USER REQUESTS THE WARRANTY SERVICE.HE/SHE SHALL ACTIVELY PROVIDE THE VALID
WARRANTY SERVICE CERTIFICATE OR INVOICE
ADDITIONAL SERVICES BEYOND THE WARRANTY SHALL BE CHARGED IN ACCORDANCE WITH RELEVANT REGULATIONS,AND THE WARRANTY PERIOD OF THE PRODUCTS SHALL BE 3 MONTHS FROM THE DATE OF DELIVERY.
THE WARRANTY SERVICES PROVIDED BY OUR COMPANY IS LIMITED TO PRODUCTS WITH QUALITY
PROBLEMS AND DOES NOT INCLUDE COMPENSATION FOR BUYERS'LOSS OF INTERESTS LOSS CAUSED BY ACCIDENTS AND ANY OTHER INDIRECT OR DIRECTOSS
THE RESPONSIBILITY AND AVAILABILITY OF THE WARRANTY CARD, SELLER PLACE ADDRING TO THE REQUIREMENTSTO FILL IN NEGESSARYINTHEARRANTY CARD.

界探 JIETAN 大金刚

Manufacturer: Shenzhen Hejian Technology Co., Ltd

Address: No. 5, qundai Road, Jiangling community, Pingshan New District, Shenzhen, Guangdong

Service Contact: [redacted]