75*90MM

智能宝

使 用 手 册

关于产品

本产品是穿戴+音响+充电宝三合一产品，通过安装APP连接手机在设备上通话、播放音乐、休闲小游戏、离线收款、消息提醒等功能；本产品也是便携式的移动电源，其具备高容量、安全可靠、智能快充等优点，能够为您的电子设备提供可靠的电力支持。它适用于各种数码产品如手机、平板电脑、蓝牙耳机等的充电，是您生活、旅行、工作中的理想伴侣。

产品概览



① 开关机按键
② 显示屏幕
③ 手电筒灯
④ Type-C输入/输出接口
⑤ Micro输入接口
⑥ USB输出接口
⑦ Micro自带线输出接口
⑧ Type-C自带线输出接口
⑨ USB自带线输出接口
⑩ Lightning自带线输出接口
⑪ 喇叭出音孔

充电说明

输入

Type-C	DC 5V⎓3A 9V⎓2A 12V⎓1.5A
Micro	DC 5V⎓2A
USB	DC 5V⎓2A

输出

Type-C	DC 5V⎓3A 9V⎓2.22A 12V⎓1.67A
Type-C 自带线	DC 5V⎓3A 9V⎓2A 12V⎓1.5A
Micro 自带线	DC 5V⎓3A
Lighting 自带线	DC 5V⎓3A
USB	DC 5V⎓3A

对本产品进行充电，如：
（1）AC适配器接入任一输入端口给产品进行充电。
（2）电脑的USB接口接入任一输入端口给产品充电。

对数码设备充电：
1.选择对应的自带线接口给您的数码设备充电。

屏幕操作与按键操作

主页触摸手势
*右滑分屏功能：右滑出现，左滑返回。
*左滑自定义卡片：左滑进入自定义卡片。
*下滑消息通知：下滑出现，最多保存20条消息，上滑返回。
*上滑快捷栏：上滑出现，下滑返回。
*长按屏幕中央：切换壁纸

按键操作
长按开关机/手电筒
(任意界面长按三秒开启关闭手电筒)；
单击：返回上一级/进入菜单；
双击：菜单界面切换菜单；

下载与连接APP

扫码下载GS Fit

1、设备开机进入主页后，右滑进入分屏模式，点击"扫码连接"快捷按钮，右滑扫描下载APP二维码下载APP到手机上并安装，也可扫描上方或包装盒上GS Fit二维码跳转连接下载（浏览器、微信等都可扫描）。
2、连接设备
1）扫码连接：设备开机后进入主页后，右滑进入分屏功能，点击"扫码连接"快捷按钮，会弹出连接二维码，在APP内可直接进行扫码连接。
2）手动连接：手机开启蓝牙后，进入APP直接搜索设备进行手动连接。

功能介绍

电话 — 通讯录：连接手机可同步手机端联系人并可设定紧急联系人；
拨号：连接手机拨出，可以在手表端实现通话；
通话记录：连接手机可同步手机端通话纪录；

运动记录 — 记录当天的运动数据，包括：卡路里、活动时间、活动次数、步数及距离。

钱包 — 可以进行离线收款，离线交友；

地图 — 内置地图APP，连接手机同步地图导航。

语音助手 — 连接手机，语音唤醒手机APP.

本地音乐 — 手机上下载音乐，同步到设备本地音乐播放；也可以连接蓝牙耳机播放音乐。

小游戏 — 内含电子木鱼、电子佛珠、飞机大战、飞机躲避四款休闲小游戏。

相册 — 同步手机相册在智能宝上查看。

锻炼 — 内含户外跑步、室内跑步、户外步行、室内步行、户外骑行、室内单车、瑜伽、登山、徒步、越野跑、自由训练等11种运动模式。

睡眠 — 检测每天晚上您的睡眠状况。

天气 — 连接手机同步天气信息。

电子书 — 同步手机下载电子书在设备上。

闹钟 — 可以设置5个闹钟提醒。

录音 — 内含手机录音和本地录音功能

设置 — 包含屏幕显示、声音与振动、语音设置、时间设置、页面风格、通话设置、勿扰模式、健康提醒、省电模式、系统菜单、关于。

温馨提示

1.请详细阅读以下内容再使用本产品，错误的使用方法或者不兼容的设备有可能损坏您的产品；或导致本品受损；
2.请不要用尖锐物体刮擦本产品外壳表面。请勿抛掷、摇晃、强压或试图拆卸产品；
3.长期不使用时，请确保3个月内至少为本产品充满电一次；
4.请勿使用化学物质或者强效清洁剂清洁本产品；
5.在给您的数码产品充电工作完成后，请及时拔出连接线，以免连接线消耗本产品的部分电量。

注意事项

1.应防止日晒雨淋，防止剧烈震动、冲击或挤压。
2.应存贮于环境温度-10℃～45℃，相对湿度不大于75%的室内，应避免与腐蚀性物质接触，远离火源。
3.本产品不可当做普通垃圾丢弃，必须将此等废弃设备携至适当的电池回收点处理。
4.本产品不适合14岁以下儿童单独使用，须在成人监护下使用。
5.使用时务必认真核对被充电产品与本产品的电压是否兼容。
6.请勿置于水中、火中、过高或过低温度环境中。
7.请勿强拆、改装产品以免损坏产品的保护装置，导致电池发热，起火或爆炸。
8.产品在使用、充电或存放时，如出现异常气味、温度过高（正常使用会产生热量但不应烫手），或形状改变等异常现象应当立即停止使用并与经销商联系；
9.用户不正确使用或不正确放置本产品导致本产品寿命缩短甚至损坏而带来的责任，不属于保修责任或厂家责任，敬请谅解。

*注:如因消费者违反上述警示造成人身及财产损害将自行承担一切后果，本公司将不产生任何法律责任。

产品参数

产品名称：智能宝
产品尺寸：91.5*82.29.5MM
产品材质：PC+ABS注塑
蓝牙版本：5.3
系统要求：Android 5.0或ios 12.0及以上版本

Smart Treasure

User Manual

About the product

This product is a three in one product of wearable, audio, and power bank, which can be connected to the phone through the installation of an APP On device functions such as calling, playing music, casual games, offline payment, and message reminders;
This product is also a portable mobile power supply, which has high capacity, safety and reliability, and is intelligent and fast
The advantages of charging can provide reliable power support for your electronic devices. It is applicable to all
Charging various digital products such as mobile phones, tablets, Bluetooth earphones, etc. is essential for your daily life and travel An ideal companion in the workplace.

Product Overview



① On/Off button
② Display Screen
③ Flashlight
④ Type-C input/output interface
⑤ Micro input interface
⑥ USB output interface
⑦ Micro built-in cable output interface
⑧ Type-C built-in line output interface
⑨ USB built-in cable output interface
⑩ Lightning comes with a built-in cable output interface
⑪ Speaker sound hole

Charging instructions

input

Type-C	DC 5V⎓3A 9V⎓2A 12V⎓1.5A
Micro	DC 5V⎓2A
USB	DC 5V⎓2A

output

Type-C	DC 5V⎓3A 9V⎓2.22A 12V⎓1.67A
Type-C Built-in line	DC 5V⎓3A 9V⎓2A 12V⎓1.5A
Micro Built-in line	DC 5V⎓3A
Lighting Built-in line	DC 5V⎓3A
USB	DC 5V⎓3A

Charge this product, such as:
(1) Connect the AC adapter to any input port to charge the product.
(2) Connect the USB interface of the computer to any input port to charge the product.

Charging digital devices:
1. Choose the corresponding built-in cable interface to charge your digital device.

Screen operation and button operation

Home touch gestures
*Right swipe split screen function: Right swipe appears, left swipe returns.
*Left swipe custom card: Left swipe to enter custom card.
*Downward Message Notification: Downward movement occurs, up to 20 messages can be saved, and upward movement returns.
*Up scrolling shortcut bar: Up scrolling appears, down scrolling returns.
*Long press the center of the screen: switch wallpapers

key operation
Long press to turn on/off/flashlight
(Press and hold for three seconds on any interface to turn on or off the flashlight);
Click: Return to the previous level/enter the menu;
Double click: Switch menus on the menu interface;

Download and connect apps

Scan the QR code to Download GS Fit

1、After turning on the device and entering the homepage, right swipe to enter split screen mode, click the "Scan Code Connection" shortcut button, right swipe to scan and download the APP QR code to download the APP on your phone and install it. You can also scan the GS Fit QR code above or on the packaging box to jump to connect and download (browser, WeChat, etc. can be scanned).
2、Connected Device
1) Scan Code Connection: After the device is turned on and enters the homepage, right-click to enter the split screen function, click the "Scan Code Connection" shortcut button, and a QR code will pop up to connect. Scan code connection can be directly performed in the APP.
2) Manual connection: After enabling Bluetooth on the phone, enter the app and directly search for the device to manually connect.

Function Introduction

phone — Address book: Connecting to the phone allows for synchronization of mobile contacts and the ability to set emergency contacts;
Dialing: Connect your phone to make a call, which can be done on the watch end;
Call history: Connecting to the phone can synchronize the call history on the mobile end;

Sports Record — Record daily exercise data, including calories, activity time, number of activities, steps taken, and distance.

wallet — Can conduct offline payment and make friends offline;

map — Built in map app, connect to your phone to synchronize map navigation.

Voice Assistant — Connect your phone and voice wake up the mobile app

Local music — Download music on your phone and sync it to your device's local music playback; You can also connect Bluetooth headphones to play music.

Mini Games — It includes four leisure games: Electronic Woodfish, Electronic Buddha Beads, Aircraft Battle, and Aircraft Dodge.

Album — Synchronize your phone photo album and view it on WeChat.

physical exercise — It includes 11 sports modes, including outdoor running, indoor running, outdoor walking, indoor walking, outdoor cycling, indoor cycling, yoga, mountaineering, hiking, off-road running, and free training.

sleep — Check your sleep status every night.

weather — Connect your phone to synchronize weather information.

E-book — Synchronize downloading e-books from your phone on your device.

Alarm Clock — You can set 5 alarm reminders.

Sound Recording — Equipped with mobile recording and local recording functions

set up — Includes screen display, sound and vibration, voice settings, time settings, page style, call settings, do not disturb mode, health reminders, power-saving mode, system menu, and more.

Tips

1.Please read the following content carefully before using this product. Incorrect usage methods or incompatible devices may damage your product or cause damage to this product;
2.Please do not use sharp objects to scratch the surface of the outer shell of this product. Do not throw, shake, press or attempt to disassemble the product;
3.When not in use for a long time, please ensure that this product is fully charged at least once within 3 months;
4.Do not use chemicals or strong cleaning agents to clean this product;
5.After charging your digital product, please unplug the connection cable in a timely manner to avoid consuming some of the battery of this product.

note

1.It should be protected from sunlight and rain, as well as from severe vibration, impact, or compression.
2.It should be stored indoors with an ambient temperature of -10 ° C to 45 ° C and a relative humidity not exceeding 75%. It should be avoided from contact with corrosive substances and kept away from sources of fire.
3.This product cannot be disposed of as ordinary garbage and must be taken to an appropriate battery recycling point for disposal.
4.This product is not suitable for children under 14 years old to use alone and must be used under adult supervision.
5.Be sure to carefully check whether the voltage of the charged product is compatible with that of this product when using it.
6.Do not place in water, fire, high or low temperature environments.
7.Do not forcefully disassemble or modify the product to avoid damaging the protective device, causing the battery to heat up, catch fire, or explode.
8.If there is any abnormal odor, high temperature (normal use generates heat but should not be hot to the hands), or shape change during use, charging, or storage of the product, it should be stopped immediately and the dealer should be contacted;
9.The responsibility for shortening or even damaging the lifespan of this product due to incorrect use or placement by the user does not fall under warranty or manufacturer responsibility. We apologize for any inconvenience caused.

*Note: If consumers violate the above warning and cause personal and property damage, they will bear all consequences on their own, and our company will not be held legally responsible.

Product parameters

Product Name: Smart Treasure
Product size: 91.5 * 82.29.5mm
Product material: PC+ABS injection molding
Bluetooth version: 5.3
System requirements: Android 5.0 or iOS 12.0 and above

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.