尺寸：186x88mm
材质：105g铜版纸，黑白，单面印刷

186 mm

88 mm

10000mAh Wireless Power Bank

Instruction Manual

573-M2050Q

Product Overview



1. ON/OFF button
2. Lightning input
3. USB-A output
4. Type-C input
5. Digital Battery Indicator
6. Charging area
7. Wireless Charger LED indicator
8. Phone Holder

Package Contents



10000 mAh Power bank * 1
Charging Cable * 1
Instruction Manual * 1

SPECIFICATIONS

- Battery: 10000mah/3.82V/38.2Wh
- Wireless Output: 5W/7.5W/10W/15W
- Lightning input: 5V/2A 10W(Max)
- Type-C Output: 5V3A/ 9V2.22A/ 12V1.67A 20W(Max)
- Type-C Input: 5V3A/ 9V2A/ 12V1.5A 18W(Max)
- Transmitting Distance: ≤6mm
- USB-A output: 5V4.5A/ 9V2.2A/ 12V1.67A 22.5W(Max)
- Total Output: 5V/3A(Max)

LED INDICATORS

- ON/OFF button ① : Press once to view the remaining power capacity on Digital Battery Indicator ③ .

INSTRUCTIONS

1. Charging the Power bank:

- Charge the Power bank fully before use.
- Connect the USB-A to Type-C cable provided to a power source and to the Type-C input port on the Power bank ④ .
- Once connected, the Digital Battery Indicator ⑤ will flash during charging and stop once fully charged.

2. Charging electronic devices with the Power bank:

- Connect the appropriate cable to your mobile phone/device and plug the other end of the cable into the Type-C output port ⑤ or USB-A output port ③.
- The Digital Battery Indicator ⑤ will illuminate when charging.
- Remove the cable from your mobile device and Power bank once fully charged.

3. Charging electronic devices through wireless charging:

- Press the Power bank's ON/OFF button ① to turn on the wireless charging function. Press twice to turn off.
- Place the wireless charging supported mobile device on the charging surface ⑥, the LED indicator ⑦ will Turn GREEN when device is charging.
- Remove the mobile device and Powerbank once fully charged.

* Note: If the LED indicator is flashing green, the device is either NOT a wireless charging device or an object between the device and charging surface is interfering with the charging process.
PD means power delivery via the Type-C port.

SAFETY PRECAUTIONS

- WARNING - When using this product, basic precautions must be followed at all times:

1. Read all the instructions before use.
2. Never store or use this product below 32°F (0°C) or above 115°F (45°C).
3. Do not overcharge your phone. The unit may become hot under excessive use. Remove your phone once it is fully charged. Never charge your phone for longer than 7 hours.
4. The unit will only achieve full performance after completing 2 or 3 charge and discharge cycles.
5. To reduce the risk of injury, close supervision is required when the product is used near children.
6. Do not expose the device to moisture.
7. Do not use the device in excess of its output rating. Overloaded outputs above the rating may result in fire or injury.
8. Do not use the device if it has been damaged or modified.
9. Damaged or modified batteries may exhibit unpredictable behaviour resulting in fire, explosion or injury.
10. Do not disassemble the device. For repairs, seek a qualified service professional. Incorrect reassembly may result in fire or injury.
11. Do not expose the device to fire or temperatures above 104°F (40°C) as this may result in explosion.
12. To ensure product safety, ensure that qualified service professionals use only identical replacement parts.
13. Attachments to the back of your phone can interfere with the effectiveness of the wireless charger and lead to overheating. Please remove attachments from the phone before charging it on this device.

2022.11.24

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

2022.11.24