QUICK START GUIDE

Interface

Create Parent Account

- Enter Control Center.
- Choose parent account and set the password and user picture.This will protect the kids from going into the parent account.



Create Kids Account

- Create the kid account in the Control Center of parent account.Click on the user drop-down box and select a specific user.
- Choose user information,and set the kid account and password.

Time Management

Enter Control Center of parent account. Two methods are available for time management.

- In Dynamic Time Period:
  Set up the total length of time that allows your kids to use the tablet in a whole day.
  Total using time means the time that allows kids to use the tablet,for example,1:00 for one hour each time.
  Rest of time means the time for kids to have a rest after a certain time period,for example,0:10 for 10 minutes.

- In Static Time Period:
  Choose time period that allows your kids to use the tablet.You can add several time periods.For example,11:00-12:00 and 15:00-16:00 for kids to use the tablet.

Fire Wall

Enter Control Center of parent account. Under the Firewall section,you can set:

- URL filtering:Turn on and add the links.Configure list of websites access to which are denied to kids.

- Keyword Filtering:Turn on and add the words and select OK.Set the keywords and any websites that contain such words will be blocked.

- Application Filtering: Turn on and Choose applications.The website links of these chosen applications will be blocked.

Shielded Application

Enter Control Center of parent account.

- Turn on and choose applications. Applications can be rendered unavailable for your kids in this section.

How to do the System upgrade?

Enter Control Center of parent account.

- In this section, you can set up whether to update automatically or manually by "system upgrade".

How to delete an app from the tablet

- Enter parent account first.
- Go to "Settings"
- Find the app that you want to delete.
- Press the app and choose "uninstall".



How to close the window/apps?

- Press and hold your finger on the App icon.
- Swipe the App icon to close.

How to shift the account user?



From parent account to kid account

- If you're logging in with the parent account,you should press the power button twice and back to the shift interface as shown.Choose kid account.

From kid account to parent account

- If you're logging in with the kid account,you can click "Account shifter"on the right corner of the home screen(shown as the following interface).Choose kid account.

How to create a folder?



- Put your finger on the file.
- Hold your finger on the file and move it to the top of another file to combine these files into a folder.

- You can put any file you want into the folder.

How to remove the file from the folder?



- Put your finger on the file.
- Hold the file and put it outside of the folder.



How to rename the folder?

- Put your finger on the folder icon,and there will come out a dialogue box.Input what you want to rename.-Click the folder icon again to finish renaming.



What is the Cloud Account?

- The cloud account is created by parents to do the cloud control of the tablets. One cloud account can be used to bind and control several devices with different device names.

How to create a Cloud Account?



There're two ways to create a cloud account.

- In the Setup Guide

- In the computer:by visiting the website: http://www.young-cloud.cn/Control/

You can do the registration and sign-up in your PC or other mobile device.By logging in,you can do the remote cloud control of the tablet,whose function includes the log record analysis of the tablet usage,resetting of the kids account information,and remote control of tablet's booting and shut-down.

How to connect the tablet to PC by Cloud Control?

- Go to the Control Center of the tablet.
- Under the parent account,click and turn on the "Cloud service ".Input the cloud account that you have created.In this way,you can connect the tablet to our cloud center.



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.