© 2018 Zeikos, Inc. iHip is a trademark of Zeikos, Inc. iPod, iPhone and iPad are trademarks of Apple Inc., Registered in the U.S. and other countries. The illustrated product and specifications may differ slightly from that supplied. All other trademarks and trade names are those of their respective owners. United States and international patent pending. All Rights Reserved. For ages 12+up. This is not a toy. Designed by iHip, Manufactured in China.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this device.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

One Year Warranty. Customer service: 1-888-934-5675
To activate your product warranty go to our website www.ihip.com & register this product.

Bluetooth

SOUND MACHINE

Bluetooth Speaker

Operating Instructions

Enjoy rich, clear audio from your mobile phone, tablet, or other Bluetooth-enabled device. Portable yet powerful, the iHip Sound Machine gives you a high-quality sound experience while listening to music, movies, and games; as well as a convenient, hands-free way to answer calls.



Charging
Connect to a power source such as a computer via the built-in micro USB port. The red LED light will flash until the charge is complete. turn on and a voice confirmation will sound when the unit is charging. The light will go out and you will hear another voice confirmation when the charge is complete.

Power
Slide the Power button to the ON position. A voice notification will confirm "Power on."

Power button

Pairing with Cell Phone
Turn the unit on. Mobile phone search "ihip soundm" to pair. The blue LED will flash. You will hear voice confirmations for "Bluetooth," "Waiting for pairing," and "Bluetooth connect."

Power button

LED light

Phone Operation
A ringer will sound for an incoming call and music play will be temporarily suspended. Press the Hands Free button (telephone handset icon) to answer and end calls.

To ignore an incoming call, hold down the Hands Free button for a few seconds.

To call back the last incoming number, press the Hands Free button.

Audio Operation
Volume control: Press and hold the V+/Next (⏭) and V-/Prev (⏮) buttons on the top of the unit to adjust volume up or down.

Start/pause music: Press the Play/Pause button.

Skip songs: Press the V+/Next (⏭) and V-/Prev button (⏮) on the top of the unit to advance or backtrack through songs.

Line in: Use the 3.5mm audio input for connection to headphones or other audio output devices.

Mini/micro SD card slot: Listen to audio recorded on a (TransFlash) memory card.

Specifications
Battery: Built-in lithium-ion rechargeable battery, 600 mAh
Battery charge time: 2 hours
Drive Units: 2 x 45mm
Amplifier power: 3w
Frequency response: 150Hz - 20kHz
S/N: >80 dB
Frequency range: 2.402 - 2.480GHz
Transmitter power: -3.38 dBm (Max)
Transmitter modulation: GFSK,π4/-DQPSK
Reception range: 33 ft. (10m)
Working time: >5 hours @ 0.2W
Size: 155 x 47 x 42mm

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by "iHip" is under license. Other trademarks and trade names are those of their respective owners.

FCC Notice:

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

---Reorient or relocate the receiving antenna.
---Increase the separation between the equipment and receiver.
---Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
---Consult the dealer or an experienced radio/TV technician for help.

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF Exposure
The equipment has been evaluated to meet general RF exposure requirement. The device can be used in portable condition without restriction.