MATT BLACK

折页展开尺寸：210mm*285mm

黑色字体采用专色印刷

反面

352mm

S2 WEARABLE BLUETOOTH SPEAKER WITH CALL FUNCTION

QUICK START GUIDE

Welcome to use our product. The following detailed description will help you have a better understanding of our product. In order to use it correctly, please read the instructions carefully before using it.

1. Brief introduction

Anatomy



① USB cap

② MFB

Function		Operation
MFB	Power on	Press and hold the MFB key for 2 seconds.
	Manual shutdown	Press MFB key for 4 seconds.
	Auto shut off	No connection within 5 minutes in standby mode.
Pair	Enter pairing mode	Automatically enter the pairing state after power on.
	Exit pairing mode	No pairing success within 3 minutes.
	Pairing success	Cyclora-S2 shows in the mobile phone Bluetooth menu.
Standby	In the connection	Enter standby mode after the pairing is connected.
	Disconnect	The phone and Bluetooth are out of range.
Re-connect	Automatically reconnect	Press the MFB button for 2 seconds .
	Manually reconnect	click the phone menu to correspond to the Bluetooth device.
Music Player	Play	Press the MFB key to play.
	Pause	Press the MFB button during music playing.
	Skip forward	Press the MFB key 3 times during music playing.
	Skip backward	Press the MFB key 2 times during music playing.
Call Function	Answer	Press MFB once when rings.
	Reject	Press and hold MFB for 2s when rings.
	Hang up	Press MFB during a conversation.
Battery low	Low battery alarm	In every 60 seconds, red light flashes once, along with a "charge me" voice prompt.
	Low battery	The red light turns on till the product shutdowns, and the voice prompts power off.
Charge	Charge	Charge with micro USB cable , red light on during charging
	Full charged	Red light off, blue light on.

2. Instructions

2.1 Power on

Long press the MFB key for 2S, there is a prompt of voice power on, while the blue light flashing three times. Automatic shutdown when no pairing on standby mode, long press the MFB button for 2 seconds, and there is a prompt of voice "power on", while the blue light flashing three times.

2.2 Power off

When power on, long press the MFB key for 4S, and there is a "power off" prompt voice, speaker power off after red light on.
Automatic power off when no paring on standby mode, waiting for 3 minutes, enter into standby mode after no pairing, automatically power off after 2 minutes, there is a "power off" prompt voice, and speaker power off after red light on.

2.3 Pairing

Automatically enter into pairing mode after power on, red and blue lights flashing alternately, voice prompts "pairing".
Enter into standby mode, after 3 minutes without connecting. After 2 minutes, a "power off" prompt voice, red light on.
Select the appropriate device name in the phone's Bluetooth menu: Cyclora-S2 appears when paired with "paired" prompt voice.

2.4 Standby

Enter standby mode after the pairing is connected, and the blue light flashes every 8 seconds. When phones and Bluetooth beyond the effective range there will be a voice prompts:Speakers disconnected, Pairing.

2.5 Re-connect

Bluetooth is active on the phone, long press the MFB button for 2 seconds, speaker will re-connect to the phone automatically when speaker power on and there will be a voice prompt "paired", connected state showing on the phone.
After the mobile phone Bluetooth on / failed re-connect/automatically back even beyond the effective range, click on the menu to correspond mobile phone Bluetooth devices. There will show connected on the phone and voice prompt "paired".

2.6 Music Playing

When standby in music playing mode, press the MFB button to start playing the music in the mobile phone.
Pause music: press the MFB button to pause the current music playing.
Skip backward: press the MFB for 3 times to switch to the backward song.
Skip forward: double-press the MFB key to switch to the next song.

2.7 Call Functions

Press MFB once when rings.

Press and hold MFB for 2s when rings.

Press MFB during a conversation.

2.8 Low Battery

Low battery alarm, In every 60 seconds, red light flashes once, along with a "charge me" voice prompt.

Automatic "power off", the red light turns on till the product shutdowns, and the voice prompts "power off".

2.9 Charge

Charge with micro USB cable , red light on during charging.
When full charged, red light off, blue light on.

3. Security Information

For the sake of your personal and property safety, please read carefully the following safety warnings and reminders, the manufacturer shall not be liable for any loss caused by improper use or misuse of this product.

3.1. Fire and Explosion Hazard

1) Do not drop, disassemble, open, crush, bend, deform, puncture, tear, microwave, fire Burn, smear or insert foreign bodies to the speaker. These actions will result in combustion or explosion;
2) Do not expose the Bluetooth speaker to a very high or very low temperature environment;
3) Do not expose the Bluetooth speaker for a long time under the condition of direct sunlight;
4) Do not put the Bluetooth speakers in the vicinity of the fire, such as stoves, candles or fireplace.

3.2. Battery / Charger Hazards

1) Do not put your Bluetooth speaker into a fire, Battery explosion can cause injury or death;
2) Charge according to the QSG;
3) Do not attempt to disassemble or forcibly open the built-in battery, as this may result in combustion or explosion.

4. Trouble Shooting

4.1 The volume is not big enough.

1) Increase the volume on the phone / Bluetooth speaker;
2) If asked to match the password, please enter "0000";
3) Make sure your phone / Device and Bluetooth speakers are fully charged.

4.2 Voice distorted.

1) Reduce the volume of the phone / Bluetooth speaker;
2) To ensure that the battery of Bluetooth speaker is sufficient, Charge with USB cable if there is a low power prompt.

4.3 Can not paire with Bluetooth device.

1) Make sure your phone is compatible with bluetooth;
2) Re-paire with device (see 2.3).

4.4 Signal is lost or distorted.

1) Move the Bluetooth speaker close to the phone / Device;
2) Make sure your phone / Bluetooth speakers are fully charged;
3) Bluetooth speaker and mobile phone set off, and then restart the boot.

Specification

Bluetooth version:	V4.2
Bluetooth specification:	HFP, A2DP, AVRCP
Working distance:	About 10 meters(straight-line distance without obstacles)
Playing time:	About 10 hours(affected by volume and audio contents)
Battery:	Polymer battery 3.7V
Standby time:	About 100 hours
Button:	MFB X1
LED:	Red & blue LED x1
USB:	Micro USB DC 5V 350mA
Bluetooth device name:	Cyclora-S2
Bluetooth compatibility:	Compatible with Bluetooth v1.1 and above
Size:	82.5*67*32mm
Weight:	76.2g
Waterproof:	IPX4
Speaker:	3W(maximum power)

FCC Part 15.19 Warning Statement

This device complies with part 15 of the FCC rules.Operation is subject to the following two conditions:

(1) This device may not cause harmful interference,and

(2) This device must accept any interference received ,including interference that may cause undesired operation .

FCC Part 15.21 Warning Statement

Note: The grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance .Such modifications could void the user's authority to operate the equipment.

FCC Part 15.105 Warning Statement

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment used in portable exposure condition without restriction.This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

— Reorient or relocate the receiving antenna.

— Increase the separation between the equipment and receiver.

— Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

— Consult the dealer or an experienced radio/TV technician for help.

RF warning statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

210mm

技术要求：
1）尺寸公差请参考右图；
2）不允许有飞边，破损，污点等外观不良
3）材料：70g双胶纸，双面印刷
4）带*作为QC检验尺寸(外尺寸:长宽)
5）单位:mm

角度	±1.5°
>100	±0.20
50-100	±0.15
20-50	±0.10
<20	±0.05
未注尺寸公差	

3			名 称	编 号					
2									
1			S2 说明书	61S200DH00YS000					
更改标记	更改原因	更改前尺寸							
版本号	设计	ztt		投影法	等级	标记	重 量	比 例	
V1.0	工艺							&scale	
	审核		材 料						
日 期	标准化		70g双胶纸，双面印刷	拙雅科技					
20170330	批准								