Tablet PC QQ0801

EN

User Manual

This manual contains important safety precautions and information of correct use. Please be sure to read this manual carefully before use so as to avoid any accidents.

Do not place the product in hot, wet or dusty environment, especially in summer, do not leave the product inside a car with all windows closed.
Avoid dropping, impacting or shaking the product violently, otherwise it may cause damages or malfunctions. Select a proper volume to avoid ear problem when using earphones.
Do not cross the road or drive vehicles, using headphones to avoid traffic accidents.
Be sure to use the provided chargers and accessories in the package.
Be sure to charge the product when the following situations take place,
- The battery icon shows lower or empty.
- System automatically shut down and it turns off soon after restart.
- Operation keys do not respond properly.
- The device shows on the top right corner.

1.Power On/Off

Long press power button to turn on/off the device. It may take a minute to boot the device.
Short press power button to turn on/off the screen.(Standby mode. Refer to 3. below)

2. Desktop

After turning on the device, desktop displays with shortcut icons and arrow panel at the right side


4% 9:19
Google
4K

3. Standby mode(Screen off mode) / Unlock the screen

Short press the power button to turn on/off the screen (standby mode on/off).
After standby mode o , slide the lock icon in order to unlock the screen.


4%
正在充电 (4%)
9:21
5月22日周四

4. System settings

On the desktop, press menu button and select system settings.



Press System Settings

1.Wireless & networks



Wi-Fi – Press Wi-Fi to turn on/off Set up each setting as you like. Wi-Fi settings - Press Wi-Fi settings, then the device
will automatically search the available Wi-Fi signals. Select the network
you want to connect with.

2.Bluetooth



3.Data usage


Settings
WIRELESS & NETWORKS
Wi-Fi
ON
Bluetooth
ON
Data usage
More...
DEVICE
Sound
Display
Storage
Battery
Apps
PERSONAL
Location
Data usage
Data usage cycle 24 Apr - 22 May
15-22 May: about 0.00B used.
No apps used data during this period.

4.More...


Settings
WIRELESS & NETWORKS
Wi-Fi
ON
Bluetooth
ON
Data usage
More...
DEVICE
Sound
Display
Storage
Battery
Apps
PERSONAL
Location
Wireless & networks
Airplane mode
Tethering & portable hotspot
VPN
3G Support Information

5. Sound


Settings
WIRELESS & NETWORKS
Wi-Fi
ON
Bluetooth
ON
Data usage
More...
DEVICE
Sound
Display
Storage
Battery
Apps
PERSONAL
Location
Sound
Volumes
SYSTEM
Default notification sound
Pixie Dust
Touch sounds
Screen lock sound
Vibrate on touch

6. Display

Set up each setting as you like.

7. Storage



Check device memory and microSD card status. Unmount SD card – Unmount the SD card for safe removal.

8. Battery

Check battery usage status.



9. Apps

Manage downloaded or running applications.



Downloaded
All installed application are listing.

10. Location


4% 9:28
Settings
Display
Storage
Battery
Apps
PERSONAL
Location
Security
Language & input
Backup & reset
ACCOUNTS
Add account
SYSTEM
Date & time
Location
Mode
Location off
RECENT LOCATION REQUESTS
No apps have requested location recently
LOCATION SERVICES
Google Location Reporting
Not available in this region

11. Security

Screen lock – Protect your device from unauthorized use by creating a personal screen unlock pattern. Make passwords visible – Show password as you type.

Unknown sources - If you want to allow installation of non-Market Applications,

Press Unknown sources and presses OK.



12. Language&input

Language – Choose your preferable language.
Keyboard & input method – Change keyboard & keyboard settings.
On Language & input settings, if you need other languages besides English on keyboard, press the relevant keyboard and enter the chosen Keyboard settings, select Keyboards, press the language you need.


4% 9:35
Settings
Display
Storage
Battery
Apps
PERSONAL
Location
Security
Language & input
Backup & reset
ACCOUNTS
Add account
SYSTEM
Date & time
Language & input
Language
English (Australia)
Spell checker
Personal dictionary
KEYBOARD & INPUT METHODS
Default
English (US) - Google Keyboard
Google Keyboard
English (US)
Google voice typing
Automatic
SPEECH
Voice Search

13. Backup&reset



14. Add account



15. Date&time


4% 9:36
Settings
Apps
PERSONAL
Location
Security
Language & input
Backup & reset
ACCOUNTS
Add account
SYSTEM
Date & time
Accessibility
Printing
Developer options
Date & time
Automatic date & time
Use network-provided time
Set date
22/05/2014
Set time
9:36 am
Select time zone
GMT+08:00, China Standard Time
Use 24-hour format
1:00 pm
Choose date format
31/12/2014

16. Accessibility



17. printing


7% 11:14
Settings
PERSONAL
Location
Security
Language & input
Backup & reset
ACCOUNTS
Add account
SYSTEM
Date & time
Accessibility
Printing
Developer options
About tablet
Printing
No services installed

18. Developer options


7% 11:15
Settings
ON
PERSONAL
Location
Security
Language & input
Backup & reset
ACCOUNTS
Add account
SYSTEM
Date & time
Accessibility
Printing
Developer options
About tablet
Developer options
Take bug report
Desktop backup password
Desktop full backups aren't currently protected
Stay awake
Screen will never sleep while charging
HDCP checking
Use HDCP checking for DRM content only
Enable Bluetooth HCI snoop log
Capture all bluetooth HCI packets in a file
Process Stats
Geeky stats about running processes
DEBUGGING
USB debugging
Debug mode when USB is connected
Power menu bug reports
Include option in power menu for taking a bug report

19. About tablet



How to connect/disconnect the device with/from the computer

On main desktop, connect the device with the PC,
touch right side of the status bar on the bottom of desktop



Press “USB connected”, select “Turn on USB storage”. The device is recognized at Explorer of the computer. Now you can use it as an external storage.



After finishing your work,

Press “Turn on USB storage”to unmount it.

How to install Applications(.apk file) into the device

Method 1.

1. Connect the device with internet. See above [1.Wireless & networks] in order to connect internet.
2. Run “Getjar” and search the applications you want to install.
3. Follow the instruction on the screen for installation.

Method 2.

1. With your computer, search application file(.apk) that you want to install into the device.
2. Download the file(.apk) into your computer.
3. Connect the device with your computer.
   See above [How to connect/disconnect the device with/from the computer.]
4. Copy and paste .apk file into the device and disconnect it from your computer.
5. Run “File browser” and nd .apk le that was copied into the device.
6. Press the file to install and follow the instruction on the screen.

How to make desktop icons

Press the upper right side icon of desktop, the pop-up displays.





Shortcuts

Long press your desired APK icon and put it on the desktop.



Widgets

Press Widgets and press your desired icon to put it on the desktop.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two

conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

ASA P&E(Shenzhen) Co.,Ltd, declares that this Radio-Frequency peripheral is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.