12.6" x 8.75" x 8"

THE BLACK SERIES™

by shift3®

SUPER GRIP TIRES FOR FAST RACING

AVAILABLE IN 2 FREQUENCIES!

BOX CONTAINS THE FOLLOWING FREQUENCY:

☐ 27 MHz

☐ 49 MHz

Toy RC ATV

SF2014C

BATTERY OPERATED PLAY VEHICLE

AGES 6 AND UP

⚠ WARNING! CHOKING HAZARD - Small parts. not suitable for children under 3 years.

TWO FREQUENCIES FOR COMPETITIVE RACING

REMOVABLE ACTION RIDER WITH COMPLETE ARTICULATION

radio controlled all-terrain vehicle

sport quad

removable articulated racing figure

radio controlled all-terrain vehicle

sport quad

BATTERY INSTALLATION

Operation requires 6 "AA" 1.5V batteries (not included) for ATV and one 9V battery (not included) for radio controller.

- Carefully remove items from package.
- Locate the battery compartment on the underside of the ATV and wireless controller.
- Turn the battery compartment lock on the bottom of the ATV to remove the battery compartment.
- Insert 6 "AA" 1.5V batteries according to the polarity diagram located on the battery tray. (Fig.1)
- Replace the battery compartment.
- Slide open the battery compartment door of the controller. (Fig.2)
- Insert the one 9V battery following the correct polarity.
- Replace the battery compartment door.

NOTE: For best operation, use on a hard surface.

BASIC OPERATION

- Switch both the vehicle and controller power switches to the "ON" position.
- Adjust the steering alignment lever located on the bottom of the vehicle (between front wheels) if the vehicle does not run straight when moving forward.

OPERATING CONTROLS

LEFT JOYSTICK FORWARD & REVERSE

RIGHT JOYSTICK LEFT & RIGHT

OFF/ON SWITCH

KEEP THIS PACKAGE FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.

Made in China