ART DEPARTMENT			
Job # / Filename Product_Id_BS_ToyRCTransformingMissileLauncher_Blk		Product Line Blue Hat / The Company	
Designer Dinh Tran/Nick Kuai/Lone Qin	Brand Manager Lisa Nagamatsu	Finished Size 16" L x 10" H x 10" W / 40.6cm L x 25.4cm H x 25.4cm W	
File Format Illustrator CC 2014/CS6 (CIL)	Fonts Helvetica Neue LT Std, Helvetica Neue Regular, Trade Gothic Bold Condensed No. 20	Colors (Spot or 4C) 4 Color Process	# of Colors 4
Printing Process / Finishing Gloss PP Coating		Comments	

Merchbourne

RADIO CONTROLLED CAR

TRANSFORMING MISSILE LAUNCHER

BLUE HAT

TRANSFORMING MISSILE LAUNCHER

RADIO CONTROLLED CAR

BLUE HAT

BOX CONTAINS THE FOLLOWING FREQUENCY:
☑ 27 MHz
☐ 49 MHz

BATTERY OPERATED PLAY VEHICLE
AGES 6 AND UP
⚠ WARNING! CHOKING HAZARD – Small parts. Not suitable for children under 3 years.

BLUE HAT

CAR TRANSFORMS

WIRELESS RC ACTION!

BLUE HAT

TRANSFORMING MISSILE LAUNCHER

RADIO CONTROLLED CAR

CAR TRANSFORMS

TRANSFORMING MISSILE LAUNCHER

RADIO CONTROLLED CAR

EXCITING RADIO CONTROLLED ACTION

- Includes 10 Safe Suction Darts
- Full Function Wireless Remote Control
- Racer Instantly Transforms Into Missile Launcher

TRANSFORMING MISSILE LAUNCHER

RADIO CONTROLLED CAR

SAFETY PRECAUTIONS

- Do not operate during thunderstorms or rain.
- Avoid water and do not immerse your car.
- Avoid extreme heat and cold and keep your car.
- Never operate your car on the street or highway.
- Never operate your car in a manner that endangers this car.
- Remove all batteries when not in use to avoid accidental operation.
- Never operate your car in a crowded or congested area, out of sight of car people or animals as obstacles.
- Do not charge or bump the objects and the car.
- Keep fingers, hair and loose clothing away from the tires, gears and moving parts to avoid injury.
- Do not leave car or transmitter near sources of heat or water direct sunlight, your car will be damaged.
- Do not leave car or transmitter outside overnight. Dampness is harmful to motor components.

BATTERY INFORMATION

Operation requires 6 "AA" batteries (not included) for car and 2 "AA" battery (not included) for radio controller.

- Open the battery door on the car.
- Refer to the diagram to the right for battery installation. Unscrew the battery door screw on the bottom of the car. Insert the 6 "AA" batteries into the car. Pay attention to the polarity.
- Close and secure battery door. Insert 2 "AA" batteries into the controller. Insert 2 "AA" battery observing the correct polarity. Replace the battery cover and screw tight.





Batteries: 6 "AA" battery (not included)

ATTENTION: PLEASE KEEP THIS INSTRUCTION FOR FUTURE REFERENCE

Thank you for purchasing this battery operated toy car. Please read carefully the following instructions before operating the toy car. Failure to follow these instructions may result in injury or damage to the toy or electrical shock.

BATTERY WARNING:

1. Do not mix old and new batteries.
2. Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
3. Do not short circuit the battery terminals.
4. Do not dismantle or attempt to recharge the batteries.
5. Do not dispose of batteries in fire.
6. Remove batteries from the toy when not in use for a long period of time.
7. Remove batteries from the toy when they are exhausted.
8. Do not leave batteries in the toy when charging.
9. Do not charge non-rechargeable batteries.
10. Remove rechargeable batteries from the toy before charging.
11. Only use batteries of the same or equivalent type as recommended by the manufacturer.
12. Insert batteries with the correct polarity.
13. Remove batteries when they are dead.
14. Do not short circuit the supply terminals of a battery.
15. Do not dispose of batteries in municipal waste. Follow local regulations regarding disposal of batteries.

BY THE TOYSUS TO ATTENTION TO ATTENTION OPERATION OPERATION.

MADE IN CHINA

Made in China

16" L x 10" H x 10" W