

EGTONG 6E


Multipoint Speaker phone User Manual

THANK YOU

Thank you for purchasing the EGTONG 6E Bluetooth® in-car speakerphone. We hope you enjoy it! This instruction manual will get you started and ready to make the most of your in-car speakerphone.

ABOUT YOUR EGTONG 6E

A Answer/end button
B Status light
C Volume control
D Microphone
E On/off switch
F Personal connectivity switch
G Micro USB charging connector
H Magnet bracket
I Integrated Visor Clip
J Speaker



Specifications

- Talk time up to 20 hours/Standby time up to 30 days
- Charging time approximately 2-4 h
- Digital sound enhancement via DSP technology
- Noise cancellation through DSP
- Echo cancellation through DSP
- A2DP (Advanced Audio Distribution Profile) for supporting streaming of wireless music and directions from a GPS app on your phone
- EGTONG 6E Status Light (ready-to-pair, call status, connection status)
- Size: 1198xW57xD15 mm
- Weight 64 grams
- Operating range up to10meters (approximately 33 feet)
- Supported Bluetooth profiles: HFP, HSP, A2DP
- Bluetooth specification version 4.0
- Built-in digital cancellor for enhanced audio quality
- Rechargeable battery with charging option from car charger or USB cable

WHAT YOUR SPEAKERPHONE CAN DO

Your speakerphone can do all this:

- Answer calls
- End calls
- Reject calls
- Voice dialing
- Announce calling number
- Last number redial
- Personal connectivity/speaker switch
- Adjust volume
- Transmit mobile music, pod casts and directions from a GPS app
- Advanced Multiuse – Stay connected to two active Bluetooth devices simultaneously

How to press the buttons

Instruction	Duration of press
Tap	Press briefly
Double Tap	2 quickly repeated taps
Press	Approx. 1-2 seconds
Press and hold	Approx. 6 seconds

What the light means

Status Light	Speakerphone Status
The status light behind the answer/end button flashes in red and blue color	Pairing mode
The status light turns solid blue and goes into standby light mode	Connected
The status light flashes blue every 2" second	Standby Mode
The status light flashes blue every second	Incoming call
The status light turns solid blue	Active call
The status light is flashing red	There is less than 20 min. talk time left.
The status light turns red	The unit is charging

GETTING STARTED

Make sure that your speakerphone is fully charged for two hours before you start using it. Use the USB cable to connect EGTONG 6E to the car charger. Plug the car charger into your car's power outlet. The status light will light up red while charging. When fully charged the status light turns off.



You should follow several steps to connect your mobile phone:

1. Activate Bluetooth from your mobile phone (please refer to your phone's user's manual)

2. Turn on your speakerphone
Press the On/off switch, EGTONG 6E will be ready to pair automatically with status light flashing in red and blue color in turns as well as a voice of "ready to pair".

3. Use your mobile phone to search Bluetooth device with the name of "EGTONG 6E".

4. Your mobile phone will find EGTONG 6E, and will have options to connect or not. Please connect it with the password of "0000" (4 zero). When you successfully connect it, the status light flashes in blue color with a voice of "phone 1 connected".



Conecting with your phone Auto matically

Pairing is only needed the first time a speakerphone and phone are used together. When the speakerphone and phone have been paired once they will automatically connect when the speakerphone is on and Bluetooth® is activated on the phone. The speakerphone registers a list up to 8 mobile phones. The next time you power on, the speakerphone will automatically connect the latest phone that you connected.

Pair the second phone:

The speakerphone has advanced Multiuse, which allows to match two mobile phone at the same time, After the first mobile phone pairing successfully, please turn off the connected mobile phone's Bluetooth function and restart the speakerphone, and then repeat step "3" and "4" to connect the second mobile phone. With successful connection, turn on the first mobile Bluetooth function and restart the speaker phone to get the simultaneously connection to 2 mobiles phones.

Placing speakerphone drive in your vehicle

The speakerphone sits discreetly and conveniently on the sun visor using the integrated magnet metal clip. The product can be easily taken on and off the sun visor. For optimal sound quality, place the speakerphone right in front of you and speak directly into the speakerphone.



Additional features

Play music and GPS directions

Make sure that the speakerphone and mobile phone are connected, When you play music or GPS application directions, the music or GPS application will automatically transfer to your speakerphone. When you have an incoming call, the music or GPS application directions will automatically pause, When the call is ended it will start again.

Easy Voice Guidance

- Easy voice guidance informs you about your connection and low battery status.
- When the speakerphone automatically re-connect to existing mobile phones, you will hear again "phone one connected" or "phone two connected".
- Low battery is announced every 3 min when the speakerphone working time is less than 20 min.
- When there is a incoming call, the speakerphone will announce the incoming call number.

Personal connectivity function

- When there is an incoming call, you can transfer the call to mobile phone via the personal connectivity switch, if press this button again, the incoming call will transfer to speakerphone again.

Dormant automatically

To save power Bluetooth speaker will turn to be dormant state automatically while disconnect bluetooth device after 10 mins. Please activate it by turn it on

How to handle calls from phone

Function	How to perform
Answer or end a call	Tap the answer/end button on your speakerphone to answer or end a call
Make a call	The call will automatically transfer to your speakerphone. If not tap the answer/end button

Function	How to perform
Reject a call	Double tap the answer/end button to reject the incoming call
Redial last number	Double tap the answer/end button when the speakerphone is on and not used
Mute	Long press the volume down button. A sound will indicate that the speakerphone is on mute every 10 seconds until the speakerphone is un-muted
Un-mute	Long press the volume UP button. A short sound will indicate that your speakerphone is connected
Adjust volume	Tap volume + / volume- to adjust the volume level. A short sound will indicate when the volume level is at its highest or lowest limit

Troubleshoot ING & FAQ

I hear crackling noises

Bluetooth is a radio technology, which means it is sensitive to other electronic devices that emit radio signals or connected devices. It is designed for the speakerphone and the connected device to be used within 33 feet (10 meters) of each other, with no major objects in the way (walls, etc.).

I cannot hear anything in my speakerphone

- Increase the volume in the speakerphone.
- Ensure that the speakerphone is paired to a device that is playing.
- Make sure your phone is connected to the speaker phone by tapping the answer/end button.

I am having pairing problems ?

- You may have deleted your speakerphone pairing connection in your mobile phone. Follow the pairing instructions.

Will the speakerphone works with other Bluetooth equipment?

- The speakerphone is designed to work with Bluetooth wireless technology. It is compatible with other devices that are compliant with Bluetooth version 1.2 or higher and support a headset, handsfree and/or advance audio distribution profile.

I cannot use Reject call, call on hold, Redial or voice dialing

- These features are dependent on the ability of your phone to support a handsfree profile. Use of this feature has been tested and verified with most cell phones. Cell phone dialing are optional features which are not supported by all devices. Please consult your device manual for details.

I want to reset the pairing list in my speakerphone

- The speakerphone registers a list of up to 8 mobile phones. To remove the list, you need to reset the speakerphone to default setting by pressing together the "Volume Down" and "Volume Up" buttons for 6 seconds.

Product specifications

Bluetooth Specifications	Version4.0, Class2.10meters
Bluetooth profile supported	HFP, HSP, A2DP
Operating Frequency Band	2.402-2480MHz
Rechargeable Battery	DC3.7V , 650mAH
AC/DC Charger	DC5 to 6V,400mA
Normal Charge time	up to 2.5hrs. (approx)
Talking time	up to 17hrs.
Standby time	up to 1000hrs.
Dimensionm	Bluetooth Speakerphone: 1198×W57×D15 mm
Weight	Bluetooth Speakerphone:64g

Taking care of your speakerphone

- Always store the Speakerphone with the power off and safely protected.
- A void storage at extreme temperatures (above 45°C/113°F – including direct sunlight – or below -10°C/14°F). This can shortain battery life and may affect operation. High temperatures may also degrade performance.
- Do not expose the Speakerphone to rain or other liquids.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.