SENTRY

BC

BT920

ON-THE NECK
WIRELESS EARPHONES

BT920: ON-THE-NECK BLUETOOTH HEADPHONES

1 . Microphone
2 . Device Pairing LED
3 . Volume up / Next Song
4 . Multi Function
5 . Volume down / Last Song
6 . USB Charging Port

Version: Bluetooth 5.0 Playtime: Up to 2 hours at 50% volume

*Actual playback times may vary. Battery performance may be effected by multiple factors including but not limited to ambient temperature, listening volume, and/or distance from source audio device.

Battery Charging: Before use, make sure battery is fully charged.
1. Find the micro USB slot located on the headphones in-line control
2. Plug Micro USB (small) end into the slot, plug the standard USB (large) end into a charging port or computer.
3. When charging is complete, unplug both ends. The headphones are ready for use.

Pairing and Connection:
Before pairing, enable the Bluetooth function of the mobile phone.
1. When pairing, keep the distance between the mobile phone and the headphones within 3.5 feet.
2. Press and hold the Power button for about 5 seconds, and then release it when the red and blue lights alternately blink.
At this time, the headset has entered paring mode.
3. Enable the Bluetooth function of the mobile phone, search the Bluetooth equipment and select "**BT920**." After connection is successful, the blue light of the headset will blink slowly.

For additional information on pairing the earphones to a specific device please refer to your instructions or contact the manufacturer.

Notes:
• If the mobile phone prompts to enter the pairing password, please enter "**0000**" and confirm.
• The pairing mode will be maintained for 5 minutes. If pairing and connection are unsuccessful beyond 2 minutes, the headset will automatically switch to the stand-by mode.
• After pairing is complete, the headset and the handset will remember each other, without pairing.

Key Functions:

On/Off: Press and hold the for 5 seconds to turn on/off.

Music Pause: Press the button to pause playing, and press the again to resume playback.

Volume Increase: Press and hold the button. Volume Reduction: Press and hold the button.

Next Song: Press the button. Previous Song: Press the button.

Answer/Hang-up: Press the button to answer when the call is incoming, and press it again to hang up.

Rejection: Press and hold the button for about 2 seconds, then release it.

Warnings and Precautions:
• CAUTION: To prevent electric shock, use only compatible USB charging devices
• WARNING: To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.
• CAUTION: Use of controls or adjustments or performance of procedures other than those specified may damage your device.
• WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
• WARNING: Always store in a cool dry location.
• WARNING: Headphones are capable of producing sound levels which can be harmful to your hearing. Do not listen at high volume for prolonged periods of time. Headphones may block out surrounding sounds. Never wear headphones while operating a vehicle. Use with caution. User assumes all risks associated with the use of this product.
• WARNING: Don't over insert into ear canal. Discontinue use at the first sign of discomfort. Only use designed pads. Do not use dirty or damaged ear pads. Contains small parts that may present a choking hazard. Keep away from children.

Important Safety Instructions:
1. Read these Instructions.
2. Keep these Instructions.
3. Heed all Warnings.
4. Follow all instructions.
5. Do not use this device near water.
6. Clean only with a dry cloth.
7. Do not block any ventilation openings. Use in accordance with the manufacturer's instructions.
8. Do not charge near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Discontinue use if damaged.
10. Protect the cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the device.
11. Only use attachments/accessories specified by the manufacturer.
12. Unplug this apparatus during lightning storms and when charging is complete.
13. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate or mally, or has been dropped.
14. Headphones are capable of producing sound levels which can be harmful to your hearing. Do not listen at high volume for prolonged periods of time. Headphones may block out surrounding sounds. Never wear headphones while operating a vehicle. Use with caution. User assumes all risks associated with the use of this product.

90-Day Warranty: Sentry warrants this product to be free from defects in materials and workmanship for 90-days from the date of original purchase. This warranty does not pertain to damage resulting from accident, abnormal use, misuse or neglect. Any defective product will be replaced if returned to an authorized Sentry dealer or to Sentry directly at: P.O. Box 885, One Bridge St. Hillburn, NY 10931. Please enclose a check for $5.00 for shipping & handling.

• The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Sentry Industries Inc is under license. Other trademarks and trade names are those of their respective owners.

Sentry Industries inc declares that radio equipment BT920 is in compliance with Directive 2014/53/EU. The EU declaration of confirmity is available at https://sentryindustries.com/european-declaration-of-conformity/

Confirmity with Directives
This product is CE marked to denote conformity with Directives 73/23/EEC (low voltage) and 89/336/EEC (Electromagnetic Compatibility) , as amended.

Environmental Protection
Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.

Supplier's Declaration of Conformity 47 CFR § 2.1077 Compliance Information
Sentry Bluetooth
Responsible Party –
SENTRY INDUSTRIES INC
ONE BRIDGE STREET, HILLBURN, NY 10931 , USA
TEL +1 8457532910

FCC Compliance Statement

"This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation."

FCC ID: 2ACP4LBT1814 Model #BT920

"NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment."

SENTRY

BC

BT920

AURICULARES BLUETOOTH TIPO COLLAR

BT920: AURICULARES BLUETOOTH TIPO COLLAR

1 . Micrófono
2 . LED de emparejamiento de dispositivos
3 . Subir el volumen / Canción siguiente
4 . Multifunción
5 . Bajar el volumen / Última canción
6 . Puerto de carga USB

Carga de batería: Antes de utilizar, asegúrese de que la batería está completamente cargada.
1. Encuentre la ranura de USB micro ubicada en el control en línea de los auriculares.
2. Enchufe el extremo (pequeño) de USB micro en la ranura y enchufe el extremo (grande) de USB estándar en un puerto de carga u ordenador.
3. Una vez completada la carga, desenchufe ambos extremos. Los auriculares están listos para ser utilizados.

Emparejamiento y conexión:
Antes de emparejar, habilite la función Bluetooth del teléfono móvil.
1. Al emparejarlos, mantenga entre el teléfono móvil y los cascos una distancia de máximo 1 m.
2. Apriete y mantenga apretado el botón de encendido durante unos 5 segundos, y suéltelo cuando las luces rojas y azules parpadeen de modo alternado.
En ese momento, los cascos han pasado al modo de emparejamiento.
3. Habilite la función Bluetooth de su teléfono móvil, busque el equipo Bluetooth y seleccione "**BT920.**" Una vez lograda la conexión, la luz azul de los auriculares parpadeará lentamente.

Para información adicional en cuanto a emparejar los auriculares con un dispositivo específico, consulte por favor nuestras instrucciones o póngase en contacto con el fabricante.

Notas:
• Si el teléfono móvil solicita la introducción de la contraseña de emparejamiento, introduzca **"0000"** y confirme.
• El modo de emparejamiento se mantendrá durante 5 minutos. Si emparejamiento y conexión no se consiguen tras 2 minutos, los auriculares pasarán automáticamente al modo de espera.
• Una vez completado el emparejamiento, los auriculares y el teléfono móvil se recordarán mutuamente sin emparejarse.

Funciones clave:

Encendido/Apagado: Apriete y mantenga apretado durante 5 segundos para encender/apagar.

Pausar la música: Apriete para pausar la música, y apriete de nuevo para reanudar la reproducción.

Aumentar el volumen: Apriete y mantega apretado . Disminuir el volumen: Apriete y mantenga apretado .

Canción siguiente: Apriete . Canción anterior: Apriete .

Contestar/Colgar: Apriete para contestar cuando entra una llamada, y vuelva a apretarlo para colgar.

Rechazar: Apriete y mantenga apretado durante unos 2 segundos, y suéltelo a continuación.

Avisos y precauciones:
• PRECAUCIÓN: Para impedir un choque eléctrico, utilice sólo dispositivos de carga USB compatibles.
• AVISO: Para reducir el riesgo de incendio o choque eléctrico, no exponga este aparato a lluvia o humedad.
• PRECAUCIÓN: El uso de controles o ajustes, o la ejecución de procedimientos diferentes de lo especificado puede dañar su dispositivo.
• AVISO: Cambios o modificaciones de esta unidad no aprobadas expresamente por la parte responsable de cumplimiento podrían anular la autorización del usuario para manejar el equipo.
• AVISO: Guardar siempre en una ubicación fresca y seca.
• AVISO: Los auriculares tienen la capacidad de producir niveles de sonido que pueden dañar su oído. No utilice el volumen alto durante periodos de tiempo prolongados. Los auriculares pueden bloquear los sonidos circundantes. No lleve nunca auriculares mientras conduce un vehículo. Utilícelos con cuidado. El usuario asume todos los riesgos asociados con el uso de este producto.
• AVISO: No realice una inserción excesiva en su conducto auditivo. Deje de utilizarlos apenas surja la primera señal de incomodidad. Utilice solo almohadillas diseñadas. No utilice almohadillas sucias o dañadas. Contiene partes pequeñas que pueden suponer peligro de asfixia. Manténgalo alejado de los niños.

Instrucciones de seguridad importantes:
1. Lea estas instrucciones.
2. Conserve estas instrucciones.
3. Tome nota de todos los avisos.
4. Siga todas las instrucciones.
5. No utilice este aparato cerca del agua.
6. Límpielo sólo con un trapo seco.
7. No obstruya ninguna apertura de ventilación. Utilícelas de acuerdo con las instrucciones del fabricante.
8. No lo cargue cerca de fuentes de calor tales como radiadores, calefactores, hornos o otros aparatos (incluidos los amplificadores) que produzcan calor.
9. Interrumpa el uso si está dañado.
10. Proteja el cable de manera que nadie o nada lo pise o lo aplaste, particularmente cerca de las clavijas, tomas de corriente y la parte de la salida del aparato.11. Utilice solo los adjuntos/accesorios especificados por el fabricante.
12. Desenchufe este aparato durante tormentas eléctricas y cuando la carga se haya completado.
13. Toda reparación debe ser realizada por personal cualificado. Las reparaciones son necesarias cuando el aparato haya sufrido cualquier daño, por ejemplo si está dañado el cable de alimentación o el enchufe, si se ha derramado líquido o si ha habido objetos que han caído dentro del aparato, si el aparato ha sido expuesto a lluvia o humedad, si no funciona con normalidad o si se ha dejado caer.
14. Los auriculares tienen la capacidad de producir niveles de sonido que pueden dañar su oído. No utilice el volumen alto durante periodos de tiempo prolongados. Los auriculares pueden bloquear los sonidos circundantes. No lleve nunca auriculares mientras conduce un vehículo. Utilícelos con cuidado. El usuario asume todos los riesgos asociados con el uso de este producto.

Garantía de 90 días: Sentry garantiza que este producto carece de defectos de material y fabricación durante 90 días desde la fecha de la compra original. Esta garantía no responde de daños provocados por accidente, uso anormal, mal uso o negligencia. Cualquier producto defectuoso será reemplazado si se devuelve a un comerciante de Sentry autorizado o directamente a Sentry en: P.O. Box 885, One Bridge St. Hillburn, NY 10931. Adjunte por favor un cheque de $5,00 (USD) por envío y gestión.

Este dispositivo se atiene a la parte 15 de las Normas de la FCC [Comisión Federal de Comunicaciones]. El funcionamiento está sujeto a las dos condiciones siguientes: (1) este dispositivo no puede causar interferencias dañinas, y (2) este dispositivo debe aceptar cualquier interferencia recibida, incluidas las interferencias que puedan causar un funcionamiento indeseado.
FCC ID: 2ACP4LBT1814 Model #BT920

• La marca denominativa y los logotipos de Bluetooth® son marcas registradas propiedad de Bluetooth SIG, Inc. y cualquier uso de tales marcas por parte de Sentry Industries Inc está bajo licencia. Otras marcas registradas y los nombres comerciales son los de sus respectivos dueños.

Las industrias Sentry Inc. declaran que el equipo de radio BT920 cumple con la Directiva 2014/53/EU. La declaración de la UE sobre conformidad está disponible en https://sentryindustries.com/european-declaration-of-conformity/

Conformidad con las directivas
Este producto está marcado CE para indicar conformidad con las Directivas 73/23/EEC (bajo voltaje) y 89/336/EEC (compatibilidad electromagnética), según enmienda.

Protección ambiental
Los productos eléctricos desechables no deben desecharse junto con la basura doméstica. Por favor, recicle dónde existan las instalaciones para ello. Consulte con su autoridad local o minorista para obtener asesoría sobre el reciclaje.