32.2cm W x 22.2cm H x 20cm D



BLUE HAT
TOY COMPANY

SUPER GRIP TIRES
FOR FAST RACING

REMOVABLE ACTION RIDER
WITH COMPLETE ARTICULATION

TWO FREQUENCIES
FOR COMPETITIVE RACING

WIRELESS RC ACTION!

SPORT QUAD

RADIO CONTROLLED ALL-TERRAIN VEHICLE

Toy RC ATV
SF2015C

AGES 6+

BOX CONTAINS THE FOLLOWING FREQUENCY:
☐ 27 MHz
☐ 49 MHz

BATTERY OPERATED PLAY VEHICLE

AGES 6 AND UP

⚠ WARNING!
CHOKING HAZARD -
Small parts. Not suitable for children under 3 years.



Requires 6 "AA" 1.5V batteries (not included) and one 9V battery (not included).

EXCITING 4-WHEELING ACTION!

- *Hyper-Speed Racing On Any Terrain*
- *Oversized Knobby Tires For Gripping Power*
- *Full Function Wireless Remote Control*
- *Bright LED Lights*
- *Available In 2 Frequencies For Competitive Racing*

BATTERY INSTALLATION

KEEP THIS PACKAGE FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION

Operation requires 6 "AA" 1.5V batteries (not included) for ATV and one 9V battery (not included) for radio controller.

- Carefully remove items from package.
- Locate the battery compartment on the underside of the ATV and wireless controller.
- Turn the battery compartment lock on the bottom of the ATV to remove the battery compartment.
- Insert 6 "AA" 1.5V batteries according to the polarity diagram located on the battery tray. (Fig.1)
- Replace the battery compartment.
- Slide open the battery compartment door of the controller. (Fig.2)
- Insert the one 9V battery following the correct polarity.
- Replace the battery compartment door.

NOTE: For best operation, use on a hard surface.

ON/OFF SWITCH
LATCH
6 "AA" BATTERIES (REQUIRES 9 VOLT 1.5V BATTERIES)
Fig.1
STEERING ALIGNMENT LEVER
ON/OFF SWITCH (IS LOCATED ON FRONT OF CONTROLLER)
BATTERY DOOR
RADIO CONTROLLER USES ONE "9V" BATTERY (NOT INCLUDED)
Fig.2

BASIC OPERATION

- Switch both the vehicle and controller power switches to the "ON" position.
- Adjust the steering alignment lever located on the bottom of the vehicle (between front wheels) if the vehicle does not run straight when moving forward.

OPERATING CONTROLS

LEFT JOYSTICK
FORWARD & REVERSE

RIGHT JOYSTICK
LEFT & RIGHT

FULL FUNCTION REMOTE CONTROL

ON/OFF SWITCH

STEERING ALIGNMENT ADJUSTMENT:
To fine-tune the steering control, locate the alignment dial on the back of the controller. Pressing down on the dial in the middle activates the dial. Turning the dial adjust as needed. Should the car pull to the left or right, simply move the dial until your car drives straight without touching the directional controller.

SAFETY WARNINGS - PLEASE READ BEFORE USING PRODUCT

- Not recommended for children under 6 years of age. As with all electrical products, precautions should be observed during handling and use to reduce the risk of electrical shock.
- The remote control unit and all accessories be periodically examined for potential hazards and that any potentially hazardous parts be repaired or replaced.

BATTERY WARNING:

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Insert batteries using the correct polarity. Do not short circuit the supply terminals.
- Remove batteries during long periods of non-use. Batteries can leak chemicals that can cause burns, injury, and/or damage. Do not dispose of batteries in a fire. They may leak or explode.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not recharge, disassemble and dispose of exploded batteries under adult supervision.
- Ensure batteries are inserted correctly.

KEEP THIS PACKAGE FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

©2014 MacAllister, LLC. Blue Hat Toy Company, Blue Hat Toy Company logos are trademarks of PlanoTexas, LLC. All rights reserved.

For technical support, please call Blue Hat Toy Company at 1.800.514.2784.
Or contact us by email at info@bluehattoys.com or call 1.800.514.2784.

Made in China

2933010 (35039)

Blue Hat Toy Company® is the owner of the copyright in and to this work and has licensed it to Blue Hat Toy Company. Unauthorized copying, distribution, adaptation or other use of this work is illegal. Infringers will be prosecuted to the full extent of the law, including the seeking of damages and injunctions. If you have received this work without Blue Hat Toy Company's permission, please notify us immediately at info@bluehattoys.com. Thank you for your assistance in protecting our rights.