ART DEPARTMENT			
Job # / Filename 2017-02-07_SIToyRCMonsterSpinningCar_BlackBlueRed_BlackRed_v2		**Product Line** Sharper Image	**Revision #** 2
Designer Elena McMillin	**Brand Manager** Lisa Nagamoto	**Finished Size** 9.35" L x 7.36" D x 7.68" H / 23.75cm L x 18.7cm D x 19.5cm H	**Today's Date** 02-07-2017
File Format Adobe Illustrator CC (live)/CS2 (OL)	**Fonts** Helvetica, September, Eurostyle, Future Bugler, Trade Gothic, Univers	**Color (Spot or 4C)** 4 Color Process	**# of Colors** 4
Printing Process / Finishing Matte PP Coating		**Comments**	

MerchSource
All copyright, trademark and patent rights or any other intellectual property rights or material associated with the content provided herein, and the selection, coordination and arrangement of such content, are owned exclusively by MERCHSOURCE LLC., or any third-party licensors. The use or misuse of any copyrights, trademarks, patents or any other intellectual property or materials, except as permitted herein, is expressly prohibited. Any infringements shall be prosecuted to the fullest extent of the law, both foreign and domestic.



SHARPER IMAGE®

RC 360° RALLY CAR THUNDER TUMBLER®


BOX CONTAINS THE FOLLOWING FREQUENCY:
☐ 27 MHz
☐ 49 MHz

BATTERY OPERATED PLAY VEHICLE

AGES 6 AND UP

⚠ WARNING!
CHOKING HAZARD -
Small parts. Not suitable for children under 3 years.







OPERATING INSTRUCTIONS

KEEP THIS PACKAGE FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.

Operation requires 4 "AA" 1.5V alkaline batteries (not included) for car and one 9V battery (not included) for remote control.

1. Carefully remove items from package.
2. Turn the battery on/off switch on the back of the car to the battery on position.
3. Swivel latches on bottom of car to release battery pack and insert batteries.
4. Switch on the remote control remote buttons to "ON" position.
5. For best result use the car on hard surfaces such as wood or tile.

REMOTE CONTROL ASSEMBLY

USES ONE 9V BATTERY (NOT INCLUDED)

ON/OFF SWITCH

BATTERY DIAGRAM

ON/OFF SWITCH

BATTERY PACK (USES 4 "AA" BATTERIES NOT INCLUDED)

USE ALKALINE BATTERIES FOR BEST PERFORMANCE

GENERAL CONTROLS

ACTION BUTTON

Forward
Press both control sticks forward.

Reverse
Press both control sticks backward.

Spinning Action
Press and hold the control sticks in opposite directions to make the car spin.

Action Button
Press and hold the action button to have the car stand up on its back wheels and move forward.

SPINNING ON REAR WHEEL (ACTION BUTTON)

1) Spin the car by pressing and holding the control sticks in opposite directions.

2) Press and hold the action button while the car is spinning.

SAFETY PRECAUTIONS

- Do not operate during thunderstorms or rain.
- Avoid water and sand areas while operating car.
- Never operate your car on the street or highway.
- Never operate your car in a confined or crowded area, and do not use people or animals as obstacles.
- Do not run your car on surfaces or load surfaces, as this will cause damage to your car.
- Keep fingers, hair and loose clothing away from the tires, gears and motor while the car is operating.
- Do not store car or transmitter near sources of heat or under direct sunlight for extended periods of time.
- Do not store car or transmitter outside overnight. Dampness is harmful to interior components.
- Use only fresh batteries. Mixed old and new batteries may cause leakage.
- Adult supervision is recommended when operating this car.

BATTERY WARNING:

- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Do not mix old batteries with new batteries. Always purchase batteries by the battery type number and expiration date printed on the battery package. Always check the battery package before purchasing to be sure you are getting the battery type and quality you need.
- Do not mix batteries from different manufacturers or of different capacity ratings.
- Do not short circuit the battery terminals.
- Do not charge non-rechargeable batteries.
- Remove exhausted batteries from the product.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Batteries are harmful if swallowed. Keep batteries away from children.

KEEP THIS PACKAGE FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.

Colors and styles may vary.
Product specifications in this literature may not represent exactly the item's appearance or performance. If you have any questions or concerns about the product, please call our Consumer Relations Department at 1.800.344.4444 or visit us at www.sharperimage.com.

©2017 Sharper Image. Sharper Image® name and logo are registered trademarks. All rights reserved.
©2016 MerchSource, LLC. Thunder Tumbler and the fifth wheel design are both owned by MerchSource, LLC. All rights reserved.
Distributed by MerchSource, LLC, Irvine, CA 92618.
Patent Pending
Drive Patent No. ZL201250226060.1

SHARPER IMAGE®

Try a RC Monster Spinning Car

1002392 (2340077)

0 84202 32588 9

Made in China