BATTERY INFORMATION

1. Install only new batteries of the same type in your product.
2. Failure to insert batteries in the correct polarity, as indicated in the battery compartment, may shorten the life of the batteries or cause batteries to leak.
3. Do not mix old and new batteries.
4. Do not mix Alkaline, Standard (Carbon-Zinc) or Rechargeable (Nickel Cadmium or Nickel Metal Hydride) batteries.
5. Do not dispose of batteries in fire.

Batteries should be recycled or disposed of as per state and local guidelines.

FCC INFORMATION FCC ID – 2AE3ABTM023PC

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1) This device may not cause harmful interference, and

2) This device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

1) This device may not cause harmful interference.
2) This device must accept any interference received including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

1) l'appareil ne doit pas produire de brouillage;
2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

ONE (1) YEAR LIMITED WARRANTY

The manufacturer warrants this product to be free from defects in functionality, materials and workmanship for a period of one (1) year from the date of purchase. This warranty applies only to the original consumer purchaser and only to products used in normal use and service. If this product is found to be defective, the manufacturer's only obligation, and your exclusive remedy, is the repair or replacement of the product at the manufacturer's discretion, provided that the product has not been damaged through misuse, abuse, accident, modifications, alterations, neglect or mishandling. This warranty shall not apply to any product that is found to have been improperly installed, set up, or used in any way not in accordance with the instructions supplied with the product. This warranty shall not apply to a failure of the product as a result of an accident, misuse, abuse, negligence, alteration, faulty installation, or any other failure not relating to faulty material or workmanship. This warranty shall not apply to the finish on any portion of the product, such as surface and/or weathering, as this is considered normal wear and tear. **The manufacturer does not warrant and specifically disclaims any warranty, whether expressed or implied, of fitness for a particular purpose, other than the warranty contained herein. The manufacturer specifically disclaims any liability and shall not be liable for any consequential or incidental loss of damage, including any labor/expense costs involved in the replacement or repair of said product.**
For warranty claims, please contact Perfect Company at support@perfectbakeapp.com, (360) 524-3001, or write to Perfect Bake Support, 705 Main Street, Suite 201, Vancouver, WA 98660.

Perfect COMPANY

Version 3.1

Perfect Bake® 2.0

SMART SCALE AND INTERACTIVE RECIPE APP



DOWNLOAD FREE APP

For help please go to:
www.perfectbakeapp.com/support
Also visit the "Help" section of the Perfect Bake app for detailed instructions and tutorials.

CONTROL LAYOUT



1. **TIMER Button**
   Press to start and stop in-app timers.
2. **OFF/DOWN Button**
   Hold for 4 seconds to turn off the scale. When connected to the app, use to select the previous recipe block.
3. **BLUETOOTH INDICATOR LED**
   Blinks to indicate the scale is available for the app to connect. Remains on when a connection has been made. If no connection is made within 3 minutes the scale will turn off to save power.
4. **ON/UP Button**
   Press to turn on the scale. When connected to the app, use to select the next recipe block or manually advance.
5. **BLUETOOTH Button**
   Press to disconnect the scale from your smart device and begin looking for a connection. (Note: Bluetooth turns on automatically when the scale is turned on.)

CARE

CLEANING – Never immerse the scale in water; simply wipe it with a damp cloth. The scale is not dishwasher safe.

STORAGE – Do not place heavy objects on top of the scale during storage. Doing so may affect the accuracy of the scale.

BOWLS – The bowls are dishwasher, freezer, and microwave safe.

STATIC – In an environment with electrostatic discharge, the product may malfunction. In this case, please remove the batteries and wait for 5 minutes and then replace the batteries.

SPECIFICATIONS

Batteries.....2 x 1.5V AAA/LR03
Maximum Weight Capacity.....5000 grams/11 lbs
Bluetooth Range.....50 feet*

*Depends on connected mobile device and other devices nearby that may cause interference

Weight Resolution.....0.5 g

SETUP AND USE

INSERT THE BATTERIES

The battery compartment is on the bottom of the scale. Remove the battery door and insert 2 x 1.5v AAA/LR03 batteries (not included). Replace the battery door.



AUTO SHUT-OFF

If not connected to the app, the scale will turn off automatically after 3 minutes.

SYSTEM REQUIREMENTS

- iOS 6 or higher
- Android 4.3 or higher

Go to *http://www.perfectbakeapp.com* for the latest list of compatible devices.

CONNECTING THE SCALE TO PERFECT BAKE® APP

Available on the App Store | ANDROID APP ON Google play | amazon apps Available at amazon

DOWNLOAD THE FREE PERFECT BAKE® APP

Go to the iTunes* App Store* (for Apple devices), Google Play* (for Android), or Amazon Appstore (for Kindle) to download the Perfect Bake app.

*iPad, iPhone, iPod touch, and iTunes are registered trademarks of Apple Inc.
App Store is a service mark of Apple Inc.
Android and Google Play are trademarks of Google, Inc.
Perfect Bake is a registered trademark of Perfect Company.

CONNECT THE SCALE TO PERFECT BAKE APP

The Perfect Bake 2.0 Scale uses Bluetooth Smart to connect to the Perfect Bake app on your smart phone or tablet. To connect the scale to your device:

1. Make sure your smart device has Bluetooth turned on.
2. Start the Perfect Bake app.
3. From the Main Menu, select *Settings*.
4. Turn on the scale.
5. In the app *Perfect Bake 2.0* will appear in the *Bluetooth Scales* list. Select it to connect.
6. When the BLUETOOTH INDICATOR LED stops blinking and the app shows a check mark next to *Perfect Bake 2.0*, the scale is connected.

The Perfect Bake app will remember the last scale it connected to and attempt to reconnect to it the next time you start the app.

TO DISCONNECT THE SCALE FROM THE APP

1. From the main menu, touch *Settings* and then touch *Perfect Bake 2.0* in the *Bluetooth Scales* list.
2. Alternatively: Press the BLUETOOTH button on the scale for 3 seconds.

The scale will be unchecked in the *Bluetooth Scales* list in the app and the BLUETOOTH INDICATOR LED will begin blinking to indicate that it is available for connection to another device.

USING THE SCALE FOR BASIC WEIGHING

To use the scale to measure weight of an item without selecting a recipe

1. Launch the Perfect Bake app.
2. From the Main Menu, select *Scale*.
3. Put the item on the scale. The app displays the weight.

BATTERY INFORMATION

1. Install only new batteries of the same type in your product.
2. Failure to insert batteries in the correct polarity, as indicated in the battery compartment, may shorten the life of the batteries or cause batteries to leak.
3. Do not mix old and new batteries.
4. Do not mix Alkaline, Standard (Carbon-Zinc) or Rechargeable (Nickel Cadmium or Nickel Metal Hydride) batteries.
5. Do not dispose of batteries in fire.

Batteries should be recycled or disposed of as per state and local guidelines.

FCC INFORMATION FCC ID – 2AE3ABTM023PC
This device complies with Part 15 of the FCC Rules.
Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received including interference that may cause undesired operation.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:
(1) This device may not cause interference; and
(2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :
1) l'appareil ne doit pas produire de brouillage;
2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

ONE (1) YEAR LIMITED WARRANTY

The manufacturer warrants this product to be free from defects in functionality, materials and workmanship for a period of one (1) year from the date of purchase. This warranty applies only to the original consumer purchaser and only to products used in normal use and service. If this product is found to be defective, the manufacturer's only obligation, and your exclusive remedy, is the repair or replacement of the product at the manufacturer's discretion, provided that the product has not been damaged through misuse, abuse, accident, modifications, alterations, neglect or mishandling. This warranty shall not apply to any product that is found to have been improperly installed, set up, or used in any way not in accordance with the instructions supplied with the product. This warranty shall not apply to a failure of the product as a result of an accident, misuse, abuse, negligence, alteration, faulty installation, or any other failure not relating to faulty material or workmanship. This warranty shall not apply to the finish on any portion of the product, such as surface and/or weathering, as this is considered normal wear and tear. **The manufacturer does not warrant and specifically disclaims any warranty, whether expressed or implied, of fitness for a particular purpose, other than the warranty contained herein. The manufacturer specifically disclaims any liability and shall not be liable for any consequential or incidental loss of damage, including any labor/expense costs involved in the replacement or repair of said product.**
For warranty claims, please contact Perfect Company at support@perfectdrinkapp.com, (360) 524-3001, or write to Perfect Drink Support, 705 Main Street, Suite 201, Vancouver, WA 98660.

Perfect
COMPANY

RoHS Compliant

Version 2

Perfect Drink® 2.0

SMART SCALE AND INTERACTIVE RECIPE APP



DOWNLOAD
FREE APP

For help please go to:
www.perfectdrinkapp.com/support
Also visit the "Help" section of the Perfect Drink app for detailed instructions and tutorials.

CONTROL LAYOUT



1. **TIMER Button**
   Press to start and stop in-app timers.
2. **OFF/DOWN Button**
   Hold for 4 seconds to turn off the scale. When connected to the app, use to select the previous recipe block.
3. **BLUETOOTH INDICATOR LED**
   Blinks to indicate the scale is available for the app to connect. Remains on when a connection has been made. If no connection is made within 3 minutes the scale will turn off to save power.
4. **ON/UP Button**
   Press to turn on the scale. When connected to the app, use to select the next recipe block or manually advance.
5. **BLUETOOTH Button**
   Press to disconnect the scale from your smart device and begin looking for a connection. (Note: Bluetooth turns on automatically when the scale is turned on.)

CARE

CLEANING – Never immerse the scale in water; simply wipe it with a damp cloth. The scale is not dishwasher safe.

STORAGE – Do not place heavy objects on top of the scale during storage. Doing so may affect the accuracy of the scale.

STATIC – In an environment with electrostatic discharge, the product may malfunction. In this case, please remove the batteries and wait for 5 minutes and then replace the batteries.

SPECIFICATIONS

Batteries ..... 2 x 1.5V AAA/LR03
Maximum Weight Capacity ..... 5000 grams/11 lbs
Bluetooth Range ..... 50 feet*

*Depends on connected mobile device and other devices nearby that may cause interference

Weight Resolution ..... 0.5 g

SETUP AND USE

INSERT THE BATTERIES

The battery compartment is on the bottom of the scale. Remove the battery door and insert 2 x 1.5v AAA/LR03 batteries (not included). Replace the battery door.



AUTO SHUT-OFF

If not connected to the app, the scale will turn off automatically after 3 minutes.

SYSTEM REQUIREMENTS

- iOS 6 or higher
- Android 4.3 or higher

Go to *http://www.perfectdrinkapp.com* for the latest list of compatible devices.

CONNECTING THE SCALE TO PERFECT DRINK® APP

Available on the App Store | ANDROID APP ON Google play | amazon apps Available at amazon

DOWNLOAD THE FREE PERFECT DRINK® APP

Go to the iTunes* App Store* (for Apple devices), Google Play* (for Android), or Amazon Appstore (for Kindle) to download the Perfect Drink app.

*iPad, iPhone, iPod touch, and iTunes are registered trademarks of Apple Inc.
App Store is a service mark of Apple Inc.
Android and Google Play are trademarks of Google, Inc.
Perfect Drink is a registered trademark of Perfect Company.

CONNECT THE SCALE TO PERFECT DRINK APP

The Perfect Drink 2.0 Scale uses Bluetooth Smart to connect to the Perfect Drink app on your smart phone or tablet. To connect the scale to your device:

1. Make sure your smart device has Bluetooth turned on.
2. Start the Perfect Drink app.
3. From the Main Menu, select *Settings*.
4. Turn on the scale.
5. In the app *Perfect Drink 2.0* will appear in the *Bluetooth Scales* list. Select it to connect.
6. When the BLUETOOTH INDICATOR LED stops blinking and the app shows a check mark next to *Perfect Drink 2.0*, the scale is connected.

The Perfect Drink app will remember the last scale it connected to and attempt to reconnect to it the next time you start the app.

TO DISCONNECT THE SCALE FROM THE APP

1. From the main menu, touch *Settings* and then touch *Perfect Drink 2.0* in the *Bluetooth Scales* list.
2. Alternatively: Press the BLUETOOTH button on the scale for 3 seconds.

The scale will be unchecked in the *Bluetooth Scales* list in the app and the BLUETOOTH INDICATOR LED will begin blinking to indicate that it is available for connection to another device.

USING THE SCALE FOR BASIC WEIGHING

To use the scale to measure weight of an item without selecting a recipe

1. Launch the Perfect Drink app.
2. From the Main Menu, select *Scale*.
3. Put the item on the scale. The app displays the weight.