iDance®

www.idanceaudio.com

ACDC CLASSIC 2

Wireless Classic Vintage Speaker

User Manual

WORLD HEADQUARTERS:
iDance H.K.
Unit i, 6/F., MG Tower,
133 Hoi Bun Road, Kwun Tong,
Kowloon, Hong Kong.

UK OFFICE:
iDance Audio U.K.
Graham Lloyd Building, Midland
Structures Industrial Estate
Ampthill Road, Bedford MK42 9JJ,
United Kingdom

EUROPE OFFICE:
iDance Audio Europe
Gaasterland 2c
1948RG Beverwijk
The Netherlands

This product meets the essential requirements of Directive 1999/5/EC.
http://www.idanceaudio.com/documentation/declarationofconformity/

©2017 Leidseplein Presse B.V. Under License to Perryscope Productions / Epic Rights

CE

Company name: First Audio Manufacturing(Guangzhou)Ltd.

Product name: Wireless Classic Vintage Speaker

Item Number: Classic 2

Hereby, [First Audio Manufacturing(Guangzhou)Ltd.], declares that this[Wireless Classic Vintage Speaker] is in compliance with the essentialrequirements and other relevant provisions of Directive 2014/53/EU.A copy of the full Doc is attached.The declaration of conformity may be consult at Imports/ manufacture.

Name: First Audio Manufacturing (HK)Ltd.

Imports/ manufacture Address: 3/F.,Block A ,wing Kut Industrial Bldg., 608C astle peak Road HK.

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions,may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on,the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

FCC NOTICE

This device complies with Part 15 of the FCC rules.Operation is subject to the following two conditions:

(1) This device may not cause harmful interference; and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC CAUTION

caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

WARNING

WARNING: TO REDUCE THE RISK OF FIRE OR SHOCK, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE

CAUTION

RISK OF ELECTRIC SHOCK
DO NOT OPEN

CAUTION: TO REDUCE THE RISK OF FIRE OR SHOCK, DO NOT REMOVE COVER OR BACK. NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED PERSONNEL

Caution: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.

Class II equipment symbol
This symbol indicates that the unit has a double system.

The exclamation mark inside an equilateral triangle is intended to alert user of the presence of the important operating and maintenance (servicing) instructions in the literature accompanying the product.

The lightning flash with arrowhead symbol inside an equilateral triangle is intended to alert User of the presence of un-insulated "hazardous voltage" within the product's enclosure, which may be of sufficient magnitude to induce a risk of electric shock to persons

NOTES:
Please do not attempt to open the back cover or power adapter as opening or removing the covers may expose you to dangerous voltage or other hazards, and it will also cause the restricted servicing to be disabled: There are no user servicing components inside.

NOTES:
This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus as set out in the Radio Interference Regulations of Industry Canada. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

NOTES:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for assistance.

IMPORTANT SAFETY INSTRUCTIONS

1. Read these instructions.
2. Keep these instructions. Heed all warnings.
3. Follow all instructions.
4. Do not use this apparatus near water.
5. Clean only with dry cloth.
6. Do not block any ventilation openings.
7. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacture, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over. Portable Cart Warning
13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture does not operate normally, or has been dropped.
15. The apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.
16. The battery shall not be exposed to excessive heat such as sunshine, fire or the like.

FEATURES

1. Bluetooth streaming audio with smartphone / tablet
2. Built-in rechargeable batteries for up to 4-hour use
3. USB MP3 player for music playback, supporting MP3 and WMA
4. 3.5mm LINE input for external audio source
5. 2x 3.5” full range speaker
6. Integrated handle for easy carrying

FUNCTION DESCRIPTION



1. AUX IN:3.5mm Line Input
2. TONE CONTROL:
   Clockwise rotation to reduce bass (max.-15dB@100Hz);
   Counter rotation to reduce treble (max.-15dB@10kHz);
3. ⏻ Power ON/OFF button
4. POWER indicator: When unit is on, LED displays in Green.
5. USB input socket: Insert your USB thumb for MP3/WMA playback.
6. Bluetooth: When LED is flashing in blue, Bluetooth is available for connection; when LED display stops flashing, Bluetooth is successfully connected.
7. ▶II At USB/BT mode, press ▶II to play or pause music. Under Bluetooth mode, press ▶II for seconds to reset Bluetooth pairing.
8. MASTER VOL: Turn to adjust the master volume.
9. DC IN charging:5V/1A Micro USB
10. MODE: Press the button MODE to select BT/USB/AUX play
    (Remark: When unit is on, the default mode is Bluetooth play; USB selection should be with USB insert, otherwise only BT/AUX)
11. Charging and Battery LED: shows the charging or battery indicator. Green LED flashing= charging; Green LED stop flashing= fully charged; Red LED= low battery
12. USB/AUX Indicator: shows the USB or AUX play mode. Red LED flashing=USB mode; Red LED stop flashing= AUX mode
13. I◀◀/▶▶I : Button PREVIOUS/NEXT (for Bluetooth and MP3 only)
    Short press to play next song and long press (2 seconds) for play previous song.

Connecting Bluetooth Wireless

- Keep the Classic 2 in 3 feet distance to your device
- Turn ON Classic 2 to enter wireless mode
- Turn ON Bluetooth connectivity on your mobile device
- Search the Bluetooth device with name “Classic 2” and connect*
- Once connection established, Classic 2 will prompt

** In case no “Classic 2” is found or the Classic 2 is automatically connected to another device, please press and hold “>||” button to enter pairing mode*

SPECIFICATIONS

Speaker Unit	2x 3.5”full range,4Ω
Power Supply	DC 5V 1A charging
Power Consumption	
Standby	<0.5W
Maximum	16W
Rated Output Power	4Wx2
Maximum Output Power	4.5Wx2
Rechargeable Battery	Li-ion battery, 3.7V 4400mAH
Distortion	≤0.5%
S/N Ratio	≥ 75dB
Frequency Response	50Hz ~ 20kHz
Input Sensitivity	
Bluetooth	-4dB
MP3	-4dB
LINE INPUT	600mV
Maximum Input Voltage	
LINE INPUT	1V
Unit Dimensions (WxDxH)	247x140x159mm
Net Weight	1.7kg

Disposal of Old Electrical & Electronic Equipment
(Applicablein the European Union and other European countries with separate collection systems).

This symbol on the product or on its packaging indicates that this product shall not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. The recycling of materials will help to conserve natural resources. For more detailed information about recycling of this product, please contact your local Civic office, your household waste disposal service or the shop where you purchased the product.