Android Platform to introduce and use of guidance

SMART PHONE

Cool 2

May 2, 2015

Version 4.4.2

CONTENTS

How Introduction 5
Introduction phone keys 5
Introduction widgets 5
Information Function 5
Call History Features 11
Dail and caller ID display Features 12
Paste the text / copy Features 13
E-mail Features 13
Desktop Features 15
Wifi Features 21
Flight mode Function 21
Black unlock 22
Restore to factory default 23
Storage Settings 24
English language switching phone 24
Replacement mobile phone input method 25
Android phone data cable links 26
Introduce cross-screen display 27
Browser Features 27
Q/A 29
1. How to turn off the software running in the background too much 29
2. How to quickly set up Email 29
3. How do I view the capacity of SD card case 29
4. How to save electricity crown. 30
5. How crown lock screen, to prevent others from using 30
6. Why does not the USB data cable links your computer 30
7. How to install a program on a non-Android Market 30
8. In browsing the web or other applications, how to switch to other applications 30
9. How to enter the silent mode quickly 31
10. How to forward SMS / MMS 31
11. how to paste and copy text 31
12. In the phone program group is installed too many applications, how to solve 31
13. Contacts are sorted, can change 31
14. Contacts whether to support the group 31
15. contacts and SMS storage capacity limits the number of 32
16. How to set the SD card, personalized ring tones 32
17. How to sync the phone contacts to the original crown 32
18. How to use the crown access Wifi (WLAN) 32
19. How to Find Contact 32
20. how to download applications for the crown 32
21. What are commonly used android forum 33
22. How do I delete the downloaded software 33
23. How to view mobile phone version information 33

24. How do I copy SIM card contact information 33
25. why the message has a different time and date display 33
26.crown whether to support the Java..... 34

Basic terms

Root：Super Android system is the administrator user account, which has the authority to control the whole system, and only have the privileges to the original system can be refreshed for the revision of the various systems;

APK：Android application types, with the cab and the Windows Mobile platform, like exe files, the user can be installed directly;

Eclari：The name of one of the Android platform, version, and the corresponding version number is 4.2, Crown use this version;

Webkit：Core Android platform, browser, and now Apple's Safari, Google's Chrome and FireFox are using this kernel as a web page rendering mechanism;

GPhone：To use Google Android mobile phone operating system developed collectively, crown, etc.;

ActiveSync：Push email solution to support Microsoft proprietary technology, pre-primary mailbox servers at Microsoft (Exchange server) to provide support, and now Google's Gmail also provided support

G-Sensor：Is the acceleration sensors for mobile phones can provide the direction of gravity sensors, which begin with the letter G represents the gravity, the latter Snesor meant to represent the sensor

How Introduction

Introduction phone keys

Menu button: Click on the program display the corresponding menu item, the user can choose the corresponding sub-menu functions;
Home button: Click on the background into the current application will, and enter the main interface; Note that using this key will not really exit the application, the application will continue to run in the background;
Back button: Click to fall back to previous step of the operation of the interface;

Introduction widgets

1, long press the space of the idle -choose widgets ,add widgets to the main screen: in the widgets interface - > Long press a widget can add to the main screen
2, change the position of widgets: in the main interface, Long press a widget, sliding the widget can change the position of the widget in the main screen
3. Delete widgets: in the main interface, Long press a widget, the top of the main screen will be delete ", sliding the widget to delete , when there is red ", can let go, the widget is deleted





Information Function

To sort the information by contacts, the conversational arrangement, user understanding of the history of the entire communication information, information sorted according to first contacts, including contact name for the first numbers, then letters（A-Z）



Send MMS

New information -"click , add "function - " to select the desired additional content;

New information-click the menu button -add theme





Replacement SMS reminder tone

Access to the information interface - "click the menu button, select "Settings "function ,select "Notifications "function ,Select "Ringtone"function;





View the sender information

Access to the information screen - "Select the message - " click - "click ,can view the sender information"-"click ,canadd to favorites"





Forwards

Access to the information screen - "Select the message - "short press the message can display the message details" -Long press the Information, there shortcut keys - "select"Forward "function







View information details

Access to the information screen- "Select the message-" Long press the Information, there shortcut keys -"select View details "function



Delete information session specific information on a particular

Access to the information screen - "Select the message - " Long press and Information, there shortcut keys - "select "Delete "function





Contact Features

contacts groups, contacts and favorites feature;

Book description

By the first number, then sort the way English characters （A-Z）



Favorites Introduction

Included collection of contacts, and users often call the recent contact information, part of the overall fabric Top of the contact information for the user collection, lower often call into the system default contact information;



Contact Search

Into the contact interface - "click button

Search supported by the first letter and the entire search string



Import contact information methods
using Bluetooth to achieve data synchronization
Andy 5EI phone and the original binding, using Bluetooth to achieve synchronization of contacts;

Call History Features

One by one to delete call records

Enter the call log interface - "Click the menu button –Select the delete Function- " Choose the delete call records- click ok button-"Click , choose the resources of the sim card"



Contact information stored call records

Enter the call log screen - "Select the Save call log - " click- "select "Add to Contacts "feature

Or directly into the call log entry, -click button -select "Add to Contacts "feature



Dail and caller ID display Features

New dial-up procedures will be according to your habits, automatic intelligent recommend commonly used contact, convenient to speed dial,Some well-known enterprises or service of the number of the caller, using Google's online database for matching automatically display name.



Paste the text / copy Features

Into the input field - "input string, long press and enter the region, there shortcut keys - " select All " " cut All " ,"copy All","paste All"



E-mail Features

Configuring mail account
Enter the Program Group screen - "Select"Email"application -"Enter e-mail address and password
If the system automatically recognizes the mailbox information, will automatically configure; if the system does not recognize, will require users to type IMAP mailbox, or POP3, enter the appropriate configuration information.

For example:
E-mail Address: 936877975@qq.com
Password:
Configure multiple email accounts
Enter the Program Group screen - "Select"Email"application -" Click on the menu button-select setting function -select "Add Account"feature



Delete email account

Enter the Program Group screen - "Select"Email"application - Click on the menu button-select setting function –select account - " select the "Remove Account"function



Email check frequency setting

Enter the Program Group screen - "Select"Email"application - Click on the menu button-select setting function –select account - " select I box check frequency "function



Desktop Features

The common features into the desktop
Interface into the program group - "Select the desktop into the application -"long by application, the application will be placed to the desktop;



New lock screen and color schemes Function

Blue/green color design has changed into white/gray, more simple, the other ICONS style also further flattening,Also joined the translucent interface style, to ensure the status bar and the

navigation bar can play better effect in application.



Wallpapers

In the desktop space - the "long Click the desktop, the shortcut keys -"Select"Wallpaper"feature.





Application Packet

In the desktop space – sliding the application to another application – click the application to open New Folder





Change the folder name

Open the folder on the desktop - " click Input box - Rename Folder



Add contacts to your desktop

In the widgets space -long press the contact widget -" choose a contact





Add URL to the desktop

In the widgets space -long press the Bookmark widget -" choose a bookmark





Add a playlist to your desktop

In the widgets space -long press the Music playlist widget -" Select a playlist (operation method and procedure as above)



Delete the contents of the desktop

Select the desktop content - then "Long press the icon - " into the remove icon to the lower right corner of the screen



Full Screen Function

Whether you are looking at the books, or use any application, you can easily into the full screen mode



Wireless Printing Function

You can use Google Cloud Print to Print the photos, documents, or web pages.”gallery-choose one picture -menu-print-set a google account -choose print /save as PDF”





Bluetooth Function

Select "Settings" -" Select "Bluetooth"function





Wifi Features

Select "Settings"-"Select Wi-Fi"- select "Add NETWORK ", select the desired access APN



Flight mode Function

Select "Settings"-"Select More"-" choose "Airplane Mode"function



Or select the phone, "Off"button - "select the"Flight Mode "function



Black unlock

Select "Settings"-"Select " security "-" Select the " Screen lock"-Pattern







Restore to factory default

Select "Settings"-"Select"Backup&reset "-" select "Factory data reset"





Storage Settings

Select "Settings"-"Select"storage"



English language switching phone

Select "Settings"- "Language & input "-" Select " Language ", select English or other





Input set

Select "Settings"- " Language & input "-click button



Replacement mobile phone input method

Select "Settings"- " Language & input "-Default



Android phone data cable links

Select "Settings"-"Select"Developer options"-"Check"USB debugging "
Products installed on your computer drive, the link on the USB cable;



Introduce cross-screen display

Select "Settings"-""Display "-"Check"Auto- rotate screen, " according to the phone automatically change the direction of rotation



Browser Features

Visit the website

Browser - "Click url input area "-" Enter the URL of web browsing-click button

Download Web page images or other objects

Browser - "browse the web, long press on the picture, there shortcut keys, choose "Save Image "function



Browser settings / search page

Browser - "browse the web -"click "menu button",-select settings / find in page



Q/A

1. How to turn off the software running in the background too much

Download Advanced Task Manager Advanced Task Manager and select install, it can help you achieve, automatic end of the program services, to switch between programs, display memory information, exclusion list, an end of all widgets, fast uninstall program and other functions, To free up memory space, reducing the CPU's operation long pressure, increase speed, to extend the purpose of standby time.

2. How to quickly set up Email

In the Android system, can automatically set the POP3 or IMAP e-mail most accounts, the e-mail application, directly enter the e-mail address and password, if not automatically fit in the mailbox, the mailbox will be required by user Server information. See details in front of the "E-mail Features"section.

3. How do I view the capacity of SD card case

Select the "Settings"-Select Storage -select "SD card and phone memory", will see the current SD card capacity information phone

4. How to save electricity crown.

First, reduce the screen brightness can be used in peacetime by reducing the brightness to reduce battery consumption, in the "Settings " in the "sound and display" found on "brightness", and then sliding scale in respect of the brightness can be set Android phones;
Close GPS global positioning, in the "Settings"and select" location services" -uncheck the following "Enable GPS satellite set" can be;
Usually if you do not use the Wi-Fi, Bluetooth headset can be improved by turning off these options to the standby time, turn off the WLAN search can save about 30% to 40% of standby time;
Usually close calls and text messages to remind vibration;

5. How crown lock screen, to prevent others from using

In the "Settings", select " Security "and then select "screen lock""pattern", to set individual unlock pattern, to prevent strangers use or purpose of ensuring privacy of confidential documents.

6. Why does not the USB data cable links your computer

Confirmed in the phone's "Settings"-""Developer options"-" in the "USB debugging"functionality check; also installed the correct USB driver

7. How to install a program on a non-Android Market

Select "Settings"-"" Security ", the"unknown source "function check

8. In browsing the web or other applications, how to switch to other applications

If you need to open when browsing other applications, you can long press the Home key to achieving long task switch, long press return directly to the desktop (note that the system default task only last 6 months)

9. How to enter the silent mode quickly

Long press the power key,and directly Into the pop menu to select the silent mode.

10. How to forward SMS / MMS

Long press and Information applications in the information content of an item in the list, until the pop-up shortcut menu, select "Forward" can be realized.

11. how to paste and copy text

Into the input field - "input string, long press and enter the region, there shortcut keys - " select All " " cut All " ,"copy All","paste All"

12. In the phone program group is installed too many applications, how to solve

In the desktop space – sliding the application to another application – click the application to open New Folder

13. Contacts are sorted, can change

Sort of way platform, the first number, then letters, then the Chinese way of sorting; the user can not set their own sort

14. Contacts whether to support the group

In the contacts interface-select group

15. contacts and SMS storage capacity limits the number of

Platform reason, contacts and SMS storage for no clear limit value, depending on the size of the current mobile phone memory space

16. How to set the SD card, personalized ring tones

In the SD card, are established "ringtones" (ringtones) "alarms" (alarm tone) "notifications" (SMS notification tone), the ring tones into a different folder, the phone can be automatically identified.

17. How to sync the phone contacts to the original crown

using Bluetooth the way, the two cellphone, sync contacts;

18. How to use the crown access Wifi (WLAN)

Wifi signal at the scene to ensure that the premise of the specific see "Wifi function "

19. How to Find Contact

Into the contact interface, select the "Search"menu, you can search for contacts, you can use the first letter of query letters;

20. how to download applications for the crown

1) Visit Google Market http://www.android.com/market/; need to pay to download some software;
2) third-party sites, access to applications, such sites are:

http://www.waptw.com/

http://android.sj.91.com/list/rjyxhj.shtml

……

More downloaded software will be installed in the SD card and some software may vary depending on operating system version, network access nodes, size or other reasons can not be used.

21. What are commonly used android forum

http://www.waptw.com/
http://sj.91.com/
http://www.android123.com/
http://www.android86.com.cn/
http://www.androidin.net/bbs/index.php
http://bbs.zhiqi.com.cn/forum-33-1.html
http://www.androidin.net/bbs/
http://www.hiapk.com/bbs/

22. How do I delete the downloaded software

"Settings" - ""Manage app"-"Select the application to be deleted

23. How to view mobile phone version information

"Settings" - "" About phone "mobile phone version information can be obtained, including the Android version, Linux version, software version, hardware version, etc.

24. How do I copy SIM card contact information

Into the Contacts application, click the menu button, select "Import Contacts", then you can see the SIM card contacts, if only to import one, you can click an item. If all the import needs to long press the menu key, select Import to import all.

25. why the message has a different time and date display

Message displayed on the principle that the display of the day time and date have shown that non-day

26.crown whether to support the Java

crown support Java,

27.How to open developer options

Enter the Settings -- the About phone -- click the Build number five times, system will be generated developer options

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

This GSM Mobile Phone meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

FCC RF Exposure Information and Statement

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: Cool 2 (FCC ID: 2AEHZCOOL2FTC) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the ear is 0.717W/kg and when properly worn on the body is 0.671W/kg. This device was tested for typical body-worn operations with the back of the handset kept 1.0cm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 1.0cm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 1.0 cm must be maintained between the user’s body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.