Z CAM®

E2Ⓝ Mark II

4K Professional Camera



Quick User Guide

CAMERA INTRODUCTION



Front



Top



Left



Right



Back



Bottom

POWER SUPPLY

Using PoE+ (Power over Ethernet)❶

- Connect a network cable (category 5e or higher, shielded twisted pair) from the PoE+ power supply device (Compliant with the IEEE802.3at) to [16] LAN/PoE+ port.

Using Camera Battery (LP-E6 compatible)❷

- Mount LP-E6 battery onto [18] Battery Socket of camera;
- Push gently downwards and lock into position.

Using 12V DC❸

- Connect AC DC power adapter (12V/5A) DC output to the [23] Power Socket through LEMO connector;
- Connect AC DC power adapter AC input to AC power outlet (110~240V, 50/60 Hz).

Note:
❶ Network cable is not included in the standard package. For more information on the connection, refer to the instruction manual of the PoE+ power supply device.
❷ Only compatible with LP-E6 battery which is not included in the standard package.
❸ AC-DC power adapter and LEMO connector are optional accessories and not included in the standard package.

HOW TO TURN ON Wi-Fi

- Connect the antenna to the [20] Wi-Fi Antenna Port;
- Turn on the camera. Set Wi-Fi to ON in “Connect” – “Network” settings;
- Press [06] MENU Button to return to home screen. Wi-Fi icon shall be displayed at the top;
- Connect a mobile phone to the camera over Wi-Fi. Default password : 12345678.

INDICATOR[01] [15] STATUS

Green	:	Standby
Red	:	Recording
Flashing Red (every 1s)	:	No storage
Flashing Red (every 0.5s)	:	Storage full
Flashing Red (every 0.2s)	:	Overheat
Flashing Red (very fast)	:	Critical error
Flashing Red (fast & slow alternanting)	:	Low Battery

Z CAM APP

Scan the QR code below to access the Z CAM official app download page, and download and install the Z CAM mobile application.
The app supports connecting to your device via Wi-Fi or USB cable, enabling real-time monitoring and remote control of your Z CAM camera.

DISCLAIMER

All product features and technical specifications stated are subject to the sole interpretation and explanation of Shenzhen ImagineVision Technology Limited, and subject to change without notice.

LIMITED WARRANTY

Warranty Scope
Warranty Service covers defects in material and workmanship of Z CAM E2N Mark II (hereinafter collectively referred to as “this Product”).

Warranty Period
Warranty Period is 12 months from the date of original purchase. Warranty period will start 90 days from date of shipment according to internal record of Shenzhen ImagineVision Technology Limited (herein after referred to as "ImagineVision"), whichever is later, in case of failure to provide valid purchase invoice or other valid proof showing date of original purchase, serviced or replacement product will continue to be covered under the original warranty period of the product.

Warranty Arrangement
In case the product is found defective either due to material or workmanship issues by ImagineVision or its designated/approved service partners within the warranty period, ImagineVision or its designated/approved service partners will carry out repair service or product replacement at no cost. Note that all costs and risks associated with the transportation and delivery of the defective product to ImagineVision or its designated/approved service partners shall be borne by the customer.

Limited Warranty:
- This warranty is non-transferable and non-assignable, and only applicable to the original purchase customer.
- This warranty does not cover any misused, abused, accidentally or intentionally damaged, altered /deleted serial number product.
- This warranty does not cover repaired or replacement products serviced by non ImagineVision authorized service center or personnel.

FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

深圳视觉科技有限公司
广东省深圳市南山区中山园路1001号
TCL国际E城F5栋1A
邮编：518055

www.z-cam.com.cn

版权所有©2026 深圳视觉科技有限公司保留所有权利。
所有商标均为其所有者的财产。