User Manual Version: V1.1

Xiaomi Bluetooth Speaker Essential User Manual - 01
Xiaomi 蓝牙音箱 To Go 使用说明书 - 07
Xiaomi 蓝牙音箱 To Go 使用说明书 - 13
Manual de usuario del Xiaomi Bluetooth Speaker Essential - 16
Manual del usuario del Xiaomi Bluetooth Speaker Essential - 22
Xiaomi Bluetooth Speaker Essential Bedienungsanleitung - 30
Manuel d'utilisation du Xiaomi Bluetooth Speaker Essential - 36
Manuale utente Xiaomi Bluetooth Speaker Essential - 42
Руководство пользователя портативной колонки Xiaomi Bluetooth Speaker Essential - 48
Instrukcja obsługi Xiaomi Bluetooth Speaker Essential - 54
Manual de utilizador do Xiaomi Bluetooth Speaker Essential - 60
Xiaomi Bluetooth Speaker Essential Kullanım Kılavuzu - 66
Xiaomi Bluetooth Speaker Essential 小型 蓝牙音箱 - 72
Xiaomi Bluetooth Speaker Essential 사용 설명서 - 78
Xiaomi Bluetooth Speaker Essential ภาษาไทย คู่มือ - 84
Посібник користувача Xiaomi Bluetooth Speaker Essential - 90
Xiaomi Bluetooth Speaker Essential Tiếng Việt - 96
Hướng dẫn sử dụng Xiaomi Bluetooth Speaker Essential - 102

Read this manual carefully before use, and retain it for future reference.

Specifications

Name: Portable Bluetooth Speaker
Model: Essential
Wireless Connectivity: Bluetooth 5.0
Rating: 5Vdc
Wireless Frequency Range: 2402 MHz–2480 MHz
EIRP: 2402 MHz–2480 MHz:≤20dBm
Wireless Protocol: Bluetooth 5.0

* The model parameters and safety information of the speaker are provided in the user manual and on the product nameplate.
* The IPX7 rate of the speaker only refers to its sealing ring and not its charging port.

Important Safety Information

Thank you for purchasing the Bluetooth speaker (such for outdoor audio enjoyment, with high-quality sound and long-lasting battery life).
Read all safety information below before using your device:

* Keep the speaker away from water.
* The speaker may lose sound and waterproof performance when the protective cover of the charging port is lightly sealed.
* Do not use the speaker while charging and in a highly closed or all-mesh cover.
* When using the protective cover of the charging port, ensure that no foreign objects are inside.
* During charging, keep the speaker away from water, humid or high temperature environments.
* Do not use the speaker in places with high water pressure such as under a shower, and do not place it in water or spash it with hot water.
* Do not disassemble or modify the speaker. The speaker is not permanently effective, and will decrease due to daily wear and tear.

Maintenance methods

* If the surface of the speaker is dirty, wipe it with a cloth in time to avoid fading or other damage.
* If the surface of the speaker comes into contact with water, wipe it dry as soon as possible to avoid affecting the appearance and service life of the speaker.
* If foreign objects such as dust and sand enter the speaker, carefully remove them. Do not use sharp objects to remove them, to avoid damage to the internal structure.
* Do not use a vacuum cleaner, a hair dryer, or other devices on the speaker, as it may damage it.

Precautions

* When using the speaker in your hand, hold the speaker firmly to avoid dropping and causing damage.
* When placing the speaker, put it on a flat horizontal surface and keep it away from heat sources and direct sunlight. Avoid placing it in a place where it may fall and cause damage to the device.
* Do not place the speaker in a place where the speaker or the following equipment: high-temperature (above 45°C), under direct sunlight, under lighting fixtures, near heat sources, or in saunas and other high-temperature environments, may cause fire or explosion. Excessive heat can also cause a system to enter a dangerous situation.
* Do not place the speaker in a place where the temperature is too high (exceeding 45°C) or high humidity environments.
* Do not place the speaker in a low-temperature range (-20°C to 0°C).
* It is not advisable to or high temperature environments, the speaker may not be charged normally, and the battery life may be affected. Please use it in a normal temperature.
* If the speaker is not used for a long time, it is recommended to fully charge it once every six months to maintain battery performance.

Rechargeable battery statement

* Do not place the battery in extremely high temperature environments, such as in direct sunlight, near a heater, or in a microwave oven. Do not place the battery in a place where it is flooded or in liquid. Prohibited to puncture, crush, or throw the battery.
* Do not use the battery in high-voltage environments. Please touch or pick the battery with dried objects or screwdrivers. Otherwise, the battery may explode.
* Do not disassemble, modify, or tamper with the battery. Do not use the battery, charger, or other flammable liquids or gases.
* Do not use the battery in a place where it may be in metal contact with metal wires, or short circuit can cause the battery to overheat, leading to personal injuries such as burns.
* The battery contains a small amount of rare earth metals. Keep it away from children. Do not let children or pets touch the battery. Do not let the battery be crushed by heavy overload, leak battery fluid, or even explode, which will result in personal injuries.
* When using the battery, if there is a leak, a bad smell, or other abnormal phenomena, stop using it and contact customer service. Do not use the battery if it is damaged, deformed, or abnormally hot. Do not use the battery if it is damaged, deformed, or abnormal in appearance, or if the battery is aged. Disassembling or modifying a battery will not be covered under warranty. Built-in batteries can only be replaced by Xiaomi's authorized service providers. Improper battery replacement may cause fire or explosion. Household waste. Improper battery disposal may cause fire or explosion. Ensure that you dispose of the battery in accordance with local environmental protection laws and regulations.

Electrical safety information

* Improper use of the charging adapter may contain dangerous electrical current. To avoid the risk of electric shock, follow the safety instructions below.
* Do not disassemble, modify, or tamper with the charger. Do not perform installation, maintenance, or other unauthorized operation operations.
* Do not use the charger in a place where it may be difficult to unplug the power.
* Use a certified power adapter (self-assembly) that complies with the power supply requirements of the speaker for charging.

* Use of unauthorized cables, power adapters can cause fire, explosion, or even other risks.
* When charging is complete, disconnect the adapter from both the device and the power outlet.
* For AC/DC adapters, the socket-outlet shall be installed near the equipment and shall be easily accessible.
* Unless otherwise specified, always disconnect the power cord and other cables before cleaning or performing maintenance.

WARRANTY NOTICE

Thank you for purchasing our product!
Our products bearing the operation and related and electronic equipment WEEE as a Class A or Class B EQUIPMENT which should not be mixed with unsorted municipal waste. Please contact your local authorized dealer for information on environment by handing over your waste equipment to a designated collection point for the purpose of recycling. Please contact your local authorized dealer or the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences for the environment and human health. Please contact your local retailer or local authorities for more information about the location as well as terms and conditions of recycling of this product.
The product is in compliance with the TSDI regulations, the full text of declaration of conformity is available at the following internet address: https://www.mi.com/global/support/terms/declaration

FCC Regulations

* Under This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning this equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
  - Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.
* This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.
* Caution:
  Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
* This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.
* Use only the supplied and approved adapter when using the product in the United States.

Xiaomi Technology Netherlands B.V.
Address: Zuidplein 36, Zuidplein Kantoren WE, 1081 BW, The Hague, The Netherlands
customer@xiaomi.eu
Hotline: 0800 022 0088
KAI-FAN TECHNOLOGY (HK) LIMITED
Address: Unit 1001-1002, 10/F, No.11-15 Shu Kwan Road, Lantau, England, 215-337
customer@xiaomi.com.hk

The power delivered by the charger shall be between min.0.5Watts required by the safety equipment, and max.30Watts in order to achieve the maximum charging speed.

The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Xiaomi Inc. is under license. Other trademarks and trade names are those of their respective owners.

Type-C Interface CIP Cable: ≤ 0.5 M
Temp & Hum Use Condition: 5 ~ 45℃
Note:
Please use a compatible and qualified adapter with an output of 5 V=1.5 A, 9 V=1.5 A to ensure the product.

Manufacturer: Xiaomi Communications Co., Ltd.
Address: 6th Floor, Building 15, Kexing Science Park, Yuedong District, Beijing, 100085, China
For more information, please go to www.mi.com
User Manual Version: V1.1