Bluetooth AI Translation Stick User Guide

Bluetooth AI translation stick user's manual

Please read carefully before use

Product Function Description



Download and connect to the app

1. Scan the QR code below with your mobile phone to install the translation and communication APP

2. Open the mobile APP account with the mobile account to log in

3. Follow the operation steps to complete the connection with the translation stick.
Main: Location/Bluetooth/Microphone /Notification and other permissions need to be selected and allowed;
IOS system mobile phone needs to manually connect to the Bluetooth device prefixed with AUD in the Bluetooth settings.

Switch machine.

Press and hold the power button to switch the translation stick.

Dialogue translation

1. Press and hold the A key to speak, and release it to translate the language corresponding to the A key in the APP;

2. Press and hold the B key to speak, and release it to translate the language corresponding to the APPB middle key.

Language switch selection

Please switch the language at the top of the APP:



Repeat

1. Short press the M button to play and repeat the last translation content, and you can listen to the repeat while following it.

AI assistant

Long press the M button to enter the AI assistant function, which can conduct encyclopedia questions and answers, play nursery rhymes, listen to opera comics, and more than 40 AI artificial intelligence skills.
How to use: Long press the M key to speak the question you need to know, and after releasing it, the corresponding answer or corresponding audio content will be played.

Volume addition and subtraction

1. Short press the A button to increase the volume;

2. Short press the B button to decrease the volume.

State of work light

1. The red light is on in the charging state;
2. The blue light is on after fully charged;
3. The red light flashes in the low power state;
4. The blue light keeps flashing slowly when the Bluetooth is not connected when the device is turned on;
5. The blue light goes out after successful Bluetooth connection;
6. Turn off the voice broadcast without lighting;
7. Press the A/B button to pick up the sound and turn on the blue light, let go and start translating and turn off the light;
8. To repeat the last sentence, press the M button and the blue light will flash once to start repeating.

Troubleshooting

The translation stick often disconnects from the phone

1. Switch the Bluetooth of the mobile phone again;
2. Close the APP in the background and reopen it;
3. Try to connect the translation stick after restarting the phone.

The translation stick is silent after connecting to the app

1. Please turn the phone and translation stick to the maximum;
2. (IOS) Please go to the Bluetooth settings and confirm that the AUD Bluetooth device has been connected, and the audio data needs to be connected to transfer to the translation stick.

Can not boot

1. Check whether the battery is exhausted, connect the charger and charge it for 2 minutes and check whether the red light is on.

Precautions

★ Do not random discard the machine or place it in a fire, as it may cause danger because of built-in polymer battery.

★ The charging voltage of this machine is 5V. When charging this machine, use a 5V charger. If you charge this machine with a charger higher than 5V, it will burn out the chip inside the machine and cause the machine to malfunction.

The following conditions are not covered by the warranty:

★ 1. due to improper use of the user, and self-repairing caused by artificial disassembly;

★ 2. Failure caused by irresistible factors (such as flood, fire, earthquake, lightning, etc.) after purchase;

★ 3. no product warranty card, valid purchase certificate, Don' t match the product model.

Warranty

Warranty Terms

1 year warranty Since purchasing this product, the user enjoys free warranty service when the machine fails according to the user manual operation instruction.
When applying the warranty, the user needs to present a valid proof of purchase to the local dealer, and the dealer will contact the manufacturer for repairs.
During the warranty period, the manufacturer will charge a reasonable raw material fee or maintenance fee based on the specific failure in the following circumstances:
1. Damage caused by improper storage, improper use, fall off , or failure to use as required after purchase.
2. Damage caused by disassembly, maintenance, and cleaning of the machine without permission.
3. the appearance of scratches during use, artificial damage and other circumstances need to replace the new shell.
4. The use of fast charging causes the machine to malfunction (including fast charging head and fast charging cable), please use the charging cable that comes with the machine to charge.

Note: The company has the

Warranty Card

WARRANTY CARD

Thank you for purchasing our products, please fill in the following content when purchasing and save this card properly .

User profile

Contact person:_____

Contact number :_____

Date of purchase :_____

Purchase address:_____

contact address:_____

Remark:_____

★ Warranty with this card

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.