USER MANUAL


Hi! Let's Start Now

Model: KM7

Accessories




Media Player | User Manual | Voice Remote




HDTV Cable | Power Adapter

01

1 | Connection Diagram:



2 | BT Voice TV Remote Guide:



02

3 | Google Assistant:

Simplify your entertainment experience with Android TV, by signing into your Google account.
Press the Google Assistant button on your remote to talk to Google.

4 | System Setting Function:

- Screen settings: You can adjust the screen zoom so that the screen shows the best status.
- Resolution settings: The machine defaults to automatic, You can manually adjust to the best display status.
- Date & time settings: Set your GMT time, and time display format. (Note: The system display time is synchronized with the network time after the network connection is successful.).
- Uninstall APPS: You can uninstall unwanted APKs to keep your system in top condition.
- Factory reset: Be careful to do this. All the data will be cleared after factory data reset.

Android TV makes it easier to get more from your TV. Choose from a huge selection of movies, TV shows, music and games, Ask Google to control your TV, get recommendations of what to watch, dim the lights, and more with your voice, Cast photos, videos, and music from smart devices to your TV with Chromecast built-in™.

* Subscriptions may be required for certain content providers.
* Casting optimized for selected services only. Streaming quality for video content might vary. Supported operating systems and devices: Android™ 5.0 and higher, iOS™ and higher, Windows 7 and higher, Mac OS™ 10.7 and higher and Chrome OS (version 38 or higher).

5 | Firmware Update Instruction:

[System Update]
-Run the "System update" app.
-Select System update, the device will detect and update to the latest version.

03

Your system is up to date

Check for update

Last checked: Some unspecified number

Note: DO NOT power off the device during updating process.
Please do not download any third party software to upgrade, This product belongs to genuine system, The upgrade will only be operated through OTA, or please contact the seller to upgrade.

6 | Troubleshooting Manual:

In any case, please do not try to repair the TV box yourself, so as not to invalidate the warranty. Do not open it because there is a risk of electric shock. If any problems occur, you can check them first by referring to the methods listed below. If you are unable to resolve the issue through the list below, please contact the dealer for assistance.

Problem	Solution
No signal	• Make sure the connecting cable is plugged in correctly. • Check if the cable is damaged. If damaged, replace it with a new one. • Ensure that the connection between the cable and the TV is secure. Unplug and replug the cable to ensure a proper connection. • Check if the TV is set to the correct input source. Use the TV remote control to switch between different input sources (e.g., HDMI, AV) and see if the signal appears.
Wi-Fi signal is weak or not supported	• Move the device closer to the Wi-Fi router to improve signal strength. • Make sure the device is connected to the correct Wi-Fi network and that the password is entered correctly. • Restart the Wi-Fi router and the device to refresh the connection. • Check if the device supports the Wi-Fi frequency band (2.4GHz or 5GHz) that your router is using. If not, connect to the appropriate band.
Video playback issues	• Check the internet connection speed. Slow speeds can cause buffering or poor video quality. • Clear the cache and data of the video playback app. • Update the app to the latest version.
Audio problems	• Make sure the volume is not muted and is set to an appropriate level. • Check the audio output settings and ensure the correct audio output device is selected.

7 | Tips

- Keep a minimum of 10cm clearance around the device, do not cover newspapers or other items
- The equipment must not be exposed to water droplets or water splashes, Objects such as vases filled with liquids must not be placed on the machine
- Keep the product away from moisture, exposure, high temperatures, etc, away from magnetic objects
- Avoid scratching the case and the interface, and prevent damage due to falling, throwing or strong impact
- Use a dedicated power adapter to prevent damage to important components on the motherboard due to excessive current
- Please do not attempt to disassemble this product yourself, The repair work is only for authorized personnel of the company
- The battery must not be exposed to some conditions like sunlight, fire, or other overheating environment

04

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation, If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1)This device may not cause harmful interference
(2)This device must accept any interference received, including interference that may cause undesired operation

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator &your body

FCC ID: 2AGKM-KM7

Google, Android, Google Play, YouTube and other marks are trademarks of Google LLC.

05

Dear Customer,

Thank you so much for your purchased, we hope that our product can meet your needs and expectations.

If you have any problem with the product, please do not hesitate to contact us,We will reply to you at supreme@aoni.com and provide the best service for you.

Thanks again and best wishes for you!

Customer Service Email:
supreme@aoni.com

06

RoHS

MADE IN CHINA